



BEC 8920NE

The Ultimate Residential Gateway

User Manual

TABLE OF CONTENTS

CHAPTER 1: INTRODUCTION	1
INTRODUCTION TO YOUR ROUTER	1
FEATURES & SPECIFICATIONS	2
HARDWARE SPECIFICATIONS	6
APPLICATIONS DIAGRAM	6
CHAPTER 2: PRODUCT OVERVIEW	7
IMPORTANT NOTE FOR USING THIS ROUTER	7
PACKAGE CONTENTS	7
DEVICE DESCRIPTION	8
The Front LEDs	8
The Rear Ports	9
CABLING	9
CHAPTER 3: BASIC INSTALLATION	10
NETWORK CONFIGURATION	11
Configuring a PC in Windows 7	11
Configuring a PC in Windows Vista	13
Configuring a PC in Windows XP	15
Configuring a PC in Windows 2000	16
Configuring PC in Windows 98/Me	17
Configuring PC in Windows NT4.0.....	18

FACTORY DEFAULT SETTINGS	19
INFORMATION FROM YOUR ISP	20
CONFIGURING WITH YOUR WEB BROWSER	21
CHAPTER 4: BASIC CONFIGURATION.....	22
STATUS	23
WAN Info.....	24
Statistics.....	25
<i>LAN</i>	25
<i>WAN Service</i>	25
<i>xTM</i>	26
<i>xDSL</i>	27
<i>Route Table</i>	28
<i>ARP Table</i>	29
<i>DHCP Table</i>	29
<i>System Log</i>	29
CONFIGURATION	30
LAN - Local Area Network	30
WAN - Wide Area Network	32
<i>Layer2 Interface</i>	32
<i>WAN Service</i>	34
<i>DSL</i>	42
SYSTEM	43
Time Zone	43
Firmware Upgrade	44
Backup / Restore.....	44
Restart	45

User Management	46
FIREWALL.....	47
IP Filtering	47
<i>MAC Filtering</i>	50
QoS - QUALITY OF SERVICE.....	52
Queue Config	52
QoS Classification.....	53
VIRTUAL SERVER.....	56
Port Mapping	57
DMZ Host	58
ADVANCED.....	59
Routing.....	59
Default Gateway	59
Static Route.....	59
RIP.....	60
DNS.....	60
DNS Server	60
Dynamic DNS	61
INTERFACE GROUPING	62
DEVICE MANAGEMENT	64
<i>Installing UPnP in Windows Example</i>	64
<i>Auto-discover Your UPnP-enabled Network Device</i>	66
<i>Web Configurator Easy Access</i>	68
System Log Server	69
TR-069 Client.....	70
DIAGNOSTICS.....	71

Diagnostics.....71

Fault Management.....72

CHAPTER 5: TROUBLESHOOTING73

APPENDIX: PRODUCT SUPPORT & CONTACT74

Chapter 1: Introduction

Introduction to Your Router

Thank you for purchasing **BEC 8920NE The Ultimate Residential Gateway**. The BEC 8920NE is an all-in-one Universal Bonded Gateway supporting ultra-broadband triple-play services via multiple WAN connection options. Service providers can utilize one gateway for all major broadband technologies such as ADSL2+, VDSL2, xDSL bonding and FTTH. In addition to offering the multiple WAN connection options, the 8920NE integrates multiport Ethernet switching and routing, 802.11n Wireless networking, advanced firewall security including stateful packet inspection, Quality of Service (QoS) and remote management. Users can easily enjoy high bandwidth services such as High Definition IPTV, streaming video, interactive gaming, over-the-top (OTT) applications to multiple devices throughout the home.

Flexible Deployment Options

The BEC 8920NE provides service operators with flexible, scalable deployment options optimized to both reduce costs and provide the longest possible lifespan for the investment. The BEC 8920NE integrates dual WAN options; a VDSL2/ADSL2+ interface and a second 10/100/1000 Ethernet WAN interface which can be used for broadband connectivity to any other Ethernet broadband device. Operators can now deploy one device to support current and future network migration.

Quality of Service

Quality of Service (QoS) gives users' full control over outgoing data traffic. Priority can be assigned by the router to ensure that important transmissions like gaming packets, VoIP calls or IPTV/streaming content passes through the router at lightning speed, even when there is heavy Internet traffic. The speed of different types of outgoing data passing through the gateway is also controlled to ensure that users do not saturate bandwidth with their browsing activities.

Robust Firewall Security

The NAT default firewall has advanced anti-hacker pattern-filtering protection features that automatically detect and block Denial of Service (DoS) attacks. In addition, Packet Filtering provides high-level security for access control. Built with Stateful Packet Inspection (SPI), the router enables users to determine whether or not a data packet is allowed to pass through the firewall to the private LAN.

Optimal Wireless Speed and Coverage

With an integrated 802.11n Wireless Access Point, the router delivers up to 6 times the speed and 3 times the wireless coverage of an 802.11b / g network device. It supports a link rate up to 300Mbps and is also compatible with 802.11b/g equipment. The Wireless Protected Access (WPA-PSK/WPA2-PSK) and Wireless Encryption Protocol (WEP) features enhance the level of transmission security and access control over Wireless LAN. The router also supports the Wi-Fi Protected Setup (WPS) standard for easy and secure establishment of a wireless home network. If the user's network requires wider coverage, the built-in Wireless Distribution System (WDS) repeater function expands the wireless network without needing any external wires or cables.

Pathway to the Future

The BEC 8920NE fully supports IPv6 (Internet Protocol Version 6), implementation of IPv6 is growing significantly and multiple transition methods are required to support the coexistence and migration from IPv4. With BEC IPv6 enabled devices, service providers easily adapt IPv6 to their network as we support major transition mechanisms such as Dual-Stack, Dual-Stack Lite, and 6RD.

Features & Specifications

VDSL Compliance

- Compliant with ITU-T G.993.2, G.994.1 and G.997.1 VDSL2 Standard
- VDSL2 Profiles for one line: 8a, 8b, 8c.8d,12a,12b, 17a
- VDSL2 Profiles for two line: 8a, 8b, 8c.8d,12a, 12b
- ADSL/2/2+ fallback modes
- Comply G.993.5, G.998.2 and G.998.4

ADSL Compliance

- Compliant with ADSL Standards
 - Full-rate ANSI T1.413 Issue 2
 - G.dmt (ITU G.992.1)
 - G.lite (ITU G.992.2)
 - G.hs (ITU G.994.1)
- Compliant with ADSL2 Standards
 - G.dmt.bis (ITU G.992.3)
 - ADSL2 Annex M (ITU G.992.3 Annex M)
- Compliant with ADSL2+ Standards
 - G.dmt.bis plus (ITU G.992.5)
- Comply ITU T G.998.1 and G.998.2

Network Protocols and Features

- NAT, static routing and RIP-1/2
- Universal Plug and Play (UPnP) Compliant
- Transparent Bridging
- Dynamic Domain Name System (DDNS)
- Virtual Server and DMZ
- SNTP, DNS relay and IGMP proxy
- VLAN_MUX and IGMP snooping for video service
- Management based-on IP protocol, port number and address
- SMTP Client

Quality of Service Control

- Supports the DiffServ approach
- Traffic prioritization and bandwidth management based-on IP protocol, port number and address

Firewall & Virtual Private Network (VPN)

- Built-in NAT Firewall
- Stateful Packet Inspection (SPI)
- Prevents DoS attacks including Land Attack and Ping of Death, etc.
- Remote access control for web base access
- Anti probe function
- Packet filtering, MAC filtering, URL content filtering
- Password protection for system management
- VPN pass-through

Wireless LAN

- Compliant with IEEE 802.11n, 802.11g and 802.11b standards
- 2.4 GHz - 2.484 GHz frequency range
- Up to 300Mbps wireless operation rate
- WPS (Wi-Fi Protected Setup) supported
- 64/128 bits WEP supported for encryption
- Wireless Security with WPA-PSK/ WPA2-PSK support
- WDS repeater function support
- ATM Adaptation Layer Type 5 (AAL5)
- Multiple Protocol over AAL5 (RFC 2684, formerly RFC 1483)
- Bridged or routed Ethernet encapsulation
- VC and LLC based multiplexing
- PPP over Ethernet (PPPoE)
- PPP over ATM (RFC 2364)
- Classical IP over ATM (RFC 1577)
- MAC Encapsulated Routing (RFC 1483 MER)
- OAM F4/F5
- ATM QoS: UBR, CBR, VBR-rt, VBR-nrt

Management

- Quick Installation Wizard
- Web-based GUI for remote and local management
- Firmware upgrades and configuration data transfer via web-based interface
- Embedded Telnet server for remote and local management
- Available syslog
- Supports DHCP server/client/relay
- SNMP v1/v2, MIB supported

Hardware Specifications


Physical interface

- DSL: Single xDSL RJ-11 Interface
- E-WAN: Giga Ethernet WAN port can be connected to ADSL/Cable/VDSL/Fiber modem device
- Ethernet MDI/MDIX Switch: 3-port 10/100Mbps and 1-10/100/1000Mbps port (GigaConnect ®)
- Factory default reset button
- WPS push button
- Power jack
- Power switch
- WLAN: 2 antennas

Physical Specifications

- Dimensions: 9.04" x 6.10" x 1.46" (229.5mm x 155mm x 37mm)

Applications Diagram



Chapter 2: Product Overview

Important note for using this router



Warning

- Do not use the router in high humidity or high temperatures.
- Do not use the same power source for the router as other equipment.
- Do not open or repair the case yourself. If the router is too hot, turn off the power immediately and have it repaired at a qualified service center.
- Avoid using this product and all accessories outdoors.



Attention

- Place the router on a stable surface.
- Only use the power adapter that comes with the package. Using a different voltage rating power adaptor may damage the router.

Package Contents

- ✓ **BEC 8920NE The Ultimate Residential Gateway**
- ✓ **RJ-45 Ethernet Cable**
- ✓ **Y-Cable for VDSL bonded operation**
- ✓ **Two wireless detachable antennas**
- ✓ **Power adaptor**


Device Description

The Front LEDs



LED	Function
1 Power (PWR)	Lit green: when the device is ready. No light: when no power is connected.
2 Ethernet (ETH) 1 - 3	Lit green: when LAN port is connected to an Ethernet device. Flashing green: when data is being Transmitted / Received. No light: when no LAN port is not being connected.
3 Gigabit Ethernet (ETH) 4	This is a Gigabit LAN Ethernet port. Lit green: when LAN port is connected to an Ethernet device. Flashing green: when data is being Transmitted / Received. No light: when no LAN port is not being connected.
4 GbEthernet (GbE)	WAN port for broadband connectivity Lit green: when connected to a Cable modem, xDSL modem, Fiber (PON) modem's Ethernet port.
5 Wireless (WLAN)	Lit green: when the wireless connection is enabled. Flashing green: when the device is sending/receiving data. No light: when wireless function is off
6 WPS	Lit green: when wireless device(s) has connected successfully connected to the wireless network via WPS mode. Flashing green: when WPS is enabled and trying to establish a WPS connetion. No light: when WPS function is off
7 DSL / DSL2	Lit green: DSL is in sych with DSLAM and connection is up. Quick Flashing green: DSL trys to establish handshke with the DSLAM. Slow Flashing green: No DSL link
8 INET	Lit green: when Internet is being connected; IP recieved. Flashing green: when the device is sending/recieving data traffic. No light: Device is either off or DSL failed to connect.

The Rear Ports



Port		Function
1	Wireless detachable antenna (ANT)	Connect a wireless detachable antenna to this port.
2	DSL	Connect the device to an ADSL/VDSL telephone jack or splitter using a RJ-11 telephone cable
3	WAN	Connect to a Cable modem, xDSL modem, Fiber (PON) modem.
4	Ethernet (1~4)	Connect your computer or an Ethernet device to a LAN port, using the included Ethernet cable.
5	USB *future release	Both USB1 and USB2 can be connected to a USB device, such as, HDD. *future release
6	Reset Button	Press it to reset the device or restore to factory default settings.
7	Power Switch	Power ON/OFF switch
8	Power Jack	Connect the supplied power adapter to this jack.
9	Wireless detachable antenna (ANT)	Connect the 3G / 4G detachable antenna to this port.

Cabling

The most common problem associated with Ethernet is bad cabling. Make sure that all connected devices are turned on. In the front of the product is a bank of LEDs. Verify that the LAN Link and WAN Link LEDs are lit. If they are not, verify that you are using the proper cables.

Chapter 3: Basic Installation

You can configure the **BEC 8920NE The Ultimate Residential Gateway** through the convenient and user-friendly interface of a web browser. Most popular operating systems such as Linux and Windows 98 / NT /2000 / XP / ME / 7 / Vista include a web browser as a standard application.

PCs must have a properly installed Ethernet interface which connects to the router directly or through an external repeater hub. In addition, PCs must have TCP/IP installed and configured to obtain an IP address through a DHCP server or a fixed IP address that must be in the same subnet as the router. The default IP address of the router is **192.168.1.254** and the subnet mask is **255.255.255.0** (i.e. any attached PC must be in the same subnet, and have an IP address in the range between 192.168.1.1 and 192.168.1.253). The easiest way is to configure the PC is to obtain an IP address automatically from the router using DHCP. If you encounter any problems accessing the router's web interface you are advised to **uninstall** any kind of software firewall on your PCs, as they can cause problems when trying to access the 192.168.1.254 IP address of the router.

Please follow the steps below for installation on your PC's network environment. First of all, check your PC's network components. The TCP/IP protocol stack and Ethernet network adapter must be installed. If not, please refer to your Windows-related or other operating system manuals.




Any TCP/IP capable workstation can be used to communicate with or through the **BEC 8920NE The Ultimate Residential Gateway**. To configure other types of workstations, please consult the manufacturer's documentation.


Network Configuration

Configuring a PC in Windows 7

1. Go to **Start**. Click on **Control Panel**.
2. Then click on **Network and Internet**.
3. When the **Network and Sharing Center** window pops up, select and click on **Change adapter settings** on the left window panel.
4. Select the **Local Area Connection**, and right click the icon to select **Properties**.




5. Select **Internet Protocol Version 4 (TCP/IPv4)** then click **Properties**.




6. In the **TCP/IPv4 properties** window, select the **Obtain an IP address automatically** and **Obtain DNS Server address automatically** radio buttons. Then click **OK** to exit the setting.

7. Click **OK** again in the **Local Area Connection Properties** window to apply the new configuration.




Configuring a PC in Windows Vista

1. Go to **Start**. Click on **Network**.
2. Then click on **Network and Sharing Center** at the top bar.
3. When the **Network and Sharing Center** window pops up, select and click on **Manage network connections** on the left window pane.
4. Select the **Local Area Connection**, and right click the icon to select **Properties**.




5. Select **Internet Protocol Version 4 (TCP/IPv4)** then click **Properties**.




6. In the **TCP/IPv4 properties** window, select the **Obtain an IP address automatically** and **Obtain DNS Server address automatically** radio buttons. Then click **OK** to exit the setting.

7. Click **OK** again in the **Local Area Connection Properties** window to apply the new configuration.




Configuring a PC in Windows XP


1. Go to **Start**. Click on **Control Panel**.
2. Then click on **Network and Internet**.




3. In the **Local Area Connection Status** window, click **Properties**.



4. Select **Internet Protocol (TCP/IP)** and click **Properties**.



5. Select the **Obtain an IP address automatically** and the **Obtain DNS server address automatically** radio buttons.



6. Click **OK** to finish the configuration.

Configuring a PC in Windows 2000

1. Go to **Start / Settings / Control Panel**. In the Control Panel, double-click on **Network and Dial-up Connections**.





2. Double-click **Local Area Connection**.

3. In the **Local Area Connection Status** window click **Properties**.

4. Select **Internet Protocol (TCP/IP)** and click **Properties**.

5. Select the **Obtain an IP address automatically** and the **Obtain DNS server address automatically** radio buttons.


6. Click **OK** to finish the configuration.




Configuring PC in Windows 98/Me

1. Go to **Start / Settings / Control Panel**. In the Control Panel, double-click on **Network** and choose the **Configuration** tab.

2. Select **TCP/IP ->NE2000 Compatible**, or the name of your Network Interface Card (NIC) in your PC.




3. Select the **Obtain an IP address automatically** radio button.



4. Then select the **DNS Configuration** tab.


5. Select the **Disable DNS** radio button and click **OK** to finish the configuration.




Configuring PC in Windows NT4.0

1. Go to **Start / Settings / Control Panel**. In the Control Panel, double-click on **Network** and choose the **Protocols** tab.

2. Select **TCP/IP Protocol** and click **Properties**.



3. Select the **Obtain an IP address from a DHCP server** radio button and click **OK**.



Factory Default Settings

Before configuring the router, you need to know the following default settings.

Web Interface: (Username and Password)

- ▶ Username: admin
- ▶ Password: admin

The default username and password are “**admin**” and “**admin**” respectively.



If you ever forget the username/password to login to the router, you may press the RESET button up to 6 seconds then release it to restore the factory default settings.

Caution: After pressing the RESET button for more than 6 seconds then release it, to be sure you power cycle the device again.

Device LAN IP settings

- ▶ IP Address: 192.168.1.254
- ▶ Subnet Mask: 255.255.255.0

DHCP server

- ▶ DHCP server is enabled.
- ▶ Start IP Address: 192.168.1.100
- ▶ IP pool counts: 100

LAN Port Addresses

The parameters of LAN and WAN ports are preset at the factory. The default values are shown below.

LAN Port	
IP address	192.168.1.254
Subnet Mask	255.255.255.0
IP addresses for distribution to PCs	100 IP addresses continuing from 192.168.1.100 through 192.168.1.199

Information from your ISP

Before configuring this device, you have to check with your ISP (Internet Service Provider) what kind of services are provided, such as PPPoE, Obtain an IP Address Automatically, Fixed IP address.

Gather the information as illustrated in the following table and keep it for reference.

PPPoE(RFC2516)	VPI/VCI, VC / LLC-based multiplexing, Username, Password, Service Name, and Domain Name System (DNS) IP address (it can be automatically assigned by your ISP when you connect or be set manually)
PPPoA(RFC2364)	VPI/VCI, VC / LLC-based multiplexing, Username, Password and Domain Name System (DNS) IP address (it can be automatically assigned by your ISP when you connect or be set manually)
Obtain an IP Address Automatically	DHCP Client (it can be automatically assigned by your ISP when you connect or be set manually).
Fixed IP Address	IP address, Subnet mask, Gateway address, and Domain Name System (DNS) IP address (it is fixed IP address).
Bridge	VPI/VCI, VC / LLC-based multiplexing to use Bridged Mode

Configuring with your Web Browser

Open your web browser, enter the IP address of your router, which by default is **192.168.1.254**, and click **Go**, a user name and password window prompt appears. Enter the user name and password that your administrator has set for you then click **OK**. When you are authorised, you will access to the router.

The default username and password are **“admin”** and **“admin”** respectively for the Administrator account type.

Congratulations! You have successfully logged on to your **BEC 8920NE The Ultimate Residential Gateway!**



Status	
▼ Device Information	
Model Name	BEC 8800N
Host Name	gateway
System Up-Time	8 min(s) 47 seconds
Current Time	Sat Jan 1 00:08:47 2000
Hardware Version	ANNEX A
Software Version	1.00m
MAC Address	00:04:ed:88:00:01
Wireless Driver Version	5.10.85.0.cpe4.402.0
▼ DSL connection information	
Line Rate - Upstream (Kbps)	
Line Rate - Downstream (Kbps)	
LAN IPv4 Address	192.168.1.254
Default Gateway	
Primary DNS Server	
Secondary DNS Server	

Chapter 4: Basic Configuration

Once you have logged on to your router via your web browser, you can begin to set it up according to your requirements. On the configuration homepage, the left navigation pane links you directly to the setup pages, which includes:

Status

- WAN Info
- Statistics
- Route Table
- ARP Table
- DHCP Table
- System Log

Configuration

- LAN
- WAN
- System
- Firewall
- QoS
- Virtual Server
- Advanced

Diagnostic

- Diagnostics
- Fault Management

Status

Status	
Device Information	
Model Name	BEC 8800N
Host Name	gateway
System Up-Time	8 min(s) 47 seconds
Current Time	Sat Jan 1 00:08:47 2000
Hardware Version	ANNEX A
Software Version	1.00m
MAC Address	00:04:ed:88:00:01
Wireless Driver Version	5.10.85.0.cpe4.402.0
DSL connection information	
Line Rate - Upstream (Kbps)	
Line Rate - Downstream (Kbps)	
LAN IPv4 Address	192.168.1.254
Default Gateway	
Primary DNS Server	
Secondary DNS Server	

Device Information

Model Name: Displays the model name.

Host Name: Provide a name for the router for identification purposes. Host Name lets you change the router name.

System Up-Time: Records system up-time.

Current time: Set the current time. See the **Time Zone** section for more information.

Hardware Version: Device version.

Software Version: Firmware version.

MAC Address: The LAN MAC address.

DSL connection information

DSL connection information: User can look up to see all the information for DSL connection: Upstream/Downstream Line Rate (Kbps), LAN IPv4 Address, Default Gateway, and Primary/Secondary DNS Server.

WAN Info

The WAN Info screen displays the configured PVC(s) and the status.

Interface: Shows connection interfaces.

Description: Shows the user defined name of WAN service.

Type: Shows the connection type, such as PPPoE, IPoE and so on.

VlanMuxId: Shows the status of the VLAN MuxId.

Igmp: Shows the status of the IGMP function.

NAT: Shows the status of the NAT.

Firewall: Shows the status of the firewall.

Status: Shows the connection state of the WAN connection.

IPv4 Address: Shows IP address for WAN interface.

Statistics

These are the items within the Statistics section: [LAN](#), [WAN Service](#), [xTM](#) and [xDSL](#).

LAN

This screen shows interface statistics for LAN of Ethernet interfaces.

Interface	Received				Transmitted			
	Bytes	Pkts	Errs	Drops	Bytes	Pkts	Errs	Drops
eth1	3648403	22772	0	0	5345495	9362	0	0
eth2	0	0	0	0	72262	334	0	0
eth3	30656	104	0	0	2182	20	0	0
eth0	0	0	0	0	71020	324	0	0

Reset Statistics

Interface: Lists connection interfaces.

Received/Transmitted Bytes: Rx/TX (receive/transmit) packet in Byte.

Received/Transmitted Pkts: Rx/TX (receive/transmit) packets.

Received/Transmitted Errs: Rx/TX (receive/transmit) packets that are errors.

Received/Transmitted Drops: Rx/TX (receive/transmit) packets that are dropped.

Reset statistics: Click to update the statistics.

WAN Service

Interface	Description	Received				Transmitted			
		Bytes	Pkts	Errs	Drops	Bytes	Pkts	Errs	Drops

Reset Statistics

This screen shows the current statistics for WAN.

Interface: Shows connection interfaces.

Description: Shows the user defined name of WAN service.

Received/Transmitted Bytes: Rx/TX (receive/transmit) packet in Byte.

Received/Transmitted Pkts: Rx/TX (receive/transmit) packets.


Received/Transmitted Errs: Rx/TX (receive/transmit) packets that are errors.

Received/Transmitted Drops: Rx/TX (receive/transmit) packets that are dropped.

Reset statistics: Click to update the statistics.

xTM

The Statistics-xTM screen displays all the xTM statistics.



The screenshot shows a web interface with a 'Status' header and a 'Statistics -- xTM' section. The statistics are presented in a table with 11 columns: Port Number, In Octets, Out Octets, In Packets, Out Packets, In OAM Cells, Out OAM Cells, In ASM Cells, Out ASM Cells, In Packet Errors, and In Cell Errors. A 'Reset' button is located below the table.

Port Number	In Octets	Out Octets	In Packets	Out Packets	In OAM Cells	Out OAM Cells	In ASM Cells	Out ASM Cells	In Packet Errors	In Cell Errors

Port Number: Shows number of the port for xTM.

In Octets: Number of received octets over the interface.

Out Octets: Number of transmitted octets over the interface.

In Packets: Number of received packets over the interface.

Out Packets: Number of transmitted packets over the interface.

In OAM Cells: Number of OAM cells received.

Out OAM Cells: Number of OAM cells transmitted.

In ASM Cells: Number of ASM cells received.

Out ASM Cells: Number of ASM cells transmitted.


In Packet Errors: Number of received packets with errors.

In Cell Errors: Number of received cells with errors.

Reset: Click to reset the statistics.

xDSL

The Statistics-xDSL screen displays all the xDSL network statistics.



The screenshot shows a web interface for xDSL statistics. At the top, there is a 'Status' tab. Below it, a section titled 'Statistics - xDSL' contains a table of various metrics. The 'Status' metric is set to 'Disabled'. The 'Link Power State' section has two columns: 'Downstream' and 'Upstream'. At the bottom of the table, there are two buttons: 'xDSL BER Test' and 'Reset Statistics'.

Statistics - xDSL		
DSP Firmware Version	A2pvC011d.d21j2	
Mode		
Traffic Type		
Status	Disabled	
Link Power State		
	Downstream	Upstream
Line Coding(Trellis)		
SNR Margin (0.1 dB)		
Attenuation (0.1 dB)		
Output Power (0.1 dBm)		
Attainable Rate (Kbps)		
Rate (Kbps)		
Super Frames		
Super Frame Errors		
RS Words		
RS Correctable Errors		
RS Uncorrectable Errors		
HEC Errors		
OCD Errors		
LCD Errors		
Total Cells		
Data Cells		
Bit Errors		
Total ES		
Total SES		
Total UAS		

DSP Firmware Version: DSP code version.

Mode: Modulation protocol, including G.dmt, G.lite, T1.413, ADSL2, ADSL2+ and VDSL2.

Traffic Type: Channel type, including ATM or PTM.

Status: Shows the status of the DSL link.

Link Power State: Shows link output power state.

Upstream: Upstream rate.

Downstream: Downstream rate.

Line Coding(Trellis): Trellis On/Off.

SNR Margin (0.1 dB): This shows the Signal to Noise Ratio (SNR) margin.

Attenuation (0.1 dB): This is estimate of average loop attenuation of signal.

Output Power (0.1 dBm): Total upstream output power.

Attainable Rate (Kbps): The sync rate you would obtain.

Rate (Kbps): Current sync rate.

Super Frames: Total number of super frames.

Super Frame Errors: Number of super frames received with errors.

RS Words: Total number of Reed-Solomon code errors.

RS Correctable Errors: Total number of RS with correctable errors.

RS Uncorrectable Errors: Total number of RS words with uncorrectable errors.

HEC Errors: Total number of Header Error Checksum errors.

OCD Errors: Total number of out-of-cell Delineation errors.

LCD Errors: Total number of Loss of Cell Delineation.

Total Cells: Total number of cells.

Data Cells: Total number of data cells.

Bit Errors: Total number of bit errors.

Total ES: Total Number of Errored Seconds.

Total SES: Total Number of Severely Errored Seconds.


Total UAS: Total Number of Unavailable Seconds.

xDSL BER Test: Click this button to start a bit Error Rate Test.

Reset Statistics: Click this button to reset the statistics.

Route Table

The Route Table provides users with a database in the router that contains current network topology such as current paths for transmitted packets. Both static and dynamic routes are displayed.



The screenshot shows a web interface with a 'Status' tab selected. Below it, the 'Route Table' is expanded, displaying a table with the following data:

Destination	Gateway	Subnet Mask	Metric	Service	Interface
192.168.17.0	0.0.0.0	255.255.255.0	0		br0

Destination: Displays the IP address of the destination network.

Gateway: Displays the IP address of the gateway that this route uses.

Subnet Mask: Displays the destination subnet mask address.

Metric: Displays the number of hops counted as the Metric of the route.

Service: Displays the current service that this route uses.

Interface: Displays the existing interface that this route uses.

ARP Table



The screenshot shows a web interface with a 'Status' tab. Underneath, there is a section for the 'ARP Table'. It contains a table with three columns: 'IP Address', 'MAC Address', and 'Interface'. The data row shows the IP address 192.168.17.63, the MAC address 00:18:F3:8A:B2:CA, and the interface br0.

IP Address	MAC Address	Interface
192.168.17.63	00:18:F3:8A:B2:CA	br0

This table stores mapping information that the device uses to find the Layer 2 Media Access Control (MAC) address that corresponds to the Layer 3 IP address of the device via the Address Resolution Protocol (ARP) feature.

IP Address: Shows the IP Address of the device that the MAC address maps to.

MAC Address: Shows the MAC address that is corresponded to the IP address of the device it is mapped to.

Interface: The interface name (on the router) that this IP address connects to.

DHCP Table

This Table lists the DHCP lease information for all IP addresses assigned by the DHCP server in the device.



The screenshot shows a web interface with a 'Status' tab. Underneath, there is a section for the 'DHCP Table'. It contains a table with four columns: 'Hostname', 'MAC Address', 'IP Address', and 'Expires In'.

Hostname	MAC Address	IP Address	Expires In
----------	-------------	------------	------------

Hostname: The Hostname of internal dhcp client.


MAC Address: The MAC Address of internal dhcp client host.

IP Address: This is the IP address that is assigned to the host with this MAC address.

Expires In: Shows the information provided during registration.

System Log

Display system logs accumulated up to the present time. You can trace its historical information with this function.



The screenshot shows a web interface with a 'Status' tab. Underneath, there is a section for the 'System Log'. It contains a table with three columns: 'Date/Time', 'Facility', and 'Message'. There are two log entries. Below the table is a 'Refresh' button.

Date/Time	Facility	Message
Jan 1 00:00:03	user	hub 1-0:1.0: over-current change on port 2
Jan 1 00:00:03	user	eth1 Link UP 100 mbps half duplex

Refresh: Click to update the system log.

Configuration

When you click this item, the column will expand to display the sub-items that will allow you to further configure your BEC 8920NE router.

[LAN](#), [WAN](#), [System](#), [Firewall](#), [QoS](#), [Virtual Server](#) and [Advanced](#).

The function of each configuration sub-item is described in the following sections.

LAN - Local Area Network

A Local Area Network (LAN) is a shared communication system network where many computers are connected. This type of network is area defined and is usually limited to a confined region within a building or just within the same storey of a building.

The screenshot shows the 'LAN Setting' configuration page. It is organized into three main sections: Ethernet, IP Alias, and DHCP Server/DHCP Relay. The Ethernet section includes a 'Parameters' table with 'GroupName' set to 'Default', 'IP Address' set to '192.168.1.254', and 'Subnet Mask' set to '255.255.255.0'. Below this is an 'IGMP' section with 'IGMP Snooping' checked, and radio buttons for 'Standard Mode' (selected) and 'Blocking Mode'. The IP Alias section has an 'IP Alias' checkbox (unchecked) and empty fields for 'IP Address' and 'Subnet Mask'. The DHCP Server/DHCP Relay section has a 'DHCP Server Mode' dropdown set to 'Disable'. An 'Apply/Save' button is at the bottom.

Ethernet

The router supports more than one Ethernet IP addresses in the LAN, and with distinct LAN subnets through which you can access the Internet at the same time. Users usually only have one subnet in their LAN. The default IP address for the router is 192.168.1.254.

Parameters

GroupName: Select the groupname from the listbox. You can add new groups on Interface Grouping screen (Configuration>Advanced>Interface Grouping, please refer to **Interface Grouping** section).

IP Address: Enter the default IP on this router.

Subnet Mask: Enter the default subnet mask on this router.

IGMP

IGMP Snooping: Allows a layer 2 switch to manage the transmission of any incoming IGMP multicast

packet groups between the host and the router. Default is set to Disable. Check Enable IGMP Snooping check box to activate this function and choose Standard Mode or Blocking Mode.

IP Alias

This function allows the addition of an IP alias to the network interface. This further allows user flexibility to assign a specific function to use this IP.

IP Alias: Check Enable check box to activate this function.


IP Address: Enter the IP address to be added to the network.

Subnet Mask: Specify a subnet mask for the IP to be added.


DHCP Server/DHCP Relay

DHCP allows networked devices to obtain information on the parameter of IP, Netmask, Gateway as well as DNS through the Ethernet Address of the device.

To configure the router's DHCP Server, select **DHCP Server** from the DHCP Server Mode drop-down menu. A message window will pop up to remind you as below. Click OK to continue.



You can then configure parameters of the DHCP Server including the domain name, IP pool (starting IP address and ending IP address to be allocated to PCs on your network) and lease time for each assigned IP address (the period of time the IP address assigned will be valid). These details are sent to the DHCP client (i.e. your PC) when it requests an IP address from the DHCP server. Click Add to save this entry or Remove to delete an existing entry.



If you select **DHCP Relay** from the DHCP Server Mode drop-down menu, you must enter the IP address of the DHCP server that assigns an IP address to the DHCP client in the LAN. Use this function only if advised to do so by your network administrator or ISP.



Click Apply/Save to confirm the changes and enable the above functions.

WAN - Wide Area Network

A WAN (Wide Area Network) is a computer network that covers a broad geographical area (eg. Internet) that is used to connect LAN and other types of network systems. There are the items within the WAN section: [Layer2 Interface](#), [WAN Service](#) and [DSL](#).

Layer2 Interface

PTM Interface (VDSL)

The screenshot shows a configuration page titled "Configuration" with a sub-section "DSL PTM Interface". It contains a table with the following columns: Interface, DSL Latency, PTM Priority, Connection Mode, QoS, and Remove. Below the table are "Add" and "Remove" buttons.

Click Add to go to PTM Configuration screen.

The screenshot shows the "PTM Configuration" screen. It includes a "Parameters" section with the following settings:

- DSL Latency: Path0, Path1
- PTM Priority: Normal Priority, High Priority (Preemption)
- Connection Mode: Default Mode - Single service over one connection, VLAN MUX Mode - Multiple Vlan service over one connection, MSC Mode - Multiple Service over one Connection
- Enable Quality Of Service: Enable Quality Of Service. (Text: Enabling packet level QoS for this PTM interface. Use **Advanced Setup**/Quality of Service to assign priorities for the applications.)

Buttons: Back, Apply/Save

On this screen, you can configure a PTM connection. Check **DSL Latency**, set **PTM Priority**, and choose the appropriate **Connection Mode**. If you want to activate packet level QoS for this PTM interface, check **Enable Quality Of Service** check box (To assign priorities for the applications, please use **Advanced Setup**>Quality of Service.).

Click Apply/Save to save the changes or Back to return to DSL PTM Interface table.

ATM Interface (ADSL)

The screenshot shows a configuration page titled "Configuration" with a sub-section "DSL ATM interface". It contains a table with the following columns: Interface, Vpi, Vci, DSL Latency, Category, Link Type, Connection Mode, QoS, and Remove. Below the table are "Add" and "Remove" buttons.

Click Add to go to ATM PVC Configuration screen.

Configuration

ATM PVC Configuration

Parameters

VPI (0-255)	<input type="text" value="0"/>
VCI (32-65535)	<input type="text" value="35"/>
DSL Latency	<input checked="" type="checkbox"/> Path0 <input type="checkbox"/> Path1
DSL Link Type (EoA is for PPPoE, IPoE, and Bridge.)	<input checked="" type="radio"/> EoA <input type="radio"/> PPPoA <input type="radio"/> IPoA
Encapsulation Mode	LLC/SNAP-BRIDGING ▾
Service Category:	UBR Without PCR ▾
Peak Cell Rate (cells/s)	<input type="text"/>
Sustainable Cell Rate (cells/s)	<input type="text"/>
Maximum Burst Size (cells)	<input type="text"/>
Connection Mode	<input checked="" type="radio"/> Default Mode - Single service over one connection <input type="radio"/> VLAN MUX Mode - Multiple Vlan service over one connection <input type="radio"/> MSC Mode - Multiple Service over one Connection
Enable Quality Of Service Enabling packet level QoS for a PVC improves performance for selected classes of applications. QoS cannot be set for CBR and Realtime VBR. QoS consumes system resources; therefore the number of PVCs will be reduced. Use Advanced Setup/Quality of Service to assign priorities for the applications.	<input type="checkbox"/> Enable Quality Of Service.

VPI (0~255) / VCI (32~65535): Enter the VPI/VCI values provided by your ISP.

DSL Latency: Check Path0 or Path1 for DSL latency.

DSL Link Type: Select EoA (which is for PPPoE, IPoE and Bridge), PPPoA, or IPoA. Select the one provided by your ISP.

Encapsulation Mode: Select the encapsulation mode. Different options will be provided for different DSL link types. Select the one provided by your ISP.

Service Category: Describes the ATM Quality Of Service (QoS) being used on the VC.

Peak Cell Rate (cells/s): Specifies the upstream peak cell rate in cells per second.

Sustainable Cell Rate (cells/s): Specifies the upstream sustainable cell rate, in cells per second, used for traffic shaping.

Maximum Burst Size (cells/s): Specifies the upstream maximum burst size in cells.

Connection Mode: Choose a appropriate connection mode.

Enable Quality Of Service: Check to activate packet level QoS for this PTM interface. To assign priorities for the applications, please use Advanced Setup>Quality of Service.

Click Apply/Save to save the changes or Back to return to DSL ATM Interface table.

ETH Interface (EWAN)

The screenshot shows a configuration page with a table titled "ETH WAN Interface". The table has three columns: "Interface/(Name)", "Connection Mode", and "Remove". Below the table are "Add" and "Remove" buttons.

Click Add to go to ETH WAN Configuration screen.

The screenshot shows the "ETH WAN Configuration" screen. It has a "Parameters" section with the following fields:

- ETH port: eth0/eth0 (dropdown menu)
- Connection Mode: Default Mode - Single service over one connection, VLAN MUX Mode - Multiple Vlan service over one connection, MSC Mode - Multiple Service over one Connection

At the bottom, there are "Back" and "Apply/Save" buttons.

ETH port: Select the port for ETH WAN connection from the listbox.

Connection Mode: Choose a appropriate connection mode.

Click Apply/Save to save the changes or Back to return to ETH WAN Interface table.

WAN Service

The screenshot shows the "WAN Service" page with a table titled "WAN Service Interface Table". The table has columns: "Interface", "Description", "Type", "Vlan8021p", "VlanMuxId", "ConnId", "Icmp", "NAT", "Firewall", and "Remove". Below the table is a message: "*ETH and PTM/ATM service can not coexist." and "Add" and "Remove" buttons.

Note: You have to set an interface at least previously. (Please refer to PTM Interface, ATM Interface and ETH Interface sections. ETH and PTM/ATM service can not coexist.) If the WAN interface has not set, a page will display as below and you are not allowed to create a WAN connection.

The screenshot shows an error message: "Error! WAN Configuration: No available interfaces." Below the message is a "Back" button.

Click Add to go to WAN Service Interface screen.

WAN Setting

▼ **WAN Service Interface**

Select a layer 2 interface for this service

atm0(0_0_35)

Note For ATM interface, the descriptor string is (portid_vpi_vci)
 For PTM interface, the descriptor string is (portid_high_low)
 Where portid=0 --> DSL Latency PATH0
 portid=1 --> DSL Latency PATH1
 portid=4 --> DSL Latency PATH0&1
 low =0 --> Low PTM Priority not set
 low =1 --> Low PTM Priority set
 high =0 --> High PTM Priority not set
 high =1 --> High PTM Priority set

Back Next

Select a layer2 interface form the drop-down menu for this service and then click on Next to continue.

PPP over Ethernet

PPPoE (PPP over Ethernet) provides access control in a manner similar to dial-up services using PPP.

WAN Setting

▼ **WAN Service Configuration**

Select WAN service type:

PPP over Ethernet (PPPoE)
 IP over Ethernet
 Bridging

Enter Service Description: pppoe_0_0_35

Back Next

Select WAN service type: Click PPP over Ethernet (PPPoE) radio button.

Enter Service Description: You are allowed to enter the user defined name for this service.

Click Next to go to next step.

WAN Service	
▼ PPPoE Parameters	
PPP Username	<input type="text"/>
PPP Password	<input type="text"/>
PPPoE Service Name	<input type="text"/>
Authentication Method	AUTO ▼
Fullcone NAT	<input type="checkbox"/> Enable
Dial on demand (with idle timeout timer)	<input type="checkbox"/> Enable
Inactivity Timeout (minutes) [1-4320]	<input type="text" value="0"/>
PPP IP extension	<input type="checkbox"/> Enable
Static IPv4 Address	<input type="checkbox"/> Enable
IPv4 Address	<input type="text" value="0.0.0.0"/>
PPP Debug Mode	<input type="checkbox"/> Enable
Bridge PPPoE Frames Between WAN and Local Ports	<input type="checkbox"/> Enable
IGMP Multicast Proxy	<input type="checkbox"/> Enable
<input type="button" value="Back"/> <input type="button" value="Next"/>	

PPP Username: Enter the username provided by your ISP. You can input up to 256 alphanumeric characters (case sensitive).

PPP Password: Enter the password provided by your ISP. You can input up to 32 alphanumeric characters (case sensitive).

PPPoE Service Name: This item is for identification purposes. If it is required, your ISP will provide you the necessary information. Maximum input is 32 alphanumeric characters.

Authentication Method: Default is AUTO. Please consult your ISP on whether to use PAP, CHAP or MSCHAP.

Fullcone NAT: Check/uncheck this item to activate/inactivate this function.

Dial on demand (with idle timeout timer) / Inactivity Timeout (minutes) [1-4320]: Check Enable to activate this function and the following field will be available, so that you can enter the time value to auto-disconnect the broadband firewall gateway when there is no activity on the line for a predetermined period of time.

PPP IP extension: Check/uncheck this item to enable/disable this function.

Static IPv4 Address / IPv4 Address: Check Enable to activate this function and the following field will be available, so that you can enter the IPv4 address (default is 0.0.0.0) to the device.

PPP Debug Mode: Check/uncheck this item to enable/disable this function.

Bridge PPPoE Frames Between WAN and Local Ports: Check/uncheck this item to enable/disable this function.

IGMP Multicast Proxy: Check/uncheck this item to enable/disable this function.

Click Next to go to next step.

WAN Service

▼ **IPParameters**

IPv4 Default Gateway

Selected WAN Interface:

Selected WAN Interface: Select the WAN interface for the IPv4 Default Gateway.

Click Next to go to next step.

WAN Service

▼ **Parameters**

IPv4 DNS Server Configuration

DNS Type:

WAN Interface selected:

Primary DNS server:

Secondary DNS server:

DNS Type: Select the appropriate DNS type.

WAN Interface selected: This field is available when DNS Type is "Obtain DNS info from a WAN interface". Select a WAN interface for this device to obtain the DNS information.

Primary DNS server/Secondary DNS server: These fields are available when DNS Type is "Use the following Static DNS IP address". Enter the primary/secondary DNS.

Click Next to go to next step.

WAN Service

▼ **Summary**

PORT / VPI / VCI	0 / 0 / 35
Connection Type	PPPoE
Service Name	pppoe_0_0_35
Service Category	UBR
IP Address	Automatically Assigned
Service State	Enabled
NAT	Enabled
Full Cone NAT	Disabled
Firewall	Enabled
IGMP Multicast	Disabled
Quality Of Service	Disabled

This page lists a summary of previous steps. Make sure that the settings are the same as those provided by your ISP and then click Apply/Save to complete the configuration process. Then you will return to WAN Service Interface Table and this new profile will be displayed on this screen.

WAN Service

▼ WAN Service Interface Table

Interface	Description	Type	Vlan8021p	VlanMuxId	ConnId	Igmp	NAT	Firewall	Remove
ppp0	pppoe_0_0_1	PPPoE	N/A	N/A	N/A	Disabled	Enabled	Enabled	<input type="checkbox"/>

*ETH and PTM/ATM service can not coexist.

IP over Ethernet

WAN Setting

▼ WAN Service Configuration

Select WAN service type:

PPP over Ethernet (PPPoE)
 IP over Ethernet
 Bridging

Enter Service Description:

Select WAN service type: Click IP over Ethernet radio button.

Enter Service Description: You are allowed to enter the user defined name for this service.

Click Next to go to next step.

WAN Service

▼ IPoE Parameters

IPv4

IPv4 Protocol:

Option 60 Vendor ID:

Option 61 IAID: (8 hexadecimal digits)

Option 61 DUID: (hexadecimal digit)

Option 125: Disable Enable

WAN IP Address:

WAN Subnet Mask:

WAN gateway IP Address:

IPv4 Protocol: Select the appropriate protocol. There are 2 options: Obtain an IP Address Automatically and Fixed IP Address.

Option 60 Vendor ID: Enter the associated information provided by your ISP.

Option 61 IAID: Enter the associated information provided by your ISP. You should input 8 hexadecimal numbers.

Option 61 DUID: Enter the associated information provided by your ISP. You should input hexadecimal number(s).

Option 125: Check Enable or Disable this function. Default setting is Disable.


WAN IP Address: Enter your IP address to the device provided by your ISP. If Fixed IP Address is

selected in the IPv4 Protocol field, default value 0.0.0.0 will display in this field.

WAN Subnet Mask: Enter your submask to the device provided by your ISP. If Fixed IP Address is selected in the IPv4 Protocol field, default value 0.0.0.0 will display in this field.

WAN gateway IP Address: Enter your gateway IP address to the device provided by your ISP. If Fixed IP Address is selected in the IPv4 Protocol field, default value 0.0.0.0 will display in this field.

Click Next to go to next step.



The screenshot shows the 'WAN Service' configuration page. Under the 'Parameters' section, there is a sub-section titled 'Network Address Translation Settings'. It contains three rows: 'NAT' with an 'Enable' checkbox, 'Firewall' with an 'Enable' checkbox, and 'IGMP Multicast' with an 'Enable' checkbox. At the bottom of this section are 'Back' and 'Next' buttons.

NAT: The NAT (Network Address Translation) feature allows multiple users to access the Internet through a single IP account by sharing the single IP address. If users on your LAN have their own public IP addresses to access the Internet, NAT function can be disabled.

Fullcone NAT: This field will be displayed when you tick Enable on the NAT field. Check/uncheck this item to activate/inactivate this function.

Firewall: Check/uncheck this item to enable/disable firewall function.

IGMP Multicast: IGMP (Internet Group Membership Protocol) is a protocol used by IP hosts to report their multicast group memberships to any immediately neighboring multicast routers. Check this item to enable IGMP multicast (proxy) on that wan interface for multicast forwarding.


Click Next to go to next step.



The screenshot shows the 'WAN Service' configuration page. Under the 'Parameters' section, there is a sub-section titled 'IPv4 Default Gateway'. It contains a 'Selected WAN Interface' dropdown menu with 'ipoe_0_0_35/atm0' selected. At the bottom of this section are 'Back' and 'Next' buttons.

Selected WAN Interface: Select the WAN interface for the IPv4 Default Gateway.

Click Next to go to next step.



The screenshot shows the 'WAN Service' configuration page. Under the 'Parameters' section, there is a sub-section titled 'IPv4 DNS Server Configuration'. It contains four rows: 'DNS Type' with a dropdown menu set to 'Obtain DNS info from a WAN interface', 'WAN interface selected' with a dropdown menu set to 'ipoe_0_0_35/atm0', 'Primary DNS server' with an empty text input field, and 'Secondary DNS server' with an empty text input field. At the bottom of this section are 'Back' and 'Next' buttons.

DNS Type: Select the appropriate DNS type.

WAN Interface selected: This field is available when DNS Type is "Obtain DNS info from a WAN interface". Select a WAN interface for this device to obtain the DNS information.

Primary DNS server/Secondary DNS server: These fields are available when DNS Type is "Use the following Static DNS IP address". Enter the primary/secondary DNS.

Click Next to go to next step.

The screenshot shows a web interface titled "WAN Service". Under the "Summary" section, the following settings are listed:

PORT / VPI / VCI	0 / 0 / 35
Connection Type	IPoE
Service Name	ipoe_0_0_35
Service Category	UBR
IP Address	Automatically Assigned
Service State	Enabled
NAT	Disabled
Full Cone NAT	Disabled
Firewall	Disabled
IGMP Multicast	Disabled
Quality Of Service	Disabled

At the bottom of the summary section, there are two buttons: "Back" and "Apply/Save".

This page lists a summary of previous steps. Make sure that the settings are the same as those provided by your ISP and then click Apply/Save to complete the configuration process.

Bridging

The screenshot shows a web interface titled "WAN Setting". Under the "WAN Service Configuration" section, the following settings are visible:

Select WAN service type:

- PPP over Ethernet (PPPoE)
- IP over Ethernet
- Bridging

Enter Service Description:

At the bottom, there are two buttons: "Back" and "Next".

Select WAN service type: Click Bridging radio button.

Enter Service Description: You are allowed to enter the user defined name for this service.

Click Next to go to next step.

WAN Service

Summary

PORT / VPI / VCI	0 / 0 / 35
Connection Type	Bridge
Service Name	br_0_0_35
Service Category	UBR
IP Address	Not Applicable
Service State	Enabled
NAT	Disabled
Full Cone NAT	Disabled
Firewall	Disabled
IGMP Multicast	Not Applicable
Quality Of Service	Disabled

This page lists a summary of previous steps. Make sure that the settings are the same as those provided by your ISP and then click Apply/Save to complete the configuration process.

DSL

This screen allows you to set DSL parameters. DSL knowledge is required to configure these settings. Contact your ISP to make sure that these parameters are correct.

DSL Settings				
Parameters				
Modulator	<input checked="" type="checkbox"/> G.Dmt Enabled	<input checked="" type="checkbox"/> G.lite Enabled	<input checked="" type="checkbox"/> T1.413 Enabled	<input checked="" type="checkbox"/> ADSL2 Enabled
	<input checked="" type="checkbox"/> AnnexL Enabled	<input checked="" type="checkbox"/> ADSL2+ Enabled	<input type="checkbox"/> AnnexM Enabled	<input checked="" type="checkbox"/> VDSL2 Enabled
VDSL2 profile	<input checked="" type="checkbox"/> 8a Enabled	<input checked="" type="checkbox"/> 8b Enabled	<input checked="" type="checkbox"/> 8c Enabled	<input checked="" type="checkbox"/> 8d Enabled
	<input checked="" type="checkbox"/> 12a Enabled	<input checked="" type="checkbox"/> 12b Enabled	<input checked="" type="checkbox"/> 17a Enabled	
US0	<input checked="" type="checkbox"/> Enabled			
Phone line pair	<input checked="" type="radio"/> Inner pair <input type="radio"/> Outer pair			
Capability	<input checked="" type="checkbox"/> Bitswap Enable <input type="checkbox"/> SRA Enable			

Apply/Save

Modulation: There are 8 modes “G.Dmt”, “G.lite”, “T1.413”, “ADSL2”, “AnnexL”, “ADSL2+”, “AnnexM”, and “VDSL2” that user can select for this connection.

G.Dmt/G.lite Enabled: Tick the G.Dmt/G.lite check box if you want the system to use either G.Dmt or G.lite mode.

T1.413 Enabled: Tick the T1.413 check box if you want the system to use only T1.413 mode.

ADSL2 Enabled: The device can support the functions of the ADSL2.

AnnexL Enabled: The device can support/enhance the long loop test.

ADSL2+ Enabled: The device can support the functions of the ADSL2+.

AnnexM Enabled: Covers a higher “upstream” data rate version, by making use of some of the downstream channels.

VDSL2 Enabled: The device can support the functions of the VDSL2.

VDSL2 profile: There are 7 profiles “8a”, “8b”, “8c”, “8d”, “8a”, “12a”, “12b” and “17a” that user can select for this connection.

US0: Check/uncheck this item to enable/disable this function.

Phone line pair: This is for reserved only. You can choose "Inner Pair" or "Outer Pair".

Capability: There are 2 options “Bitswap Enable” and “SRA Enable” that user can select for this connection.

Bitswap Enable: Allows bitswaping function.

SRA Enable: Allows seamless rate adaptation.

Click Apply/Save to confirm the changes.

System

There are 5 items within the System section: [Time Zone](#), [Firmware Upgrade](#), [Backup/Restore](#), [Restart](#) and [User Management](#).

Time Zone

Enable or disable the time zone function. If you disable time zone, the other blanks are unavailable.

The router does not have a real time clock on board; instead, it uses the Simple Network Time Protocol (SNTP) to get the most current time from an SNTP server outside your network. Choose your local time zone from the drop down menu. To apply the selected local time zone, click Enable and click the Apply button. After a successful connection to the Internet, the router will retrieve the correct local time from the SNTP server you have specified. If you prefer to specify an SNTP server other than those in the drop-down list, simply enter its IP address in their appropriate blanks provided as shown above. Your ISP may also provide an SNTP server for you to use.

Click Apply to confirm the settings.

The screenshot shows a web-based configuration interface for a router. The main heading is 'Configuration'. Underneath, there is a section for 'Time Zone'. It includes a 'Parameters' section with two radio buttons: 'Enable' (which is selected) and 'Disable'. Below the radio buttons is a dropdown menu for 'Local Time Zone (+/-GMT Time)' currently showing '(GMT-08:00) Pacific Time, Tijuana'. There are two rows for 'SNTP Server IP Address', each consisting of a dropdown menu and a text input field. The first dropdown shows 'time.nist.gov' and the second shows 'ntp1.tummy.com'. Below these fields is a world map with the landmasses highlighted in green. At the bottom of the configuration area are two buttons: 'Apply' and 'Cancel'.

The router does not have a real time clock on board; instead, it uses the Simple Network Time Protocol (SNTP) to get the most current time from an SNTP server outside your network. Choose your local time zone from the drop down menu. To apply the selected local time zone, click Enable and click the Apply button. After a successful connection to the Internet, the router will retrieve the correct local time from the SNTP server you have specified. If you prefer to specify an SNTP server other than those in the drop-down list, simply enter its IP address in their appropriate blanks provided as shown above. Your ISP may also provide an SNTP server for you to use.

Click Apply to confirm the settings.


Firmware Upgrade

Your router's firmware is the software that enables it to operate and provides all its functionality. Think of your router as a dedicated computer, and the firmware as the software that runs in your router. Thus, by upgrading the newly improved version of the firmware allows you the advantage to use newly integrated features.



The screenshot shows a web interface for firmware upgrade. At the top, there is a 'Configuration' tab. Below it, the 'Firmware Upgrade' section is expanded. It contains the text: 'You may upgrade the system software on your network device.' Below this text is a 'New Firmware Image' label followed by an empty text input field and a 'Browse...' button. At the bottom of this section are two buttons: 'Upgrade' and 'Cancel'.

Click on Browse to select the new firmware image file you have downloaded to your PC. Once the correct file is selected, click Upgrade to update the firmware to your router.



The screenshot shows the 'Firmware Upgrade' progress page. The title is 'Firmware Upgrade'. Below it, the 'firmware upgrade progress' section is expanded. It contains the text: 'do not switch off device during flash update'. Below this text is a progress bar labeled 'total :'. The progress bar is partially filled with blue, and the percentage '58%' is displayed to the right of the bar.



Warning

DO NOT power down the router or interrupt the firmware upgrading while it is still in process. Improper operation could damage the router.

Backup / Restore

These functions allow you to save a backup of the current configuration of your router to a defined location on your PC, or to restore a previously saved configuration. This is useful if you wish to experiment with different settings, knowing that you have a backup in hand in case any mistakes occur. It is advisable that you backup your router configuration before making any changes to your router configuration.

Configuration

Backup / Restore

Allows you to backup the configuration settings to your computer, or restore configuration from your computer.

Backup Configuration
Backup configuration to your computer.

Restore Configuration

Configuration File

Restore will overwrite the current configuration and restart the device. If you want to keep the current configuration, please use "Backup" first to save current configuration.

Backup Configuration

Press Backup Settings to select where on your local PC you want to store your setting file. You may also want to change the name of the file when saving if you wish to keep multiple backups.

Restore Configuration

Press Browse to select a file from your PC to restore. You should only restore your router setting that has been generated by the Backup function which is created with the current version of the router firmware. Settings files saved to your PC should not be manually edited in any way.

Select the settings files you wish to use, and press Restore to load the setting into the router. Click Restore to begin restoring the configuration and wait for the router to restart before performing any actions.

Restore Configuration

restore config progress

do not switch off device during flash update

total : 8%

Restart

There are 2 options for you to choose from before restarting your device. You can either choose to restart your device to restore it to the Factory Default Settings or to restart the device with your current settings applied. Restarting your device to Factory Default Setting will be useful especially after you have accidentally changed your settings that may result in undesirable outcome.

Configuration

Restart

After restarting. Please wait for several seconds to let the system come up.

Restart device with Factory Default Settings Current Settings

If you wish to restart the router using the factory default settings (for example, after a firmware upgrade or if you have saved an incorrect configuration), select Factory Default Settings to reset to factory default settings.

Click Restart with option Current Settings to reboot your router (and restore your last saved configuration).

After selecting the type of setting you want the device to restart with, click the Restart button to initiate the process. After restarting, please wait several minutes to let the selected setting applied to the system.




You may also reset your router to factory settings by holding the small Reset pinhole button more than 1 second on the back of your router.

52

User Management

In order to prevent unauthorized access to your router configuration interface, it requires all users to login with a username and password. Therefore only system administrator can access the system. It is highly recommended that you change your password upon receiving your router. The default password is “admin”.



Select the username you want to configure from the drop-down menu and then set the associated password.

To change your password, simply enter the old password in the Old Password blank. Then enter your new password in the New Password and Confirm Password blanks provided. When this is done, press Apply to save changes.

Firewall

Listed are the items under the Firewall section: [IP Filtering](#), [MAC Filtering](#) and [Parental Control](#).

IP Filtering

Packet filtering enables you to configure your router to block specific internal / external users (IP address) from Internet access, or disable specific service requests (Port number) to / from the Internet. This configuration program allows you to set up different filter rules for different users based on their IP addresses or their network port number. The relationship among all filters is “or” operation, which means that the router checks these different filter rules one by one, starting from the first rule. As long as one of the rules is satisfied, the specified action will be taken.


Outgoing

All outgoing IP traffic from LAN is allowed by default, but some IP traffic could be blocked by setting up filters.



The screenshot shows the 'Configuration' page with a sub-section titled 'Outgoing IP Filtering'. It features a table with columns: Filter Name, Protocol, Source Address / Mask, Source Port, Dest. Address / Mask, Dest. Port, and Remove. Below the table are 'Add' and 'Remove' buttons.

Click Add to enter Add IP Filter -- Outing screen to create a filter to identify the outgoing IP traffic.



The screenshot shows the 'Add IP Filter -- Outgoing' configuration screen. It includes a 'Parameters' section with the following fields: Filter Name (text input), Protocol (dropdown menu), Source IP address (text input), Source Subnet Mask (text input), Source Port (port or port.port) (text input), Destination IP address (text input), Destination Subnet Mask (text input), and Destination Port (port or port.port) (text input). An 'Apply/Save' button is located at the bottom.

Filter Name: User defined description for entry identification. The maximum name length is 32 characters.

Protocol: Specify the packet type (TCP/UDP, TCP, UDP and ICMP) that the rule applies to from

the listbox. Select TCP if you wish to search for the connection-based application service on the remote server using the port number. Or select UDP if you want to search for the connectionless application service on the remote server using the port number.

Source IP address: This is an Address-Filter used to allow or block traffic from particular IP address(es). Enter the IP range that you want to filter. If only the first IP block is filled, it means only that IP entered will be targeted. If you leave both IP blocks empty, it means any IP address.


Source Subnet Mask: Type the subnet mask associated with the source IP address.

Source Port (port to port:port): This is the Port Range that defines the ports allowed by the Remote/WAN to connect to the application. It is recommended that only advance user is to configure this feature.

Destination IP address: This is an Address-Filter used to allow or block traffic to particular IP address(es). Enter the IP range that you want to filter. If only the first IP block is filled, it means only that IP entered will be targeted. If you leave both IP blocks empty, it means any IP address.

Destination Subnet Mask: Type the subnet mask associated with the Destination IP address.

Destination Port (port to port:port): This is the Port Range that defines the port of the application.



The screenshot shows a web interface for configuring outgoing IP filtering. It features a table with columns for Filter Name, Protocol, Source Address / Mask, Source Port, Dest. Address / Mask, Dest. Port, and Remove. A single rule named 'Filt' is listed with Protocol 'TCP', Source Address / Mask '192.168.1.100', and Source Port '500'. There are 'Add' and 'Remove' buttons below the table.

Filter Name	Protocol	Source Address / Mask	Source Port	Dest. Address / Mask	Dest. Port	Remove
Filt	TCP	192.168.1.100	500			<input type="checkbox"/>

Click Apply/Save to set the new settings and you will be returned to the Outgoing IP Filtering page.

Remove: To delete the IP filtering rule from the table, check Remove checkbox then click Remove button to delete the selected item.

Incoming

All incoming IP traffic from the WAN is blocked by default when the firewall is enabled. However, some IP traffic can be accepted by setting up filters.



The screenshot shows a web interface for configuring incoming IP filtering. It features a table with columns for Filter Name, Interfaces, Protocol, Source Address / Mask, Source Port, Dest. Address / Mask, Dest. Port, and Remove. There are 'Add' and 'Remove' buttons below the table.

Filter Name	Interfaces	Protocol	Source Address / Mask	Source Port	Dest. Address / Mask	Dest. Port	Remove
-------------	------------	----------	-----------------------	-------------	----------------------	------------	--------

Click Add to enter Add IP Filter -- Incoming screen to add a filter rule for incoming IP traffic.

The screenshot shows a web-based configuration interface for adding an incoming IP filter. The form is titled 'Add IP Filter -- Incoming' and is located under a 'Configuration' header. It contains several input fields and checkboxes. The 'Filter Name' field is empty. The 'Protocol' field is a dropdown menu. The 'Source IP address', 'Source Subnet Mask', 'Source Port (port or port:port)', 'Destination IP address', 'Destination Subnet Mask', and 'Destination Port (port or port:port)' fields are all empty. The 'Interfaces' section has two checkboxes: 'Select All' and 'br0/br0', both of which are checked. At the bottom of the form is an 'Apply/Save' button.

Filter Name: User defined description for entry identification. The maximum name length is 32 characters

Protocol: Specify the packet type (TCP/UDP, TCP, UDP and ICMP) that the rule applies to from the listbox. Select TCP if you wish to search for the connection-based application service on the remote server using the port number. Or select UDP if you want to search for the connectionless application service on the remote server using the port number.

Source IP address: This is an Address-Filter used to allow or block traffic from particular IP address(es). Enter the IP range that you want to filter. If only the first IP block is filled, it means only that IP entered will be targeted. If you leave both IP blocks empty, it means any IP address.

Source Subnet Mask: Type the subnet mask associated with the source IP address.

Source Port (port to port:port): This is the Port Range that defines the ports allowed by the Remote/WAN to connect to the application. It is recommended that only advance user is to configure this feature.

Destination IP address: This is an Address-Filter used to allow or block traffic to particular IP address(es). Enter the IP range that you want to filter. If only the first IP block is filled, it means only that IP entered will be targeted. If you leave both IP blocks empty, it means any IP address.

Destination Subnet Mask: Type the subnet mask associated with the Destination IP address.

Destination Port (port to port:port): This is the Port Range that defines the port of the application.

Interfaces: Check the check box to select the interface for this rule.

Click Apply/Save to set the new settings and you will be returned to the Incoming IP Filtering page.

Remove: To delete the IP filtering rule from the table, check Remove checkbox then click Remove button to delete the selected item.

MAC Filtering

A MAC (Media Access Control) address is the unique network hardware identifier for each PC on your network's interface (i.e. its Network Interface Card or Ethernet card). Using your router's MAC Address Filter function, you can configure the network to block specific machines from accessing your LAN.

Configuration

MAC Filtering Setup

MAC Filtering is only effective on ATM PVCs configured in Bridge mode. **FORWARDED** means that all MAC layer frames will be **FORWARDED** except those matching with any of the specified rules in the following table. **BLOCKED** means that all MAC layer frames will be **BLOCKED** except those matching with any of the specified rules in the following table.

MAC Filtering Policy For Each Interface **WARNING: Changing from one policy to another of an interface will cause all defined rules for that interface to be REMOVED AUTOMATICALLY! You will need to create new rules for the new policy.**

Interface	Policy	Change
		<input type="button" value="Change Policy"/>

Configure MAC filtering rules

Interface	Protocol	Destination MAC	Source MAC	Frame Direction	Remove
					<input type="button" value="Add"/> <input type="button" value="Remove"/>

MAC Filtering Policy For Each Interface

MAC Filtering is only effective on ATM PVCs configured in Bridge mode. FORWARD means that all MAC layer frames will be FORWARDED except those matching with any of the specified rules in the following table. BLOCKED means that all MAC layer frames will be BLOCKED except those matching with any of the specified rules in the following table.

Note: Changing from one policy to another of an interface will cause all defined rules for that interface to be REMOVED AUTOMATICALLY! You will need to create new rules for the new policy.

Configure MAC Filtering Rules

Configuration

MAC Filter

Parameters

Protocol Type:

Destination MAC Address:

Source MAC Address:

Frame Direction:

WAN Interfaces (Configured in Bridge mode only):

To create a filter to identify the MAC layer frames, click on Add button.

You should specify at least one condition below to set a MAC filter profile. If multiple conditions are specified, all of them take effect.

Protocol Type: Select which protocol this filter will be applied to from the drop-down menu.

Destination MAC Address: Enter the destination MAC address this filter will be applied to. The format of MAC address could be: xx:xx:xx:xx:xx:xx or xx-xx-xx-xx-xx-xx.

Source MAC Address: Enter the origin MAC address this filter will be applied to. The format of MAC address could be: xx:xx:xx:xx:xx:xx or xx-xx-xx-xx-xx-xx.

Frame Direction: Select the frame flow direction from the listbox: LAN to WAN, WAN to LAN, or both

directions.

WAN Interfaces (Configured in Bridge mode only): Select the WAN interface.

Click Apply/Save to set the new settings and you will be returned to the Incoming IP Filtering page.

Remove: To delete the IP filtering rule from the table, check Remove checkbox then click Remove button to delete the selected item.

QoS - Quality of Service

QoS helps you to control the data upload traffic of each application from LAN (Ethernet) to WAN (Internet). It facilitates you the features to control the quality and speed of throughput for each application when the system is running with full upstream load.

The screenshot shows the 'Configuration' page with a sub-section for 'Queue Management Configuration'. Under 'Parameters', there is a 'QoS Enable' checkbox which is checked, and a 'Select Default DSCP Mark' dropdown menu set to 'No Change(-1)'. An 'Apply/Save' button is located at the bottom of the configuration area.

QoS Enable: Check to activate QoS function and the following field will be available.

Note: You can enable QoS function in WAN Configuration pages by checking “Enable Quality of Service.” check box (refer to Layer2 Interface section).

Select Default DSCP Mark: Select the default DSCP mark from the listbox. Differentiated Services Code Point (DSCP) is the first 6 bits in the ToS byte. DSCP Mark allows users to classify the traffic of the application to be executed according to the DSCP value.

Click Apply/Save to confirm the settings.

Queue Config

Queue Config allows you to configure a QoS queue entry and assign it to a specific network interface. Each queue entry set here will be used by the classifier to place ingress packets appropriately.

The screenshot shows the 'Configuration' page with a sub-section for 'Queue Config'. It features a table with columns: Name, Key, Interface, Precedence, DSL Latency, PTM Priority, Enable, and Remove. Below the table are three buttons: 'Add', 'Enable', and 'Remove'.

Click Add to create the queue.

The screenshot shows the 'Configuration' page with a sub-section for 'Queue Configuration'. Under 'Parameters', the following settings are visible: Name (ftp), Enable (Disable), Interface (ptm0(0_0_1)), Precedence (1), DSL Latency (Path0), and PTM Priority (Low). An 'Apply/Save' button is at the bottom.

Name: Enter a name for this QoS item.

Enable: Select enable or disable this QoS application.


Interface: Select the interface you want to assign to this QoS item.

Precedence: Select the precedence of this QoS item. The rule is performed by selecting the order of the rules. The highest priority is 1.

DSL Latency: Select the DSL latency.

PTM Priority: Select the priority given to fit PTM policy/application.

Click Apply/Save to confirm the settings and you will be returned to the Queue Config table.



The screenshot shows a configuration window titled "Configuration" with a sub-section "Queue Config". It contains a table with the following data:

Name	Key	Interface	Precedence	DSL Latency	PTM Priority	Enable	Remove
ftp	1	ptm0	1	Path0	Low	<input checked="" type="checkbox"/>	<input type="checkbox"/>
web	2	ptm0	4	Path0	Low	<input checked="" type="checkbox"/>	<input type="checkbox"/>


Below the table are three buttons: "Add", "Enable", and "Remove".

Enable: To disable the item, please uncheck Enable check box then click Enable button.

Remove: To delete the QoS rule from the table, check Remove checkbox then click Remove button to delete the selected item.

QoS Classification

This screen displays a packet QoS summary table and allows user to add or remove a QoS classification class. This is the main place to configure the classification, marking and queuing rules.



The screenshot shows a configuration window titled "Configuration" with a sub-section "QoS Classification". It contains a table with the following data:

CLASSIFICATION CRITERIA													CLASSIFICATION RESULTS						
Class Name	Order	Class Intf	Ether Type	SrcMAC/ Mask	DstMAC/ Mask	SrcIP/ Mask	DstIP/ Mask	Proto	Src Port	Dst Port	DSCP Check	802.1P Check	Queue Key	DSCP Mark	802.1P Mark	VlanID Tag	Rate Control (kbps)	Enable	Remove

Below the table are three buttons: "Add", "Enable", and "Remove".

Click Add to configure network traffic classes.

Configuration

Network Traffic Class Rule

Parameters

Traffic Class Name:

Rule Order: Last

Rule Status: Disable

Specify Classification Criteria

Class Interface:

Ether Type:

Source MAC Address:

Source MAC Mask:

Destination MAC Address:

Destination MAC Mask:

Source IP Address:

Source Subnet Mask:

Destination IP Address:

Destination Subnet Mask:

Differentiated Service Code Point (DSCP) Check:

Protocol:

UDP/TCP Source Port (port or port:port):

UDP/TCP Destination Port (port or port:port):

802.1p Priority Check:

Specify Classification Results

Assign Classification Queue:

Mark Differentiated Service Code Point (DSCP):

Mark 802.1p priority:

Tag VLAN ID (0-4094):

Set Rate Control(kbps):

Parameters

Traffic Class Name: Assign a name for this class to uniquely identify the other(s) among multiple classes.

Rule Order: Select the priority for this class rule.

Rule Status: Select Enable to activate this class rule.

Specify Classification Criteria

Enter or select appropriate parameters on the following fields. A blank criterion indicates it is not used for classification.

Specify Classification Results

Enter or select appropriate parameters in the following fields. You have to choose a classification queue. A blank mark or tag value means no change.

Click Apply/Save to confirm the settings and you will be returned to the QoS Classification page.

Enable: To disable the item, please uncheck Enable check box then click Enable button.

Remove: To delete the QoS class from the table, check Remove checkbox then click Remove button to delete the selected item.

Virtual Server

Virtual Server allows you to direct incoming traffic from WAN side (identified by Protocol and External port) to the Internal server with private IP address on the LAN side. The Internal port is required only if the external port needs to be converted to a different port number used by the server on the LAN side.

In TCP and UDP networks a port is a 16-bit number used to identify which application program (usually a server) incoming connections should be delivered to. Some ports have numbers that are pre-assigned to them by the IANA (the Internet Assigned Numbers Authority), and these are referred to as “well-known ports”. Servers follow the well-known port assignments so clients can locate them.

If you wish to run a server on your network that can be accessed from the WAN (i.e. from other machines on the Internet that are outside your local network), or any application that can accept incoming connections (e.g. Peer-to-peer/P2P software such as instant messaging applications and P2P file-sharing applications) and are using NAT (Network Address Translation), then you need to configure your router to forward these incoming connection attempts using specific ports to the PC on your network running the application. You also need to use port forwarding if you wish to host an online game server.

Examples of well-known and registered port numbers are shown below, for further information, please see IANA’s website at: <http://www.iana.org/assignments/port-numbers>

Well-known and Registered Ports

Port Number	Protocol	Description
20	TCP	FTP Data
21	TCP	FTP Control
22	TCP & UDP	SSH Remote Login Protocol
23	TCP	TEInet
25	TCP	SMTP (simple Mail Transfer Protocol)
53	TCP & UDP	DNS (Domain Name Server)
69	UDP	TFTP (Trivial File Transfer Protocol)
80	TCP	World Wide Web HTTP
110	TCP	POP3 (Post Office Protocol version 3)
119	TCP	NEWS (Network News Transfer Protocol)
123	UDP	NTP (Network Time Protocol)
161	TCP	SNMP
443	TCP & UDP	HTTPS
1503	TCP	T.120
1720	TCP	H.323
4000	TCP	ICQ
7070	UDP	Real Audio

Port Mapping

Server Name	External Port Start	External Port End	Protocol	Internal Port Start	Internal Port End	Server IP Address	WAN Interface	Remove
-------------	---------------------	-------------------	----------	---------------------	-------------------	-------------------	---------------	--------

Click Add to enter Port Mapping configuration screen.

Parameters

Use Interface:

Service Name

Select a Service:

Custom Service:

Server IP Address:

External Port Start	External Port End	Protocol	Internal Port Start	Internal Port End
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	TCP <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>

Parameters

Use Interface: Select a interface which you want from the drop-down menu.

Service Name

Choose the service you need for this server. If you choose Select a Service, select an application from the listbox. If you choose Custom Service, enter a given name for this service.

Server IP Address: Enter the IP address.

External Port Start / External Port End: Enter the public port number & range you wish to configure.

Protocol: In addition to specifying the port number used, you also need to specify the protocol used. The protocol is determined by a particular application. Most applications use TCP or UDP, however you may also specify other protocols using the drop-down Protocol menu.

Internal Port Start / Internal Port End: Enter the public port number & range you wish to configure.

Click Apply/Save to confirm the settings and you will be returned to Port Mapping table.


Remove: To delete the port mapping entry from the table, check Remove checkbox then click Remove button to delete the selected item.

Since NAT acts as a “natural” Internet firewall, your router protects your network from accessed by outside users, as all incoming connection attempts point to your router unless you specifically create Virtual Server entries to forward those ports to a PC on your network. When your router needs to allow outside users to access internal servers, e.g. a web server, FTP server, Email server or game server, the router can act as a “virtual server”. You can set up a local server with a specific port number for the service to use, e.g. web/HTTP (port 80), FTP (port 21), Telnet (port 23), SMTP (port 25), or POP3 (port 110). When an incoming access request the router for a specified port is received, it is forwarded to the corresponding internal server.

For example, if you set the port number 80 (Web/HTTP) to be mapped to the IP Address 192.168.1.2, then all incoming HTTP requests from outside users are forwarded to the local server (PC) with the IP address of 192.168.1.2. If the port is not listed as a predefined application, you need to add it manually.

DMZ Host

The DMZ Host is a local computer exposed to the Internet. When setting a particular internal IP address as the DMZ Host, all incoming packets that do not use a port number which is already used by any other Virtual Server entries will first be checked by the Firewall and NAT algorithms before it is passed to the DMZ host. When this is done, press Apply to save the changes.



DMZ Host IP Address: Enter the computer's IP address and click Save/Apply to activate the DMZ host. Or you can clear this field and click Save/Apply to inactivate the DMZ host.



Attention

If you have disabled the NAT option in the WAN-ISP section, the Virtual Server will hence become invalid. If the DHCP option is enabled, you have to be very careful in assigning the IP addresses of the virtual servers in order to avoid conflicts. The easiest way of configuring Virtual Servers is to manually assign static IP addresses to each virtual server PC, with an address that does not fall into the range of IP addresses that are to be issued by the DHCP server. You can configure the virtual server IP address manually, but it must still be in



NOTE: Since outside users are able to connect to the PCs on your network, port mapping utilization imposes security implications. You are therefore advised to use specific Virtual Server entries just for those ports that your applications require.

Advanced

Configuration options within the Advanced section are for users who wish to take advantage of the more advanced features of the router. Users who do not understand the features should not attempt to reconfigure their router, unless advised to do so by support staff.

Here are the items within the Advanced section: [Routing](#), [DNS](#), [Interface Grouping](#), [Device Management](#), [System Log Server](#) and [TR-069 client](#).

Routing

Default Gateway




WAN interface as the system default gateway: Select an appropriate WAN interface as the default gateway.

Click Save/Apply to confirm the settings.

Static Route

With static route feature, you are equipped with the capability to control the routing of the all the traffic across your network. With each routing rule created, you can specifically assign the destination where the traffic will be routed to.



Destination: Enter the destination IP where the traffic is to be forwarded.

Netmask: Enter the netmask of the destination.

Gateway: Enter the gateway address for the traffic.

Interface: Select an appropriate interface for the new routing rule from the drop-down menu.

Click Add to confirm the settings.

#: This is the rule number for each static router entry.

Edit: Check the Edit radio button to display the parameters of the selected application. Then change the items you want and click on Edit button to apply the changes.

Remove: To delete a static route entry, check the Remove box of the selected entry and then click on Remove button.

RIP

Interface	Version	Operation	Enabled
ptm0	2	Passive	<input type="checkbox"/>

Apply/Save

Interface: Displays the interface for the RIP rule.

Version: Select the desired RIP version for this interface.

Gateway: Select the desired RIP operation for this interface.

Enabled: Check Enabled check box for the interface.

Click Apply/Save to confirm the settings.

DNS

DNS Server

On the Internet, Domain Name System (DNS) servers are used to translate a hostname or a domain name to its corresponding binary identifier.

Obtain DNS info from a WAN interface:

WAN Interface selected: ipoe_0_0_1/ptm0

Use the following Static DNS IP address:

Primary DNS server:

Secondary DNS server:

Apply/Save

If you check "Obtain DNS info from a WAN interface", this router will accept the first received DNS assignment from one of the WAN interface during the connection establishment. If you check "Use the following Static DNS IP address", enter the primary and optional secondary DNS server IP addresses.

Click Apply/Save to confirm the settings.

Dynamic DNS

The Dynamic DNS function lets you alias a dynamic IP address to a static hostname, so if your ISP does not assign you a static IP address you can still use a domain name. This is especially useful when hosting servers via your ADSL connection, so that anyone wishing to connect to you may use your domain name, rather than the dynamic IP address which is assigned to you by ISP.

You need to first register and establish an account with the Dynamic DNS provider using their website, for example <http://www.dyndns.org/>.



The screenshot shows a web interface with a 'Configuration' header. Below it is a section titled 'Dynamic DNS' which contains a table with the following columns: Hostname, Username, Service, Interface, and Remove. Below the table are two buttons: 'Add' and 'Remove'.

Click Add to enter Add Dynamic DNS screen.



The screenshot shows the 'Add Dynamic DNS' form within the 'Configuration' section. It includes a 'Parameters' section with the following fields: 'D-DNS provider' (a dropdown menu with 'DynDNS.org' selected), 'Hostname' (a text input field), 'Interface' (a dropdown menu with 'ipoe_0_0_1/ptm0' selected), 'Username' (a text input field), and 'Password' (a text input field). At the bottom of the form is an 'Apply/Save' button.

Dynamic DNS Server: Select the DDNS service you have registered an account with.

Hostname: Enter your registered hostname for this service.

Interface: Select an appropriate interface for the DDNS service from the drop-down menu.

Username/Password: Enter username and password for this service.

Click Apply/Save to confirm the settings and you will be returned to Dynamic DNS table.

Remove: To delete the DDNS entry from the table, check Remove checkbox then click Remove button to delete the selected item.

Interface Grouping

This function allows you to set new interface group.

The screenshot shows the 'Configuration' page with a section for 'Interface Grouping'. It contains a table with the following data:

Group Name	Remove	WAN Interface	LAN Interface	DHCP Vendor IDs
Default		ptm0	eth2	
			eth3	
			eth1	
			eth0	

Below the table are 'Add' and 'Remove' buttons.

Click Add to create a new interface grouping.

The screenshot shows the 'Configuration' page with a section for 'Interface Grouping' in a detailed configuration mode. It includes the following fields and controls:

- Group Name:** A text input field.
- WAN interface used in the grouping:** A dropdown menu with 'ipoe_0_0_1/ptm0' selected.
- Grouped LAN Interfaces:** An empty list box.
- Available LAN Interfaces:** A list box containing 'eth0', 'eth1', 'eth2', and 'eth3'.
- Navigation:** '<- Add' and '-> Remove' buttons between the grouped and available LAN interfaces.
- Automatically Add Clients With the following DHCP Vendor IDs:** Five input fields labeled 'Vendor #0' through 'Vendor #4'.
- Buttons:** 'Apply/Save' at the bottom.

Group Name: Enter the name that you want this interface group to have.

WAN Interface used in the grouping: Select appropriate WAN interface.

Grouped LAN Interfaces: Displays the list of selected ethernet ports in this group. To delete services from the list, select the interface and click Remove.

Available LAN Interfaces: Displays the list of available ethernet ports which you can add to this group. Select the services you want and click Add.

Note: Ethernet port needs to be part of port mapping group and bridge interface.

Automatically Add Clients With the following DHCP Vendor IDs: Enter the IDs in the fields.

Click on Save/Apply button to finish the configuration and you will be returned to Interface Grouping table.

Configuration

▼ Interface Grouping

Group Name	Remove	WAN Interface	LAN Interface	DHCP Vendor IDs
Default			eth2	
			eth3	
			eth1	
test	<input type="checkbox"/>	ptm0	eth0	

Add Remove

Remove: To delete the Interface Grouping from the table, check Remove checkbox then click Remove button to delete the selected item.

Device Management

The Device Management advanced configuration settings allow you to control your router's security options and device monitoring features.



UPnP offers peer-to-peer network connectivity for PCs and other network devices, along with the feature to control data transfer between devices. UPnP offers many advantages for users running NAT routers through UPnP NAT Traversal, and on supported systems. By letting the application control the required settings and removing the need for the user to control the advanced configuration of their device will make tasks such as port forwarding become easier.

Both user's Operating System and its relevant applications must support UPnP in addition to the router. Windows XP and Windows Me have a native built-in support for UPnP (when the component is installed). Windows 98 users may have to install the Internet Connection Sharing client from Windows XP in order to support UPnP feature. Windows 2000 does not support UPnP.

Installing UPnP in Windows Example

Follow the steps below to install the UPnP in Windows Me.

Step 1: Click Start and Control Panel. Double-click Add/Remove Programs.

Step 2: Click on the Windows Setup tab and select Communication in the Components selection box. Click Details.



Step 3: In the Communications window, select the Universal Plug and Play check box in the Components selection box.



Step 4: Click OK to go back to the Add/Remove Programs Properties window. Click Next.

Step 5: Restart the computer when prompted.

Follow the steps below to install the UPnP in Windows XP


Step 1: Click Start and Control Panel.

Step 2: Double-click Network Connections.

Step 3: In the Network Connections window, click Advanced in the main menu and select Optional Networking Components ...




Step 4: When the Windows Optional Networking Components Wizard window appears, select Networking Service in the Components selection box and click Details.



Step 5: In the Networking Services window, select the Universal Plug and Play check box.

Step 6: Click OK to go back to the Windows Optional Networking Component Wizard window and click Next.



Auto-discover Your UPnP-enabled Network Device

Step 1: Click start and Control Panel. Double-click Network Connections. An icon displays under Internet Gateway.


Step 2: Right-click the icon and select Properties.



Step 3: In the Internet Connection Properties window, click Settings to see the port mappings that were automatically created.



Step 4: You may edit or delete the port mappings or click Add to manually add port mappings.



Step 5: Select Show icon in notification area when connected option and click OK. An icon displays in the system tray.



Step 6: Double-click on the icon to display your current Internet connection status.



Web Configurator Easy Access


With UPnP, you can access web-based configuration for the BEC 8800N without first finding out the IP address of the router. This helps if you do not know the router's IP address.

Follow the steps below to access web configuration.

Step 1: Click Start and then Control Panel.

Step 2: Double-click Network Connections.

Step 3: Select My Network Places under Other Places.



Step 4: An icon describing each UPnP-enabled device shows under Local Network.

Step 5: Right-click on the icon of your BEC 8800N and select Invoke. The web configuration login screen displays.

Step 6: Right-click on the icon of your BEC 8800N and select Properties. A properties window displays basic information about the BEC 8800N.

System Log Server

This screen allows you to view the system events log or to configure the system log options.



Send Log To Remote Server: By default, it is disabled. To enable it, tick Enable to activate system log.


Log Server IP Address: Enter the server IP address.

Log Server UDP Port: Enter the server UDP port.

Click Apply/Save to confirm the settings.

TR-069 Client

Please contact your ISP for the information of TR069.



Parameters	
Inform	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Inform Interval	<input type="text" value="300"/>
ACS URL	<input type="text"/>
ACS User Name	<input type="text" value="admin"/>
ACS Password	<input type="password" value="*****"/>
Connection Request Authentication	<input checked="" type="checkbox"/>
Connection Request User Name	<input type="text" value="admin"/>
Connection Request Password	<input type="password" value="*****"/>

Inform: You can enable or disable the periodic inform feature.

Inform Interval: Enter the length of the periodic inform interval (unit: seconds).

ACS URL: Enter the ACS URL address.

ACS Username: Enter the ACS server login name.

ACS Password: Enter the ACS server login password.

Connection Request Authentication: Check to enable connection request authentication feature.

Connection Request User Name: Enter the username for ACS server to make connection request.

Connection Request Password: Enter the password for ACS server to make connection request.

GetRPCMethods: Detect the types of methods that ACS supports and is in communication with.

Click Apply to confirm the settings.

Diagnostics

Here are 2 items within this section: [Diagnostics](#) and [Fault Management](#).

Diagnostics

This page allows users to test the Ethernet port connection, DSL port connection, and connection to the Internet Service Provider. If a test displays a FAIL status, click "Test" again or "Test With OAM F4" to make sure the fail status is consistent.

The screenshot shows a web interface for diagnostics. At the top, there is a header "ipoe_0_0_1 Diagnostics". Below this, there are three main sections, each with a dropdown arrow on the left:

- Local Network**:
 - Test your eth2 Connection: FAIL
 - Test your eth3 Connection: FAIL
 - Test your eth1 Connection: PASS
 - Test your eth0 Connection: FAIL
- DSL service provider**:
 - Test xDSL Synchronization: FAIL
 - Test ATM OAM F5 segment ping: DISABLED
 - Test ATM OAM F5 end-to-end ping: DISABLED
- Internet service provider**:
 - Ping default gateway: PASS
 - Ping primary Domain Name Server: FAIL

At the bottom of the interface, there are two buttons: "Test" and "Test With OAM F4".

Fault Management

IEEE 802.1ag Ethernet Connectivity Fault Management protocols comprise three protocols: continuity check, link trace and loopback protocols that work together to help administrators debug Ethernet networks. On this screen, you can configure 802.1ag CFM and use this function.

Diagnostics

802.1ag Connectivity Fault Management (only for VDSL PTM Mode)

Maintenance Domain (MD) Level:

Destination MAC Address:

802.1Q VLAN ID (0-4095):

VDSL Traffic Type:

Test the connection to another Maintenance End Point (MEP)

Loopback Message (LBM):

Find Maintenance End Points (MEPs)

Linktrace Message (LTM):

MEP ID	MAC Address	MD Level	MD Name

Chapter 5: Troubleshooting

If your router is not functioning properly, please refer to the suggested solutions provided in this chapter. If your problems persist or the suggested solutions do not meet your needs, please kindly contact your service provider or BEC for support.

Problem	Suggested Action
The power LED is not on	Make sure the connection of power supply is good, the switch of power supply is turned on and the output of power supply is correct.
None of the LEDs lit when the router is turned on	Check the connection between the router and the adapter. If the problem persists, most likely it is due to the malfunction of your hardware. Please contact your service provider or BEC for technical support.
I cannot access Internet or remote networks	Make sure that the power is turned on and the software configuration of the router is correct. Ensure that the device has been restarted after configuration change. Check IP connection using ping command and that the DNS of the computer is correct.
I cannot access some web server	This problem is often caused by one of the following issues: <ul style="list-style-type: none">• The MTU of operating system might be too large.• Some operating systems might need to be patched.
I cannot log on to the configuration page	<ul style="list-style-type: none">• Check the connection between the PC and the router.• Ensure your PC's IP address is on the same subnet as the router.• Check to see if your browser has Java, JavaScript, or ActiveX enabled. If you are using Internet Explorer, click Refresh to ensure that the Java applet is loaded.• Make sure you are using the correct user name and password. User names and passwords are case sensitive, so make sure that CAPS LOCK is not on when entering this information.• Reset the device.
I have forgotten my login username or password	Try the default username & password (Please refer to Chapter 3). If this fails, restore your router to its default setting by pressing the Reset button for 3~5 seconds.

Appendix: Product Support & Contact

If you come across any problems please contact the dealer from where you purchased your product.

Contact BEC

<http://www.bectechnologies.net>

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Customer Information

1. This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to the telephone company.
2. A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.
3. If this equipment [US: B12DL01B8920NE] causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.
4. The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.
5. If trouble is experienced with this equipment [US: B12DL01B8920NE], for repair or warranty information, Service can be facilitated through our office at:

U.S. Agent Company name: BEC Technologies Inc.

Address: 1500 Precision Drive, Suite 100 Plano TX 75074 USA

Tel: +1-972-422-0877

If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

6. Please follow instructions for repairing if any (e.g. battery replacement section); otherwise do not alternate or repair any parts of device except specified. For repair procedures, follow the instructions outlined under the limited warranty.

7. Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

8. If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this [8920NE] does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

9. If the telephone company requests information on what equipment is connected to their lines, inform them of:

- a) The ringer equivalence number [0.1B]
- b) The USOC jack required [RJ11C]
- c) Facility Interface Codes ("FIC") [METALLIC]
- d) Service Order Codes ("SOC") [9.0Y]
- e) The FCC Registration Number [US:B12DL01B8920NE]

10. The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. The REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point. For this product the FCC Registration number is [US: B12DL01B8920NE] indicates the REN would be 0.1.