

Administrator's Handbook

Motorola Netopia® Embedded Software
Version 9.0.1



Motorola Netopia® Gateways
September 2010



Copyright

Copyright © 2010 by Motorola, Inc.

All rights reserved. No part of this publication may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation or adaptation) without written permission from Motorola, Inc.

Motorola reserves the right to revise this publication and to make changes in content from time to time without obligation on the part of Motorola to provide notification of such revision or change. Motorola provides this guide without warranty of any kind, either implied or expressed, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Motorola may make improvements or changes in the product(s) described in this manual at any time. MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. Microsoft, Windows, Windows Me, and Windows NT are either trademarks or registered trademarks of Microsoft Corporation in the U.S and/or other countries. Macintosh is a registered trademark of Apple, Inc. Firefox is a registered trademark of the Mozilla Foundation. All other product or service names are the property of their respective owners.

Motorola, Inc.
1303 East Algonquin Road
Schaumburg, Illinois 60196
USA

Part Number

580780-001-00 rev a
V9.0.1-sku 1

Table of Contents

CHAPTER 1 Setting up Your Motorola Netopia® Modem or Gateway 7

Important Safety Instructions	8
POWER SUPPLY INSTALLATION	8
TELECOMMUNICATION INSTALLATION	8
PRODUCT VENTILATION	8
Wichtige Sicherheitshinweise	9
NETZTEIL INSTALLIEREN	9
INSTALLATION DER TELEKOMMUNIKATION	9
Set up your Gateway	10
Configure Your PC for Dynamic Addressing	11
Motorola Netopia® Gateway Quickstart	14

CHAPTER 2 Web-based Device Management 17

The Home Page	18
Home Page Information	18
Links Bar	19
Configure	20
Connection	21
DHCP Server	23
More IP Subnets	24
Wireless	25
NAT	31
Router Password	33
Time Zone	34
Status	35
DSL	35
WAN	35
Ethernet	36
Wireless	36
IP	36
LAN	36
System Log	37
Firewall Log	38
Utilities	39
Diagnostics	40
Restart Router	42
Reset Router	42
Update Router	43
Help	44

CHAPTER 3 Basic Troubleshooting 45

Status Indicator Lights	46
LED Function Summary Matrix	47

Factory Reset Switch	49
----------------------------	----

CHAPTER 4 Command Line Interface51

Overview	52
Starting and Ending a CLI Session	54
Logging In	54
Ending a CLI Session	54
Using the CLI Help Facility	54
About SHELL Commands	55
SHELL Prompt	55
SHELL Command Shortcuts	55
SHELL Commands	56
Common Commands	56
WAN Commands	62
About CONFIG Commands	64
CONFIG Mode Prompt	64
Navigating the CONFIG Hierarchy	64
Entering Commands in CONFIG Mode	64
Guidelines: CONFIG Commands	65
Displaying Current Gateway Settings	65
Step Mode: A CLI Configuration Technique	65
Validating Your Configuration	66
CONFIG Commands	67
Connection commands	67
IP DNS commands	68
IP IGMP commands	69
NTP commands	71
IP Gateway commands	71
Application Layer Gateway (ALG) commands	72
Link commands	72
Management commands	73
Physical interfaces commands	74
PPPoE relay commands	76
NAT Pinhole commands	77
System commands	78

CHAPTER 5 Technical Specifications and Safety Information81

Description	81
Power requirements	81
Environment	81
Software and protocols	81
Agency approvals	82
Regulatory notices	82
Manufacturer's Declaration of Conformance	83
Important Safety Instructions	85
47 CFR Part 68 Information	86
FCC Requirements	86
FCC Statements	86

Electrical Safety Advisory	87
Warranty Information	88
Software License, Limited Warranty and Limitation of Remedies	88
Software License	88
Warranty Information	89
Copyright Acknowledgments	91
Caring for the Environment by Recycling	103
Beskyttelse af miljøet med genbrug	103
Umweltschutz durch Recycling	103
Cuidar el medio ambiente mediante el reciclaje	103
Recyclage pour le respect de l'environnement	103
Milieubewust recycleren	104
Dbá[ro]Éç o Érodowisko - recykling	104
Cuidando do meio ambiente através da reciclagem	104
Var rädd om miljön genom återvinning	104
Index	107

CHAPTER 1 Setting up Your Motorola Netopia® Modem or Gateway

This Administrator's Handbook covers the advanced features of the Motorola Netopia® Modem and Gateway families.

Your Motorola Netopia® equipment offers advanced configuration features accessed through the Web-based interface screens and the Command Line Interface (CLI). This Administrator's Handbook documents the advanced features, including advanced testing, security, monitoring, and configuration. This Administrator's Handbook should be used as a companion to the User Manual. You should read the User Manual before reading this Administrator's Handbook.

This guide is targeted primarily to residential service subscribers.

Expert Mode sections and the Command Line Interface may also be of use to the support staffs of broadband service providers and advanced residential service subscribers. (See [“Expert Mode” on page 43](#) and [“Command Line Interface” on page 51.](#))

Most users will find that the basic Quickstart configuration is all that they ever need to use. This section may be all that you ever need to configure and use your Motorola Netopia® Gateway. The following instructions cover installation in Router Mode.

- ◆ [“Important Safety Instructions” on page 8](#)
[“Wichtige Sicherheitshinweise” on page 9](#)
- ◆ [“Set up your Gateway” on page 10](#)
- ◆ [“Configure Your PC for Dynamic Addressing” on page 11](#)
- ◆ [“Motorola Netopia® Gateway Quickstart” on page 14](#)

Important Safety Instructions

POWER SUPPLY INSTALLATION

Connect the power supply cord to the power jack on the Motorola Netopia® Gateway. Plug the power supply into an appropriate electrical outlet.



WARNING:

The power supply must be connected to a mains outlet with a protective earth connection. Do not defeat the protective earth connection.

CAUTION:

Depending on the power supply provided with the product, either the direct plug-in power supply blades, power supply cord plug or the appliance coupler serves as the mains power disconnect. It is important that the direct plug-in power supply, socket-outlet or appliance coupler be located so it is readily accessible.

(Sweden) Apparaten skall anslutas till jordat uttag när den ansluts till ett nätverk

(Norway) Apparatet må kun tilkoples jordet stikkontakt.

USB-powered models: For Use with Listed I.T.E. Only

TELECOMMUNICATION INSTALLATION

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- ◆ Do not use this product near water, for example, near a bathtub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
- ◆ Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electrical shock from lightning.
- ◆ Do not use the telephone to report a gas leak in the vicinity of the leak.
- ◆ CAUTION: The external phone should be UL Listed and the connections should be made in accordance with Article 800 of the NEC.

PRODUCT VENTILATION

The Motorola Netopia® Gateway is intended for use in a consumer's home. Ambient temperatures around this product should not exceed 104°F (40°C). It should not be used in locations exposed to outside heat radiation or trapping of its own heat. The product should have at least one inch of clearance on all sides except the bottom when properly installed and should not be placed inside tightly enclosed spaces unless proper ventilation is provided.

SAVE THESE INSTRUCTIONS

Wichtige Sicherheitshinweise

NETZTEIL INSTALLIEREN

Verbinden Sie das Kabel vom Netzteil mit dem Power-Anschluss an dem Motorola Netopia® Gateway. Stecken Sie dann das Netzteil in eine Netzsteckdose.



Warnung:

Das Netzteil muss an eine Steckdose, die mit einem Schutzleiter verbunden ist, angeschlossen werden. Die Schutzleiterverbindung darf in keinem Fall unterbrochen werden.

Achtung:

Abhängig von dem mit dem Produkt gelieferten Netzteil, entweder die direkten Steckernetzgeräte, Stecker vom Netzkabel oder der Gerätekoppler dienen als Hauptspannungsunterbrechung. Es ist wichtig, dass das Steckernetzgerät, Steckdose oder Gerätekoppler frei zugänglich sind.

(Sweden) Apparaten skall anslutas till jordat uttag när den ansluts till ett nätverk

(Norway) Apparatet må kun tilkoples jordet stikkontakt.

USB-powered models: For Use with Listed I.T.E. Only

INSTALLATION DER TELEKOMMUNIKATION

Wenn Ihre Telefonausrüstung verwendet wird, sollten grundlegende Sicherheitsanweisungen immer befolgt werden, um die Gefahr eines Feuers, eines elektrischen Schlages und die Verletzung von Personen, zu verringern. Beachten Sie diese weiteren Hinweise:

- ◆ Benutzen Sie dieses Produkt nicht in Wassernähe wie z.B. nahe einer Badewanne, Waschschüssel, Küchenspüle, in einem nassen Keller oder an einem Swimmingpool.
- ◆ Vermeiden Sie das Telefonieren (gilt nicht für schnurlose Telefone) während eines Gewitters. Es besteht die Gefahr eines elektrischen Schlages durch einen Blitz.
- ◆ Nicht das Telefon benutzen um eine Gasleckstelle zu Melden, wenn Sie sich in der Nähe der Leckstelle befinden.

Bewahren Sie diese Anweisungen auf

Set up your Gateway

Refer to your User Manual for instructions on how to connect your Motorola Netopia® Gateway to your power source, PC or local area network, and your Internet access point, whether it is a dedicated DSL outlet or a DSL or cable modem. Different Motorola Netopia® Gateway models are supplied for any of these connections. Be sure to enable Dynamic Addressing on your PC. See "[Configure Your PC for Dynamic Addressing](#)".

Configure Your PC for Dynamic Addressing


The following instructions assume that you want to use the automatic configuration and address sharing features of the Gateway to provide IP information to devices on your Local Area Network. To connect additional computers that will use the Gateway's address sharing feature repeat these steps for each computer.

Microsoft Windows:

1. Navigate to the TCP/IP Properties Control Panel.


a. Some Windows versions follow a path like this:

Start menu -> Settings -> Control Panel -> Network (or Network and Dial-up Connections -> Local Area Connection -> Properties) -> TCP/IP [your_network_card] or Internet Protocol [TCP/IP] -> Properties



b. Some Windows versions follow a path like this:

Start menu -> Control Panel -> Network and Internet Connections -> Network Connections -> Local Area Connection -> Properties -> Internet Protocol [TCP/IP] -> Properties




Then go to Step 2.

2. **Select *Obtain an IP address automatically*.**
3. **Select *Obtain DNS server address automatically*, if available.**
4. **Remove any previously configured gateways, if applicable.**
5. **Click the OK button. Restart if prompted.**

Proceed to the next section "[Motorola Netopia® Gateway Quickstart](#)" on page 14.

c. Windows Vista and Windows 7 are set to obtain an IP address automatically by default. You may not need to configure them at all.

To check, open the **Networking** Control Panel and select **Internet Protocol Version 4 (TCP/IPv4)**. Click the **Properties** button.



The **Internet Protocol Version 4 (TCP/IPv4) Properties** window should appear as shown.


If not, select the radio buttons shown above, and click the **OK** button.

Macintosh MacOS 9.2 and higher or Mac OS X 10.1.5 or higher:

1. Access the TCP/IP or Network control panel.


a. MacOS follows a path like this:

Apple Menu -> Control Panels -> TCP/IP Control Panel



b. Mac OS X follows a path like this:

Apple Menu -> System Preferences -> Network -> Network -> Configure



Then go to Step 2.


- 2. Select *Built-in Ethernet***
- 3. Select *Configure IPv4: Using DHCP***
- 4. Close and Save, if prompted.**

Proceed to the next section [“Motorola Netopia® Gateway Quickstart” on page 14.](#)

Motorola Netopia® Gateway Quickstart

1. Run a Web browser, such as Mozilla Firefox or Microsoft Internet Explorer.


Enter <http://192.168.1.254> in the URL Address text box.



Press Return.

(If your ISP's Configuration Worksheet tells you to use an IP address other than 192.168.1.254 to log in, enter `http://< ip-address>`.)

2. The browser displays the Welcome page.



◆ You can choose **Unrestricted LAN Access**.

If you choose Unrestricted LAN Access, any user connected to your network can access and administer the Motorola Netopia® Gateway's configuration pages.

Or,

◆ For security, you may create and enter an Administrative password for accessing the Motorola Netopia® Gateway.

- The administrative User name is **admin**.

- The initial Password can be whatever you choose, from one to 32 characters long.

This user name and password are separate from the user name and password you might use to access the Internet. You may change them later. You will be challenged for this Admin username and password any time that you attempt to access the Motorola Netopia® Gateway's configuration pages.

If you have chosen to create an Administrative password, when you connect to your Gateway as an Administrator, you enter “admin” as the UserName and the Password you just created.



3. Click **OK**.


Congratulations! Your installation is complete. You can now surf to your favorite Web sites by typing an URL in your browser's location box or by selecting one of your favorite Internet bookmarks. Optional services that you may have contracted with your provider are also available.

If you have any questions or encounter problems with your Motorola Netopia® Gateway, refer to [“Basic Troubleshooting” on page 45](#), the context-sensitive help in your Gateway's web pages, or contact your service provider's technical support helpdesk.

Answers to many frequently asked product-related questions are also available on-line at:

<http://broadband.motorola.com/consumers/support/default.asp?supportSection=blank>

If you click the Back button on your web browser, the browser displays the Basic Home Page.



CHAPTER 2 Web-based Device Management

Using the Web-based user interface for the Motorola Netopia[®] Gateway you can configure, troubleshoot, and monitor the status of your Gateway.

- ◆ [“The Home Page” on page 18](#)
- ◆ [“Links Bar” on page 19](#)
- ◆ [“Configure” on page 20](#)
- ◆ [“Status” on page 35](#)
- ◆ [“Utilities” on page 39](#)
- ◆ [“Help” on page 44](#)

The Home Page

Home Page for a Wi-Fi model

The screenshot shows the Motorola Home Page interface. On the left is a navigation menu with links for Home, Configure, Status, Utilities, and Help. The main content area is divided into three sections: Connection Information, Router Information, and Local Network. Each section contains key status and configuration details.

Connection Information			
DSL	Connected	WAN Status	Connected
IP Address	0.0.0.0	IP Gateway	
Primary DNS Server		Secondary DNS Server	
Speed	0/0 (kbps)	Line Attenuation	0/0 dB
Restart Connection			

Router Information			
Router Name	Motorola Netopia	Model	2247-N8
Serial Number	155541619056	MAC Address	00:24:37:00:c1:70
Software Version	9.0.1	Warranty Date	Unknown

Local Network			
IP Address	192.168.1.254	Ethernet	Connected
Wireless	operational	Privacy	Disabled
Wireless ID (SSID)	ssid-one (Broadcast)		

Home Page Information


The Home page displays information about the following categories:

- ◆ **Connection Information**
- ◆ **Router Information**
- ◆ **Local Network**
- ◆ **Restart Connection** – For a PPPoE connection, clicking this button will bring down any PPPoE WAN connection that is up and resend your current PPPoE login credentials and reestablish your Internet connection. For a DHCP connection, clicking this button will release and renew the DHCP lease from your service provider's DHCP server, which assigns your local WAN IP address.
- ◆ **Connect** – Only displays if you are not connected. For a PPPoE connection, clicking this button will allow you to attempt to login using a different User ID and Password.
- ◆ **Disconnect** – Only for a PPPoE connection, clicking this button will disconnect you from the Internet until you choose to reestablish your connection manually.

Click the [Help](#) link in the left-hand column of links to display a page of explanatory information. Help is available for every page in the Web interface. See [“Help” on page 44](#).

Links Bar

The links in the left-hand column of the Home page access a series of pages to allow you to monitor, diagnose, and update your Gateway. The following sections give brief descriptions of these pages.



- ◆ [“The Home Page” on page 18](#)
- ◆ [“Configure” on page 20](#)
- ◆ [“Status” on page 35](#)
- ◆ [“Utilities” on page 39](#)
- ◆ [“Help” on page 44](#)

Configure




When you click **Configure** in the left hand column of links, the links bar expands.

- ◆ [“Connection” on page 21](#)
- ◆ [“DHCP Server” on page 23](#)
- ◆ [“More IP Subnets” on page 24](#)
- ◆ [“Wireless” on page 25](#)
- ◆ [“NAT” on page 31](#)
- ◆ [“Router Password” on page 33](#)
- ◆ [“Time Zone” on page 34](#)

Connection

When you click **Connection**, the **Connection Configuration** page appears. This screen's appearance will vary depending on your type of connection to the Internet.

Here is an example.



The screenshot shows a web interface titled "Connection Configuration". It contains several settings with checkboxes and pull-down menus:

- DSL Auto Modulation**:
- DSL Transport**:
- Auto Detection VPI/VCI**:
- Encapsulation**:
- PPPoE**:
- Bridging**:
- Use Static IP Addressing**:
- UPnP**:

At the bottom of the form is a blue button labeled "Apply Changes".

Here you can set up or change the way you connect to your ISP. You should only change these settings at your ISP's direction, or by agreement with your ISP.

- ◆ **DSL Auto Modulation:** provides automatic rate adaptation which tries to sync at the fastest possible modulation.
- ◆ **DSL Transport:** Select ATM (Asynchronous Transfer Mode), PTM (Packet Transfer Mode), AUTO, or NONE from the pull-down menu. These modes depend on the equipment used by your ISP. Many providers now support dual mode IP DSLAM line cards that default to PTM, with ATM as a fallback. The default AUTO allows the best compatibility.
- ◆ **Auto Detection VPI/VCI:** If this checkbox is checked, your Gateway will attempt to detect the virtual circuit pairs in use by trying the most common ones in succession until one is found. Thereafter, the Gateway will always attempt to use that pair. If it cannot detect the VPI/VCI set in use, you can uncheck the checkbox, and enter the values manually.
- ◆ **VPI/VCI:** These values depend on the way your ISP's equipment is configured. 0/35 and 8/35 are the most common virtual circuit pairs, but others are also used.
- ◆ **Encapsulation:** The authentication and encapsulation protocol is determined by your ISP by the type of account that you have signed up for and the model of your Motorola device. Choose from the pull-down menu: pppoe-llc, pppoe-vcmux, ether-llc, ip-llc, pppoa-llc, or pppoa-vcmux
- ◆ **Bridging:** Your Gateway can be turned into a simple bridge, if desired. Select **Enabled** from the pull-down menu. However, it will no longer provide routing or security features in this mode.
- ◆ **Use Static IP Addressing:** Your service provider may tell you that the WAN IP Address for your Gateway is static. In this case, check the checkbox.

- ◆ The screen expands to allow you to enter the **Static IP Address** and **Netmask** from your Service Provider in the appropriate fields.

The screenshot shows a 'Connection Configuration' window with the following settings:

- DSL Auto Modulation:**
- DSL Transport:** AUTO (dropdown)
- VPI:** 0 (text input)
- VCI:** 35 (text input)
- Encapsulation:** ether-llc (dropdown)
- Bridging:** Disabled (dropdown)
- Use Static IP Addressing:**
- Static IP Address:** 0.0.0.0 (text input)
- Netmask:** 255.255.255.0 (text input)
- IP Gateway:** 0.0.0.0 (text input)
- Primary DNS Server:** 0.0.0.0 (text input)
- Secondary DNS Server:** 0.0.0.0 (text input)

An 'Apply Changes' button is located at the bottom of the window.

- ◆ **IP Gateway:** The IP Address of the default gateway, or peer address if using PPP. This is normally set to 0.0.0.0 for PPP connections.
- ◆ **Primary DNS Server:** The IP Address of the Primary Domain Name Server
- ◆ **Secondary DNS Server:** The IP Address of the backup Domain Name Server

When all of your entries are made, click the **Apply Changes** button.

DHCP Server

When you click **DHCP Server**, the **DHCP Server Configuration** page appears.

DHCP Server Configuration
Router IP Address
Subnet Mask
DHCP Server Enable
DHCP Start Address
DHCP End Address
DHCP Lease : : :
Days : Hours : Minutes : Seconds

The Server configuration determines the functionality of your DHCP Settings. This functionality enables the Gateway to assign your LAN computer(s) a “private” IP address and other parameters that allow network communication. This feature simplifies network administration because the Gateway maintains a list of IP address assignments. Additional computers can be added to your LAN without the hassle of configuring an IP address. This is the default mode for your Gateway.

- ◆ **Router IP Address:** Specifies the IP address of the Gateway itself.
- ◆ **Subnet Mask:** Specifies the subnet for DHCP clients on the LAN side of the gateway. Defaults to the common Class C subnet.
- ◆ **DHCP Server Enable:** Uncheck this setting if you already have a DHCP server on your LAN. This enables the DHCP server in this Gateway.
- ◆ **DHCP Start Address:** Specifies the first address in the DHCP address range. You can reserve a sequence of up to 253 IP addresses within a subnet, beginning with the specified address, for dynamic assignment.
- ◆ **DHCP End Address:** Specifies the last address in the DHCP address range.
- ◆ **DHCP Lease:** Specifies the default length for DHCP leases issued by the Gateway. Enter lease time in dd:hh:mm:ss (days/hours/minutes/seconds) format.

More IP Subnets

When you click the **More IP Subnets** link, the **Additional IP Subnets** screen appears.

Additional IP Subnets

IP Subnet List

No IP Subnet entries have been defined

IP Subnet Entry

IP Address

Netmask

Enable DHCP Server

DHCP Start Address

DHCP End

Add this IP Subnet

Apply Changes

One subnet is preconfigured by default. The Additional IP Subnets screen allows you to configure up to seven secondary subnets and their DHCP ranges, by entering IP address/subnet mask pairs:



Note:

You need not use this screen if you have only a single Ethernet IP subnet.

- ◆ To add an IP subnet, enter the Gateway's IP address on the subnet in the **IP Address** field and the subnet mask for the subnet in the **Netmask** field.
- ◆ Enter the **DHCP Start Address** and **End Address** of the subnet range in their respective fields. Ranges cannot overlap and there may be only one range per subnet. If **DHCP Server** (see ["DHCP Server" on page 23](#)) is not enabled, the DHCP Start Address and DHCP End Address fields do not appear.
- ◆ Click the **Add this IP Subnet** button. Your entries will be added to the **IP Subnet List**.

Additional IP Subnets

IP Subnet List

IP Address	Netmask	DHCP Start	DHCP End	Edit	Remove
192.168.1.55	255.255.255.255	0.0.0.0	0.0.0.0		

IP Subnet Entry

IP Address

Netmask

Enable DHCP Server

DHCP Start Address

DHCP End

Add this IP Subnet

Apply Changes

To **Edit** or **Remove** a configured subnet, click the respective icon in the list item. When you are finished, click the **Apply Changes** button.

Wireless


(supported models)

When you click the [Wireless](#) link in the links bar, the menu expands.



Wireless Configuration

When you click the [Base Settings](#) link, the **Wireless Base Settings** page appears.



- ◆ The wireless function is automatically enabled by default. If you uncheck the **Enabled** checkbox, the wireless options are disabled, and the Gateway will not provide or broadcast its wireless LAN services.
- ◆ The pull-down menu allows you to select and lock the Gateway into the wireless transmission mode you want:

B/G	B-only
G-only	B/G/N
N-only	A/N
A-only	

For compatibility with clients using 802.11b (up to 11 Mbps transmission), 802.11g (up to 20+ Mbps), 802.11a (up to 54 Mbit/s using the 5 GHz band), or 802.11n (from 54 Mbit/s to 600 Mbit/s with the use of four spatial streams at a channel width of 40 MHz), select **B/G/N**. To limit your wireless LAN to one mode or the other, select **G-only**, **N-only**, **A-only**, or **B-only**, or some combination that applies to your setup.



NOTE:

If you choose to limit the operating mode to **G-only**, **N-only**, **A-only**, or **B-only**, clients using the mode(s) you excluded will not be able to connect.

- ◆ **Channel** – (1 through 11, for North America) on which the network will broadcast. This is a frequency range within the 2.4Ghz band. Channel selection depends on government regulated radio frequencies that vary from region to region. The widest range available is from 1 to 14. Europe, France, Spain and Japan differ. Channel selection can have a significant impact on performance, depending on other wireless activity close to this Router. Channel selection is not necessary at the client computers; the clients will scan the available channels seeking access points using the same SSID as the client.
- ◆ **Wireless Protected Setup (WPS)** is a not a new security protocol. It is simply an easier way to use existing protocols to provide greater security for your wireless network connections. By default, Privacy is set to Wireless Protected Access (WPA-PSK). WPS allows you to automatically generate a new strong WPA key for your Gateway and any client devices on your wireless network.



Note:

Not all client wireless devices support WPS. Refer to their documentation.

Wireless Security

When you click the **Security** link, the **Wireless Security** page appears.

Wireless Security

Configure settings for SSID 1
Apply Changes for this SSID before changing to a new SSID

Privacy: OFF - No Privacy

Hide SSID:

Block Wireless Bridging:

Apply Changes

YOU ARE STRONGLY ENCOURAGED TO IMPLEMENT SOME FORM OF PRIVACY ON YOUR WIRELESS LAN. You can specify the Privacy mode for each SSID that you define. Options from the pull-down menu are:

- ◆ **OFF- No Privacy**
- ◆ **WEP-Manual** - see [“WEP Manual” on page 27](#)
- ◆ **WPA-PSK** - see [“WPA-PSK” on page 28](#)

Hide SSID. If you check this checkbox, the Gateway hides the wireless network from the scanning features of wireless client computers. Unless both the wireless clients and the Gateway share the same Wireless ID in this mode, the Gateway’s wireless LAN will not appear as an available network when scanned for by wireless-enabled computers. Members of this “Closed System” WLAN must log onto the Gateway’s wireless network with the identical SSID as that configured in the router.

Closed System mode is an ideal way to increase wireless security and to prevent casual detection by unwanted neighbors, office users, or malicious users such as hackers.

If you do not enable this mode, it is more convenient, but potentially less secure, for clients to access your WLAN by scanning available access points. You must decide based on your own network requirements.

Enabling Closed System Mode on your wireless Gateway provides another level of security, since your wireless LAN will no longer appear as an available access point to client PCs that are casually scanning for one.

Your own wireless network clients, however, must log into the wireless LAN by using the exact SSID of the Motorola Netopia® Gateway.

In addition, if you have enabled WEP or WPA encryption on the Motorola Netopia® Gateway, your network clients must also have WEP or WPA encryption enabled, and must have the same WEP or WPA encryption key as the Motorola Netopia® Gateway.

Once the Motorola Netopia® Gateway is located by a client computer, by setting the client to a matching SSID, the client can connect immediately if WEP or WPA is not enabled. If WEP or WPA is enabled then the client must also have WEP or WPA enabled and a matching WEP or WPA key.

Wireless client cards from different manufacturers and different operating systems accomplish connecting to a wireless LAN and enabling WEP or WPA in a variety of ways. Consult the documentation for your particular wireless card and/or operating system.

Block Wireless Bridging. Check the checkbox to block wireless clients from communicating with other wireless clients on the LAN side of the Gateway.

WEP Manual

WEP (Wired Equivalent Privacy) Security is a Privacy option that is based on encryption between the Router and any PCs (“clients”) you have with wireless cards. If you are not using WPA-PSK Privacy, you can use WEP encryption instead. For this encryption to work, both your Router and each client must share the same Wireless ID, and both must be using the same encryption keys.

Wireless Security

Configure settings for SSID 1
Apply Changes for this SSID before changing to a new SSID

Privacy WEP - Manual

Key Length 10 characters (40/64 bits)

Key

Hide SSID

Block Wireless Bridging

Apply Changes

You can provide a level of data security by enabling WEP (Wired Equivalent Privacy) for encryption of network data. You can enable 40-, 128-, or 256-bit WEP Encryption (depending on the capability of your client wireless card) for IP traffic on your LAN.

WEP - Manual allows you to enter your own encryption keys manually. This is a difficult process, but only needs to be done once. Avoid the temptation to enter all the same characters.

- ◆ **Key Length:** Selects the length of each encryption key. The longer the key, the stronger the encryption and the more difficult it is to break the encryption.
- ◆ **Key:** The encryption keys. You enter keys using hexadecimal digits. For 40/64bit encryption, you need ten digits; 26 digits for 128bit WEP. Hexadecimal characters are 0 – 9, and a – f.

Examples:

- 40bit: 02468ACE02
- 128bit: 0123456789ABCDEF0123456789

Click the click **Apply Changes** button.

Any WEP-enabled client must have an identical key of the same length as the Gateway, in order to successfully receive and decrypt the traffic. Similarly, the client also has a 'default' key that it uses to encrypt its transmissions. In order for the Gateway to receive the client's data, it must likewise have the identical key of the same length.

WPA-PSK

One of the easiest ways to enable Privacy on your Wireless network is by selecting **WPA-PSK** (Wi-Fi Protected Access) from the pull-down menu.

Wireless Security

Configure settings for SSID 1
Apply Changes for this SSID before changing to a new SSID

Privacy: WPA - PSK

Passphrase: [Empty text field]

WPA Version: Both

Hide SSID:

Block Wireless Bridging:

Apply Changes

- ◆ Enter a **Passphrase**. The key can be between 8 and 63 characters, but for best security it should be at least 20 characters.
- ◆ You also have the choice of applying **Both WPA Version 1 and 2**, **WPA Version 1 Only**, or **WPA Version 2 Only** from the pull-down menu. These can be applied to each SSID individually.

When you have finished, click the **Apply Changes** button.

Wireless Multiple SSIDs

This feature allows you to add additional network identifiers (SSIDs or Network Names) for your wireless network. To enable Multiple SSIDs, click the **Multiple SSID** link.

The **Wireless Multiple IDs** screen appears to allow you to add up to three additional Wireless IDs.

Wireless Multiple SSIDs

Configure settings for SSID 1
Apply Changes for this SSID before changing to a new SSID

SSID Enable:

SSID Name: ssid-one

Apply Changes

- ◆ When the Multiple Wireless SSIDs screen appears, check the **SSID Enable** checkbox for each SSID you want to enable.
- ◆ The screen allows you to name each additional Wireless ID.

When you have finished, click the **Apply Changes** button.

Wireless Multi-media Configuration

Wireless Multi-media is an advanced feature that allows you to prioritize various types of data travelling over the wireless network. Certain types of data that are sensitive to delays, such as voice or video, must be prioritized ahead of other, less delay-sensitive types, such as email.

Wireless Multi-media currently implements wireless Quality of Service (QoS) by transmitting data depending on Diffserv priority settings. These priorities are mapped into four Access Categories (AC), in increasing order of priority:

- ◆ Background (BK),
- ◆ Best Effort (BE),
- ◆ Video (VI), and
- ◆ Voice (VO).

It requires WiFi Multimedia (WMM)-capable clients, usually a separate feature enabled at the client network settings, and client PC software that makes use of Differentiated Services (Diffserv). Refer to your operating system instructions for enabling Diffserv QoS.


When you click the [WiFi Multimedia](#) link the **Wireless Multi-media Configuration** page appears.



Check the **Enabled** checkbox and click the **Apply Changes** button.

Wireless MAC Filtering

When you click the [MAC Filtering](#) link the **Wireless MAC Filtering** page appears.



MAC Filtering allows you to specify which client PCs are allowed to join the wireless LAN by unique hardware (MAC) address.

- ◆ To enable this feature, select either **whitelist** or **blacklist** from the **MAC Filtering Type** pull-down menu.

- ◆ You add wireless clients that you want to either authorize or exclude for your wireless LAN by entering the MAC addresses in the **MAC Address** field provided.

Click the **Add this MAC** button.

Your entries will be added to a client **MAC Filter List**.

Wireless MAC Filtering

Configure settings for SSID 1 - ssid-one ▾

MAC Filtering Type whitelist ▾

When MAC Filtering whitelist is enabled, wireless devices on this list will be allowed access to this SSID. All others will be denied.

When MAC Filtering blacklist is enabled, all devices on this list will be denied access to this SSID. All others will be allowed.

MAC Filter List

MAC	Remove
00:16:cb:39:a9:78	×
00:15:cd:39:b9:87	×

MAC Filter Entry

MAC Address e.g. 00:11:22:33:44:55

Add this MAC +

Apply Changes

Click the **Apply Changes** button.

You can **Add** more entries or **Remove** any of your entries later by returning to this page.

NAT

When you click **NAT**, the **NAT Configuration** page appears.

NAT Configuration

NAT Enable

To create a Pinhole entry, specify the field values, and click the "+" Add icon.

When changes are complete, click the "Apply Changes" button.

Pinhole List

No Pinhole entries have been defined

Pinhole Entry

Protocol

External Port Range

Internal Address

Internal Start Port

Add this pinhole

- ◆ **NAT Configuration** allows you to host internet applications when NAT is enabled. You can host different games and software on different PCs.
- ◆ **Pinhole Entry** allows you to transparently route selected types of network traffic, such as FTP requests or HTTP (Web) connections, to a specific host behind the Gateway. Creating a pinhole allows access traffic originating from a remote connection (WAN) to be sent to the internal computer (LAN) that is specified in the Pinhole page.

Pinholes are common for applications like multiplayer online games. Refer to software manufacturer application documentation for specific traffic types and port numbers.
- ◆ Determine if any of the service applications that you want to provide on your LAN stations use **TCP** or **UDP** protocols. If an application does, then you must configure a pinhole to implement port forwarding.
 - **Protocol:** UDP or TCP
 - **External Port Range:** This is the range of ports on which you expect incoming traffic to be received.
 - **Internal Address:** This is the internal host IP address to which you want the traffic to be directed.
 - **Internal Start Port:** This is the port number at the start of the port range that you want your Gateway to use when forwarding traffic of the type(s) you have selected to the internal IP address.

The following example shows three pinholes:

- ◆ a web server (using TCP on port 80, the standard HTTP protocol web port) on a host at the internal IP address 192.168.1.1
- ◆ a mail server (using TCP on port 25, the standard SMTP protocol email port) at the internal IP address 192.168.1.2
- ◆ a games server (using UDP on a port range 1100 – 1200) at the internal IP address 192.168.1.3

NAT Configuration

NAT Enable

To create a Pinhole entry, specify the field values, and click the "+" Add icon.

To edit a Pinhole from the list, click on the pencil icon in the "Action" column. Then make your changes in the Pinhole Entry fields and press the "Change" button.

To delete a Pinhole from the list, click on the X icon in the "Action" column.
When changes are complete, click the "Apply Changes" button.

Pinhole List

Protocol	External Port Range	Internal Address	Edit	Remove
TCP	80	192.168.1.1		
TCP	25	192.168.1.2		
UDP	1100-1200	192.168.1.3		

Pinhole Entry

Protocol

External Port Range

Internal Address

Internal Start Port

Add this pinhole

Apply Changes

You can edit or delete any of your entries from the Pinhole List by clicking the **Edit** or **Remove** icons.

You can add more entries to the Pinhole List by clicking the **Add this pinhole** button.

When you are finished, click the **Apply Changes** button.

Router Password

When you click **Router Password**, the **Router Password** page appears.

Router Password

Enabling Unrestricted LAN Access mode will allow you to navigate all the pages without any authentication from LAN side. If Unrestricted LAN Access mode is disabled, after you submit your new password, you must logon with the new password before continuing.

Unrestricted LAN Access

New Password

Confirm Password


Here you can change the administrative password that you use when logging onto the Gateway as **admin**. Passwords are case sensitive fields, and must be 1 to 32 characters long. Store your password in a safe place. Enter your new password, and confirm it.

- ◆ You can choose **Unrestricted LAN Access**.
If you choose Unrestricted LAN Access, any user connected to your network can access and administer the Motorola Netopia® Gateway's configuration pages.
Or,
- ◆ For security, you may create and enter an Administrative password for accessing the Motorola Netopia® Gateway.
 - The administrative User name is **admin**.
 - The Password can be whatever you choose, from one to 32 characters long.You will be challenged for this Admin username and password any time that you attempt to access the Motorola Netopia® Gateway's configuration pages.

Click the **Apply Changes** button.

Time Zone

When you click the **Time Zone** link, the **Time Zone** page appears.



The screenshot shows a web interface for configuring the time zone. At the top left, the title "Time Zone" is displayed. Below it, there is a label "Time Zone" followed by a pull-down menu currently set to "UTC". A blue button labeled "Apply Changes" is positioned below the menu.

You can set your local time zone by selecting your time zone from the pull-down menu. This allows you to set the time zone for general time stamp purposes.

Click the **Apply Changes** button.

Changes are saved immediately.

Status



When you click **Status** in the left hand column of links, the links bar expands.

Available Status links vary by platform.

DSL

When you click **DSL**, the DSL Statistics page appears.

The DSL Statistics page displays information about the Gateway's WAN connection to the Internet.

- ◆ **Line State:** May be Up (connected) or Down (disconnected).
- ◆ **Modulation:** Method of regulating the DSL signal. DMT (Discrete MultiTone) allows connections to work better when certain radio transmitters are present.
- ◆ **Data Path:** Type of path used by the device's processor.

Downstream and Upstream statistics

- ◆ **Max Allowed Speed (kbps):** Your maximum speeds for downloading (receiving) and uploading (sending) data on the DSL line, in kilobits per second.
- ◆ **SN Margin (db):** Signal to noise margin, in decibels. Reflects the amount of unwanted "noise" on the DSL line.
- ◆ **Line Attenuation:** Amount of reduction in signal strength on the DSL line, in decibels.
- ◆ **CRC Errors:** Number of times data packets have had to be resent due to errors in transmission or reception.

WAN

When you click **WAN**, the WAN Statistics page appears.

The WAN Statistics page:

- ◆ displays detailed statistics about your WAN data traffic, upstream and downstream.
- ◆ displays the Server MAC address for the PPPoE session (if applicable)

This information is useful for troubleshooting and when seeking technical support.

Ethernet

When you click **Ethernet**, the Ethernet Statistics page appears.

The Ethernet Statistics page:

- ◆ displays your Gateway's unique hardware (MAC) address.
- ◆ displays detailed statistics about your LAN data traffic, upstream and downstream.

Wireless

When you click **Wireless**, the Wireless Statistics page appears.

- ◆ **Wireless Status:** displays the enabled wireless SSIDs and their security (privacy) settings
- ◆ **Wireless Statistics:** displays both bytes and packets received and transmitted.

IP

When you click **IP**, the IP Statistics page appears. The IP Statistics page displays the IP interfaces and routing table information about your network.

General

- ◆ **IP WAN Address:** The public IP address of your Gateway, whether dynamically or statically assigned.
- ◆ **IP Gateway:** Your ISP's gateway Gateway IP address
- ◆ **Primary DNS:** The IP address of the Primary Domain Name Server
- ◆ **Primary DNS name:** The name of the Primary Domain Name Server
- ◆ **Secondary DNS:** The IP address of the backup Domain Name Server (if any)
- ◆ **Secondary DNS name:** The name of the backup Domain Name Server

IP interfaces

- ◆ **Address:** Your Gateway's IP address as seen from your internal network (LAN), and from the public Internet (WAN)
- ◆ **Netmask:** The subnet mask for the respective IP interfaces (LAN and WAN)
- ◆ **Name:** The name of each IP interface (example:Eth0, WAN2)

Network Routing Table and Host Routing Table

The Routing tables display all of the IP routes currently known to your Gateway

LAN

When you click **LAN**, the LAN Statistics page appears.

The LAN Statistics page displays detailed information about your LAN IP configuration and names and IP addresses of devices on your LAN.


- ◆ **Gateway IP Address:** The IP address of your Gateway as seen from the LAN
- ◆ **DHCP Netmask:** Subnet mask of your LAN
- ◆ **DHCP Start Address:** First IP address in the range being served to your LAN by the Gateway's DHCP server
- ◆ **DHCP End Address:** Last IP address in the range being served to your LAN by the Gateway's DHCP server
- ◆ **DHCP Server Status:** May be On or Off
- ◆ **DNS Server:** The IP address of the default DNS server

Devices on LAN

Displays the IP Address, MAC (hardware) Address, and network Name for each device on your LAN connected to the Gateway.

System Log

When you click **System Log**, the System Log page appears.



The screenshot shows the Motorola System Log interface. The left sidebar contains navigation links: Home, Configure, Status, DSL, WAN, Ethernet, Wireless, IP, LAN, System Log, Firewall Log, Utilities, and Help. The main content area is titled "System Log" and features two buttons: "Clear Log" and "Save to File". Below the buttons, a message states "Events are listed starting from the oldest." followed by a list of system log entries. The log entries include timestamps, device identifiers (sdb[228]), and various system messages such as "log buffer size set to 8192", "starting process /sbin/klogd (pid 233)", "libmotopia: Closing /dev/motopia", "Loading platform module bcm_enet", "SSL CA-root-cert directory is ready.", "Hardware is '2247-N8'", "S/N 1234567888, SKU 40", "Wireless subsystem found", "DSL subsystem found", "Taking down phy.wl80211 interface wl0", "Adding wireless port ssid-1 (wl0)", "Adding wireless port ssid-2 (wl0.1)", "Adding wireless port ssid-3 (wl0.2)", "Adding wireless port ssid-4 (wl0.3)", "DSL EOC 1234567888:2247-N8:90127", "Broadcom DSL: Create PTM object with default settings...", "Broadcom DSL: Initialize VC object. vpi = 0", "enabling vc[1]", "Broadcom DSL: Initialize VC object. vpi = 0", "Broadcom DSL: First apply - apply everything", "error opening sysfs attribute file (/var/run/nas.pid) for reading", "NAS daemon not found, not killing", "error opening sysfs attribute file (/var/run/wpsm.pid) for reading", "WPS Monitor not found, not killing", "error opening sysfs attribute file (/var/run/eapd.pid) for reading", "Taking down phy.wl80211 interface wl0", "Bringing up phy.wl80211 interface wl0", "Bringing up phy.wl80211.ssid[1]", "Setting kernel ip link wl0 to up", "Setting kernel ip link wl0.1 to down", "Setting kernel ip link wl0.2 to down", "Setting kernel ip link wl0.3 to down", "error opening sysfs attribute file (/var/run/wpsm.pid) for reading", "error opening sysfs attribute file (/var/run/eapd.pid) for reading", "starting process /sbin/eapd (pid 523)", "EAPD daemon started (pid: 523)", "starting process /bin/wps_monitor (pid 524)", "WPS Monitor started (pid: 524)", "Already applied, skipping", "Port ssid-1 sending UP event", "Already applied, skipping", "Broadcom DSL: Apply DSL_BASE settings...", "dsl_set_dsl_mode AUTO mode is ON.", "dsl_set_dsl_mode mode = 0x7fdd4698.", "XTM interface enable/disable", "DSL: Obtain 6362/6328 chip info...", "Apply DSL_PTM settings...", "dsl_delete_xtm_connection PTM not found", "dsl_add_xtm_connection Add new connection", "dsl_add_xtm_connection created net device ptm0, code = 0".

The current status of the Gateway is displayed for all logs.

- ◆ You can clear all log entries by clicking the **Clear Log** button.
- ◆ You can save logs to a text (.TXT) file by clicking the **Save to File** button. This will download the file to your browser's default download location on your hard drive. The file can be opened with your favorite text editor.




Note:

Some browsers, such as Internet Explorer for Windows XP, require that you specify the Motorola Netopia[®] Gateway's URL as a "Trusted site" in "Internet Options: Security". This is necessary to allow the "download" of the log text file to the PC.

Firewall Log

When you click **Firewall Log**, the Firewall Log page appears.




The Gateway detects security related events including common types of malicious attacks and writes them to a dedicated Firewall log file. You view this log file from either:

- ◆ Motorola Netopia[®] Web interface
- ◆ Text-based command line interface using telnet

The log provides information useful in identifying a specific type of attack and tracing its origin. The log maintains 100 entries, and requires a manual reset once full. This preserves for troubleshooting purposes the acquired information about specific attacks, their frequency and tracing information.

Utilities

When you click the **Utilities** link, the linksbar expands to display the Gateway's diagnostic and update utilities.



- ◆ [“Diagnostics” on page 40](#)
- ◆ [“Restart Router” on page 42](#)
- ◆ [“Reset Router” on page 42](#)
- ◆ [“Update Router” on page 43](#)

Diagnostics

When you click **Diagnostics**, the Diagnostics page appears.

This automated multi-layer test examines the functionality of the Gateway from the physical connections to the data traffic being sent by users through the Gateway.

The screenshot shows a web interface for diagnostics. At the top, the heading "Diagnostics" is followed by the text "Running this test will help locate problems with your Internet Connection." Below this is a blue button labeled "Run Full Diagnostics". A horizontal line separates this from the "Test Web Access" section, which includes the instruction "Enter a Web Address (such as tftp.netopia.com) to test your Internet Connection." There is a text input field labeled "Web Address" and a blue "Test" button. Another horizontal line follows, leading to a "Progress Window:" which contains a large, empty rectangular box with a small cursor icon in the bottom right corner.

The **Run Full Diagnostics** section tests a number of different things at the same time, including the DSL line, the Ethernet interface and the PPPoE session.

This sequence of tests takes approximately one minute to generate results. Please wait for the test to run to completion.

Test Web Access

You enter a web address URL or an IP address in the Web Address field and click the **Test** button. Results will be displayed in the **Progress Window** as they are generated.

Example:

```
==== Checking LAN Interfaces
Check Ethernet LAN connect           : PASS
Check IP connect to Ethernet (LAN)   : PASS
  Pinging Gateway                     : PASS
Check MAC-Bridge connect to Ethernet (LAN) : PASS
==== Checking DSL (WAN) Interfaces
Check DSL Synchronization            : PASS
Check ATM Cell-Delineation           : PASS
  ATM OAM Segment Ping through (vccl) : WARNING
  *** Don't worry, your service provider may not support this test
  ATM OAM End-To-End Ping through (vccl) : WARNING
  *** Don't worry, your service provider may not support this test
Check Ethernet connect to AAL5 (vccl) : PASS
Check PPPOE connect to Ethernet (vccl) : PASS
Check PPP connect to PPPOE (vccl)     : PASS
  Check IP connect to PPP (vccl)       : PASS
  Pinging Gateway                       : PASS
==== Checking Miscellaneous
Check DNS- Query for netopia.com      : SKIPPED
Ping DNS Server Primary IP Address    : SKIPPED
TEST DONE
```

Each test generates one of the following result codes:

Result	Meaning
* PASS:	The test was successful.
* FAIL:	The test was unsuccessful.
* SKIPPED:	The test was skipped because a test on which it depended failed.
* PENDING:	The test timed out without producing a result. Try running Diagnostics again.
* WARNING:	The test was unsuccessful. The Service Provider equipment your Gateway connects to may not support this test.

Restart Router

When the Gateway is restarted, it will disconnect all users, initialize all its interfaces, and copy the Operating System Software from its internal storage.

When you make configuration changes, you must restart for the changes to take effect.



Reset Router

You might need to reset your Gateway to its factory default state, and clear all of your previous settings. The [Reset Router](#) link allows you to do that. When you click the link, you will be challenged to confirm that this is what you want to do.



If you want to clear your settings, click the [Yes, reset to factory settings](#) button. The Gateway configuration will be reset to the factory default. Any configuration information you have entered will be lost and will have to be re-entered. The Gateway will automatically restart.

Update Router

When you click **Update Router**, the **Software Upgrade** page appears.

Operating System Software is what makes your Gateway run and occasionally it needs to be updated. Your **Current Software Version** is displayed at the top of the page.

Software Upgrade

Current Software Version: 9.0.1r1

To update the software on your Router, you must first download it to a file on your PC.
[Click here to download.](#)

Select the update file you have placed on your PC's hard drive.

no file selected


To update your software from a file on your PC, you must first download the software.

1. **Click the [Click here to download link](#).**
You will be taken to the Motorola website for software upgrades.
2. **If an upgrade exists, download it to your computer.**
3. **Browse your computer for the operating system file you downloaded.**
4. **Click the [Update Software from PC](#) button.**
5. **The install may take a few minutes; wait for it to complete.**
6. **Restart your Gateway and your new operating system will be running.**

Help

Click the **Help** link in the left-hand column of links to display a page of explanatory information. Help is available for every page in the Web interface.

Here is an example:



CHAPTER 3 Basic Troubleshooting

This section gives some simple suggestions for troubleshooting problems with your Gateway's initial configuration.


Before troubleshooting, make sure you have

- ◆ read the User Manual;
- ◆ plugged in all the necessary cables; and
- ◆ set your PC's TCP/IP controls to obtain an IP address automatically.

Status Indicator Lights

The first step in troubleshooting is to check the status indicator lights (LEDs) in the order outlined in the following section.

Motorola Netopia® Gateway 2247-N8 status indicator lights



LED	Behavior
Power	Green when power is on. Red if device malfunctions; flashes red when updating embedded software.
Ethernet 1, 2, 3, 4	Solid green when connected. Flash green when there is activity on the LAN.
Wireless	Flashes green when there is activity on the wireless LAN.
WPS	Solid green when WPS is successful.
USB	Not currently used.
DSL	Flashes green when training. Solid green when trained.
Internet	Green when device is connected. Flashes green for activity on WAN port.
Activity	Off = The device is not powered or the broadband connection is not present; Flashing green = Inbound Internet activity seen from the broadband connection

LED Function Summary Matrix

	Power	DSL	Internet
Unlit	No power	No signal	Not connected
Solid Green	Power on	DSL line synched with the DSLAM	Connected to the Internet
Flashing Green	N/A	Activity on the DSL cable	Transmitting or receiving data on the WAN port
Solid Red	System malfunction	N/A	N/A
Flashing Red	Updating embedded software	N/A	N/A

	Ethernet 1, 2, 3, 4	WPS	Wireless
Unlit	No signal	No wireless signal	No wireless signal
Solid Green	Synched with Ethernet card	WPS exchange with client is successful	N/A
Flashing Green	Activity on the Ethernet cable	N/A	Activity on the wireless LAN
Solid Red	N/A	N/A	N/A
Flashing Red	N/A	N/A	N/A

If a status indicator light does not look correct, look for these possible problems:

If LED is not Lit	Possible problems
Power	<ul style="list-style-type: none"> ◆ Make sure the power switch is in the ON position. ◆ Make sure the power adapter is plugged into the DSL Gateway properly. ◆ Try a known good wall outlet. ◆ Replace the power supply and/or unit.
DSL	<ul style="list-style-type: none"> ◆ Make sure that any telephone has a microfilter installed. ◆ Make sure that you are using the correct cable. The DSL cable is the thinner standard telephone cable. ◆ Make sure the DSL cable is plugged into the correct wall jack. ◆ Make sure the DSL cable is plugged into the DSL port on the DSL Gateway. ◆ Make sure the DSL line has been activated at the central office DSLAM. ◆ Make sure the DSL Gateway is not plugged into a micro filter.

Ethernet	<ul style="list-style-type: none">◆ Make sure the you are using the Ethernet cable, not the DSL cable. The Ethernet cable is thicker than the standard telephone cable.◆ Make sure the Ethernet cable is securely plugged into the Ethernet jack on the PC.◆ Make sure the Ethernet cable is securely plugged into the Ethernet port on the DSL Gateway.◆ Try another Ethernet cable if you have one available.◆ Make sure you have Ethernet drivers installed on the PC.◆ Make sure the PC's TCP/IP Properties for the Ethernet Network Control Panel is set to obtain an IP address via DHCP.◆ Make sure the PC has obtained an address in the 192.168.1.x range. (You may have changed the subnet addressing.)◆ Make sure the PC is configured to access the Internet over a LAN.◆ Disable any installed network devices (Ethernet, HomePNA, wireless) that are not being used to connect to the DSL Gateway.
-----------------	--

Factory Reset Switch

Lose your password? This section shows how to reset the Motorola Netopia® so that you can access the configuration screens once again.



NOTE: Keep in mind that all of your settings will need to be reconfigured.

If you don't have a password, the only way to access the Motorola Netopia® is the following:

1. Referring to the following diagram, find the round Reset Switch opening.



2. Carefully insert the point of a pen or an unwound paperclip into the opening.
 - If you press the factory default button for less than 1/2 a second, the unit will continue to run as normal.
 - If you press the factory default button for 1 – 3 seconds, when you release it, the Gateway will perform a factory reset, clear all settings and configurations, and reboot. Do not hold the button down too long (5 – 10 seconds). This will destroy any saved default settings as well.

CHAPTER 4 Command Line Interface

The Motorola Netopia® Gateway operating software includes a command line interface (CLI) that lets you access your Motorola Netopia® Gateway over a telnet connection. You can use the command line interface to enter and update the unit's configuration settings, monitor its performance, and restart it.

This chapter covers the following topics:

- ◆ [“Overview” on page 52](#)
- ◆ [“Starting and Ending a CLI Session” on page 54](#)
- ◆ [“Using the CLI Help Facility” on page 54](#)
- ◆ [“About SHELL Commands” on page 55](#)
- ◆ [“SHELL Commands” on page 56](#)
- ◆ [“About CONFIG Commands” on page 64](#)
- ◆ [“CONFIG Commands” on page 67](#)

CONFIG Commands

- [“Connection commands” on page 67](#)
- [“IP DNS commands” on page 68](#)
- [“IP IGMP commands” on page 69](#)
- [“NTP commands” on page 71](#)
- [“IP Gateway commands” on page 71](#)
- [“Application Layer Gateway \(ALG\) commands” on page 72](#)
- [“Link commands” on page 72](#)
- [“Management commands” on page 73](#)
- [“Physical interfaces commands” on page 74](#)
- [“PPPoE relay commands” on page 76](#)
- [“NAT Pinhole commands” on page 77](#)
- [“System commands” on page 78](#)

Overview

The CLI has two major command modes: **SHELL** and **CONFIG**. **Summary tables** that list the commands are provided below. Details of the entire command set follow in this section.

SHELL Commands	
Command	Status and/or Description
arp	to send ARP request
atmping	to send ATM OAM loopback
clear	to erase all stored configuration information
clear_certificate	to remove an SSL certificate that has been installed
clear_log	to erase all stored log info in flash memory
configure	to configure unit's options
diagnose	to run self-test
download	to download config file
exit	to quit this shell
help	to get more: "help all" or "help help"
install	to download and program an image into flash
log	to add a message to the diagnostic log
loglevel	to report or change diagnostic log level
netstat	to show IP information
nslookup	to send DNS query for host
ping	to send ICMP Echo request
quit	to quit this shell
reset	to reset subsystems
restart	to restart unit
show	to show system information
start	to start subsystem
status	to show basic status of unit
telnet	to telnet to a remote host
traceroute	to send traceroute probes
upload	to upload config file
view	to show configuration information
who	to show who is using the shell

CONFIG Commands

Command Verbs	Status and/or Description
delete	Delete configuration list data
help	Help command option
save	Save configuration data
script	Print configuration data
set	Set configuration data
validate	Validate configuration settings
view	View configuration data

Keywords

conn	Connection options
ip	TCP/IP protocol options
dns	Domain Name System options
igmp	IGMP configuration options
ntp	Network Time Protocol options
gateway	Gateway options
link	WAN link options
mgmt	System management options
phy	Physical interface options
dsl	DSL configuration options
enet	Ethernet options
pinhole	Pinhole options
system	Gateway's system options
log	System activity logging options

Command Utilities

top	Go to top level of configuration mode
quit	Exit from configuration mode; return to shell mode
exit	Exit from configuration mode; return to shell mode

Starting and Ending a CLI Session

Open a telnet connection from a workstation on your network.

You initiate a telnet connection by issuing the following command from an IP host that supports telnet, for example, a personal computer running a telnet application such as NCSA Telnet.

```
telnet <ip_address>
```

You must know the IP address of the Motorola Netopia® Gateway before you can make a telnet connection to it. By default, your Motorola Netopia® Gateway uses 192.168.1.254 as the IP address for its LAN interface. You can use a Web browser to configure the Motorola Netopia® Gateway IP address.

Logging In

The command line interface log-in process emulates the log-in process for a UNIX host. To logon, enter the username and your password.

Entering the administrator password lets you display and update all Motorola Netopia® Gateway settings.

When you have logged in successfully, the command line interface lists the username and the security level associated with the password you entered in the diagnostic log.

Ending a CLI Session

You end a command line interface session by typing **quit** from the SHELL node of the command line interface hierarchy.

Using the CLI Help Facility

The **help** command lets you display on-line help for SHELL and CONFIG commands. To display a list of the commands available to you from your current location within the command line interface hierarchy, enter **help** or type a question mark (?).

To obtain help for a specific CLI command, type **help <command>**. You can truncate the **help** command to **h** or a question mark when you request help for a CLI command.

About SHELL Commands

You begin in SHELL mode when you start a CLI session. SHELL mode lets you perform the following tasks with your Motorola Netopia® Gateway:

- ◆ Monitor its performance
- ◆ Display and reset Gateway statistics
- ◆ Issue administrative commands to restart Motorola Netopia® Gateway functions

SHELL Prompt

When you are in SHELL mode, the CLI prompt is the name of the Motorola Netopia® Gateway followed by a right angle bracket (>). For example, if you open a CLI connection to the Motorola Netopia® Gateway named “Netopia-3000/9437188,” you would see **Netopia-3000/9437188>** as your CLI prompt.

SHELL Command Shortcuts

You can **truncate** most commands in the CLI to their shortest unique string. For example, you can use the truncated command **q** in place of the full **quit** command to exit the CLI. However, you would need to enter **rese** for the **reset** command, since the first characters of **reset** are common to the **restart** command.

The only commands you cannot truncate are **restart** and **clear**. To prevent accidental interruption of communications, you must enter the **restart** and **clear** commands in their entirety.

You can use the Up and Down arrow keys to scroll backward and forward through recent commands you have entered. Alternatively, you can use the **!!** command to repeat the last command you entered.

SHELL Commands

Common Commands

arp *nnn.nnn.nnn.nnn*

Sends an Address Resolution Protocol (ARP) request to match the *nnn.nnn.nnn.nnn* IP address to an Ethernet hardware address.

clear [*yes*]

Clears the configuration settings in a Motorola Netopia® Gateway. You are prompted to confirm the clear command by entering **yes**.

clear_certificate

Removes an SSL certificate that has been installed.

configure

Puts the command line interface into Configure mode, which lets you configure your Motorola Netopia® Gateway with Config commands. Config commands are described starting on [page 67](#).

download [*server_address*] [*filename*] [*confirm*]

This command installs a file of configuration parameters into the Motorola Netopia® Gateway from a TFTP (Trivial File Transfer Protocol) server. The TFTP server must be accessible on your Ethernet network.

You can include one or more of the following arguments with the download command. If you omit arguments, the console prompts you for this information.

- ◆ The *server_address* argument identifies the IP address of the TFTP server from which you want to copy the Motorola Netopia® Gateway configuration file.
- ◆ The *filename* argument identifies the path and name of the configuration file on the TFTP server.
- ◆ If you include the optional **confirm** keyword, the download begins as soon as all information is entered.

You can also download an SSL certificate file from a trusted Certification Authority (CA), on platforms that support SSL, as follows:

```
download [-cert] [server_address ] [filename] [confirm]
```

install [*server_address*] [*filename*] [*confirm*]

Downloads a new version of the Motorola Netopia® Gateway operating software from a TFTP (Trivial File Transfer Protocol) server, validates the software image, and programs the image into the Motorola Netopia® Gateway memory. After you install new operating software, you must restart the Motorola Netopia® Gateway.

The *server_address* argument identifies the IP address of the TFTP server on which your Motorola Netopia® Gateway operating software is stored. The *filename* argument identifies the path and name of the operating software file on the TFTP server.

If you include the optional keyword *confirm*, you will not be prompted to confirm whether or not you want to perform the operation.

log message_string

Adds the message in the *message_string* argument to the Motorola Netopia® Gateway diagnostic log.

loglevel [level]

Displays or modifies the types of log messages you want the Motorola Netopia® Gateway to record. If you enter the **loglevel** command without the optional *level* argument, the command line interface displays the current log level setting.

You can enter the **loglevel** command with the *level* argument to specify the types of diagnostic messages you want to record. All messages with a level number equal to or greater than the level you specify are recorded. For example, if you specify loglevel 3, the diagnostic log will retain high-level informational messages (level 3), warnings (level 4), and failure messages (level 5).

Use the following values for the *level* argument:

- ◆ **1** or **low** – Low-level informational messages or greater; includes trivial status messages.
- ◆ **2** or **medium** – Medium-level informational messages or greater; includes status messages that can help monitor network traffic.
- ◆ **3** or **high** – High-level informational messages or greater; includes status messages that may be significant but do not constitute errors.
- ◆ **4** or **warning** – Warnings or greater; includes recoverable error conditions and useful operator information.
- ◆ **5** or **failure** – Failures; includes messages describing error conditions that may not be recoverable.

netstat -i

Displays the IP interfaces for your Motorola Netopia® Gateway.

netstat -r

Displays the IP routes stored in your Motorola Netopia® Gateway.

nslookup [hostname | ip_address]

Performs a domain name system lookup for a specified host.

- ◆ The *hostname* argument is the name of the host for which you want DNS information; for example, **nslookup klaatu**.
- ◆ The *ip_address* argument is the IP address, in dotted decimal notation, of the device for which you want DNS information.

ping [-s size] [-c count] [hostname | ip_address]

Causes the Motorola Netopia® Gateway to issue a series of ICMP Echo requests for the device with the specified name or IP address.

- ◆ The *hostname* argument is the name of the device you want to ping; for example, **ping ftp.motorola.com**.
- ◆ The *ip_address* argument is the IP address, in dotted decimal notation, of the device you want to locate. If a host using the specified name or IP address is active, it returns one or more ICMP Echo replies, confirming that it is accessible from your network.
- ◆ The **-s** *size* argument lets you specify the size of the ICMP packet.
- ◆ The **-c** *count* argument lets you specify the number of ICMP packets generated for the ping request. Values greater than 250 are truncated to 250.

You can use the **ping** command to determine whether a hostname or IP address is already in use on your network. You cannot use the **ping** command to ping the Motorola Netopia® Gateway's own IP address.

quit

Exits the Motorola Netopia® Gateway command line interface.

reset arp

Clears the Address Resolution Protocol (ARP) cache on your unit.

reset crash

Clears crash-dump information, which identifies the contents of the Motorola Netopia® Gateway registers at the point of system malfunction.

reset dhcp server

Clears the DHCP lease table in the Motorola Netopia® Gateway.

reset enet [all]

Resets Ethernet statistics to zero. Resets individual LAN switch port statistics as well as wireless and WAN Ethernet statistics (where applicable).

reset firewall-log

Rewinds the firewall log to the first entry.

reset ipmap

Clears the IPMap table (NAT).

reset log

Rewinds the diagnostic log display to the top of the existing Motorola Netopia® Gateway diagnostic log. The **reset** log command does not clear the diagnostic log. The next **show log** command will display information from the beginning of the log file.

reset wan

This function resets WAN interface statistics.

reset wepkeys

This function allows you to force your wireless WEP key settings back to the default values, if there are default values. For example, on some models, the WEP keys are based on the serial number. This allows you to get back those default settings if you have changed them without the need to reset the entire configuration of the unit.

restart [seconds]

Restarts your Motorola Netopia® Gateway. If you include the optional *seconds* argument, your Motorola Netopia® Gateway will restart when the specified number of seconds have elapsed. You must enter the complete **restart** command to initiate a restart.

show all-info

Displays all settings currently configured in the Motorola Netopia® Gateway.

show bridge interfaces

Displays bridge interfaces maintained by the Motorola Netopia® Gateway.

show bridge table

Displays the bridging table maintained by the Motorola Netopia® Gateway.

show config

Dumps the Motorola Netopia® Gateway's configuration script just as the **script** command does in config mode.

show crash

Displays the most recent crash information, if any, for your Motorola Netopia® Gateway.

show daylight-savings

Displays the auto-daylight savings time settings information.

show dhcp agent

Displays DHCP relay-agent leases.

show dhcp server leases

Displays the DHCP leases stored in RAM by your Motorola Netopia® Gateway.

show diffserv

Displays the Differentiated Services and QoS values configured in the Motorola Netopia® Gateway.

show dsIf device-association

Displays LAN devices that conform with the TR111 Gateway requirement. It displays - IP Address, Manufacture OUI and Serial number.

show enet [all]

Displays Ethernet interface statistics maintained by the Motorola Netopia® Gateway. Supports display of individual LAN switch port statistics as well as WAN Ethernet statistics (where applicable).

Example:

```
Ethernet driver full statistics - 10/100 Ethernet

Port Status: Link up
Type: 100BASET Duplex: Full

General:
Transmit OK           : 434
```

```
Receive OK           : 267
Tx Errors            : 0
Rx Errors            : 0

Receiver:
Incompl Packet Errors : 0
No RBD's For Packet   : 0
Carrier Sense Lost    : 0
Deferred Replen       : 0

Transmitter:
TX Retries            : 0
Single Collisions     : 0
No Buf For Packet     : 0

Upper Layers:
Rx No Handler         : 0
Rx No Message         : 0
Rx Octets             : 30773
Rx Unicast Pkts      : 267
Rx Multicast Pkts    : 0
Tx Discards          : 0
Tx Octets             : 31692
```

10/100 Ethernet phy.enet.port

```
Port Status: Link up
Duplex: Full-duplex active
Speed: 100BASE-T
Transmit OK          : 434
Transmit unicastpkts : NA
Receive OK           : 267
Receive unicastpkts : 267
```

show group-mgmt

Displays the IGMP Snooping Table. See [“IP IGMP commands” on page 69](#) for detailed explanation.

show ip arp

Displays the Ethernet address resolution table stored in your Motorola Netopia® Gateway.

show ip igmp

Displays the contents of the IGMP Group Address table and the IGMP Report table maintained by your Motorola Netopia® Gateway.

show ip interfaces

Displays the IP interfaces for your Motorola Netopia® Gateway.

show ip firewall

Displays firewall statistics.

show ip lan-discovery

Displays the LAN Host Discovery Table of hosts on the wired or wireless LAN, and whether or not they are currently online.

show ip routes

Displays the IP routes stored in your Motorola Netopia® Gateway.

show ipmap

Displays IPMap table (NAT).

show log

Displays blocks of information from the Motorola Netopia® Gateway diagnostic log. To see the entire log, you can repeat the **show log** command or you can enter **show log all**.

show memory [all]

Displays memory usage information for your Motorola Netopia® Gateway. If you include the optional **all** argument, your Motorola Netopia® Gateway will display a more detailed set of memory statistics.

show pppoe

Displays status information for each PPPoE socket, such as the socket state, service names, and host ID values.

show rootcert [all | supplicant | openssl]

Dumps the Subject line for the list of all the trusted root certificates for the supplicant, which is currently a superset of the OpenSSL trusted root certificates.

This syntax is for the 802.1x-suppliant-supported builds only. The openssl trust list is used in all TLS/SSL situations *except* the 802.1X supplicant.

The default, if you don't append a qualifier, is **all**. **all** will show both 802.1x **supplicant** and **openssl** trust list root certs; **supplicant** will show the supplicant trust list root certs; **openssl** will show **openssl** trust list root certs

show rtsp

Displays RTSP ALG session activity data.

show status

Displays the current status of a Motorola Netopia® Gateway, the device's hardware and software revision levels, a summary of errors encountered, and the length of time the Motorola Netopia® Gateway has been running since it was last restarted. Identical to the **status** command.

show summary

Displays a summary of WAN, LAN, and Gateway information.

show vlan

Displays detail of VLAN status and statistics.

show wireless [all]

Shows wireless status and statistics.

show wireless clients [MAC_address]

Displays details on connected clients, or more details on a particular client if the MAC address is added as an argument.

telnet [hostname | ip_address] [port]

Lets you open a telnet connection to the specified host through your Motorola Netopia® Gateway.

- ◆ The *hostname* argument is the name of the device to which you want to connect; for example, **telnet ftp.netopia.com**.
- ◆ The *ip_address* argument is the IP address, in dotted decimal notation, of the device to which you want to connect.
- ◆ The *port* argument is the number of the port over which you want to open a telnet session.

traceroute (ip_address | hostname)

Traces the routing path to an IP destination.

upload [server_address] [filename] [confirm]

Copies the current configuration settings of the Motorola Netopia® Gateway to a TFTP (Trivial File Transfer Protocol) server. The TFTP server must be accessible on your Ethernet network. The *server_address* argument identifies the IP address of the TFTP server on which you want to store the Motorola Netopia® Gateway settings. The *filename* argument identifies the path and name of the configuration file on the TFTP server. If you include the optional **confirm** keyword, you will not be prompted to confirm whether or not you want to perform the operation.

view config

Dumps the Motorola Netopia® Gateway's configuration just as the **view** command does in config mode.

who

Displays the names of the current shell and PPP users.

WAN Commands

atmping vccn [segment | end-to-end]

Lets you check the ATM connection reachability and network connectivity. This command sends five Operations, Administration, and Maintenance (OAM) loopback calls to the specified vpi/vci destination. There is a five second total timeout interval.

Use the **segment** argument to ping a neighbor switch.
Use the **end-to-end** argument to ping a remote end node.

reset dhcp client release [vcc-id]

Releases the DHCP lease the Motorola Netopia® Gateway is currently using to acquire the IP settings for the specified DSL port. The **vcc-id** identifier is an "index" letter in the range B-I, and does not directly map to the

VCC in use. Enter the **reset dhcp client release** command without the variable to see the letter assigned to each virtual circuit.

reset dhcp client renew [vcc-id]

Renews the DHCP lease the Motorola Netopia[®] Gateway is currently using to acquire the IP settings for the specified DSL port. The **vcc-id** identifier is an “index” letter in the range B-I, and does not directly map to the VCC in use. Enter the **reset dhcp client release** without the variable to see the letter assigned to each virtual circuit.

reset dsl

Resets any open DSL connection.

reset ppp vccn

Resets the point-to-point connection over the specified virtual circuit. This command only applies to virtual circuits that use PPP framing.

show atm [all]

Displays ATM statistics for the Motorola Netopia[®] Gateway. The optional **all** argument displays a more detailed set of ATM statistics.

show dsl [all]

Displays DSL port statistics, such as upstream and downstream connection rates and noise levels.

show ppp [{ stats | lcp | ipcp }]

Displays information about open PPP links. You can display a subset of the PPP statistics by including an optional **stats**, **lcp**, or **ipcp** argument for the **show ppp** command.

start ppp vccn

Opens a PPP link on the specified virtual circuit.

About CONFIG Commands

You reach the configuration mode of the command line interface by typing **configure** (or any truncation of **configure**, such as **con** or **config**) at the CLI SHELL prompt.

CONFIG Mode Prompt

When you are in CONFIG mode, the CLI prompt consists of the name of the Motorola Netopia® Gateway followed by your current **node** in the hierarchy and two right angle brackets (>>). For example, when you enter CONFIG mode (by typing **config** at the SHELL prompt), the **Netopia-3000/9437188 (top)>>** prompt reminds you that you are at the top of the CONFIG hierarchy. If you move to the **ip** node in the CONFIG hierarchy (by typing **ip** at the CONFIG prompt), the prompt changes to **Netopia-3000/9437188 (ip)>>** to identify your current location.

Some CLI commands are not available until certain conditions are met. For example, you must enable IP for an interface before you can enter IP settings for that interface.

Navigating the CONFIG Hierarchy

- ◆ **Moving from CONFIG to SHELL** — You can navigate from anywhere in the CONFIG hierarchy back to the SHELL level by entering **quit** at the CONFIG prompt and pressing Return.


```
Netopia-3000/9437188 (top)>> quit
Netopia-3000/9437188 >
```
- ◆ **Moving from top to a subnode** — You can navigate from the top node to a subnode by entering the node name (or the significant letters of the node name) at the CONFIG prompt and pressing RETURN. For example, you move to the IP subnode by entering **ip** and pressing RETURN.


```
Netopia-3000/9437188 (top)>> ip
Netopia-3000/9437188 (ip)>>
```

As a shortcut, you can enter the significant letters of the node name in place of the full node name at the CONFIG prompt. The significant characters of a node name are the letters that uniquely identify the node. For example, since no other CONFIG node starts with **b**, you could enter one letter ("**b**") to move to the bridge node.

- ◆ **Jumping down several nodes at once** — You can jump down several levels in the CONFIG hierarchy by entering the complete path to a node.
- ◆ **Moving up one node** — You can move up through the CONFIG hierarchy one node at a time by entering the **up** command.
- ◆ **Jumping to the top node** — You can jump to the top level from anywhere in the CONFIG hierarchy by entering the **top** command.
- ◆ **Moving from one subnode to another** — You can move from one subnode to another by entering a partial path that identifies how far back to climb.
- ◆ **Moving from any subnode to any other subnode** — You can move from any subnode to any other subnode by entering a partial path that starts with a top-level CONFIG command.
- ◆ **Scrolling backward and forward through recent commands** — You can use the Up and Down arrow keys to scroll backward and forward through recent commands you have entered. When the command you want appears, press Enter to execute it.

Entering Commands in CONFIG Mode

CONFIG commands consist of keywords and arguments. Keywords in a CONFIG command specify the action you want to take or the entity on which you want to act. Arguments in a CONFIG command specify the values appropriate to your site. For example, the CONFIG command

set ip ethernet A *ip_address*

consists of two keywords (*ip*, and *ethernet A*) and one argument (*ip_address*). When you use the command to configure your Gateway, you would replace the argument with a value appropriate to your site.

For example:

```
set ip ethernet A 192.31.222.57
```

Guidelines: CONFIG Commands

The following table provides guidelines for entering and formatting CONFIG commands.

Command component	Rules for entering CONFIG commands
Command verbs	CONFIG commands must start with a command verb (set, view, delete). You can truncate CONFIG verbs to three characters (set, vie, del).
Keywords	CONFIG verbs are case-insensitive. You can enter "SET," "Set," or "set." Keywords are case-insensitive. You can enter "Ethernet," "ETHERNET," or "ethernet" as a keyword without changing its meaning. Keywords can be abbreviated to the length that they are differentiated from other keywords.
Argument Text	Text strings can be as many as 64 characters long, unless otherwise specified. In some cases they may be as long as 255 bytes. Special characters are represented using backslash notation. Text strings may be enclosed in double (") or single (') quote marks. If the text string includes an embedded space, it must be enclosed in quotes. Special characters are represented using backslash notation.
Numbers	Enter numbers as integers, or in hexadecimal, where so noted.
IP addresses	Enter IP addresses in dotted decimal notation (0 to 255).

If a command is ambiguous or miskeyed, the CLI prompts you to enter additional information. For example, you must specify which virtual circuit you are configuring when you are setting up a Motorola Netopia® Gateway.

Displaying Current Gateway Settings

You can use the **view** command to display the current CONFIG settings for your Motorola Netopia® Gateway. If you enter the **view** command at the top level of the CONFIG hierarchy, the CLI displays the settings for all enabled functions. If you enter the **view** command at an intermediate node, you see settings for that node and its subnodes.

Step Mode: A CLI Configuration Technique

The Motorola Netopia® Gateway command line interface includes a step mode to automate the process of entering configuration settings. When you use the CONFIG step mode, the command line interface prompts you for all required and optional information. You can then enter the configuration values appropriate for your site without having to enter complete CLI commands.

When you are in step mode, the command line interface prompts you to enter required and optional settings. If a setting has a default value or a current setting, the command line interface displays the default value for the command in parentheses. If a command has a limited number of acceptable values, those values are presented in brackets, with each value separated by a vertical line. For example, the following CLI step command indicates that the default value is **off** and that valid entries are limited to **on** and **off**.

```
option (off) [on | off]: on
```

You can accept the default value for a field by pressing the Return key. To use a different value, enter it and press Return.

You can enter the CONFIG step mode by entering **set** from the top node of the CONFIG hierarchy. You can enter step mode for a particular service by entering **set service_name**. In stepping set mode (press Control-X <Return/Enter> to exit. For example:

```
Netopia-3000/9437188 (top)>> set system
...
system
  name ("Netopia-3000/9437188"): Mycroft
  Diagnostic Level (High): medium
Stepping mode ended.
```

Validating Your Configuration

You can use the **validate** CONFIG command to make sure that your configuration settings have been entered correctly. If you use the **validate** command, the Motorola Netopia® Gateway verifies that all required settings for all services are present and that settings are consistent.

```
Netopia-3000/9437188 (top)>> validate
Error: Subnet mask is incorrect
Global Validation did not pass inspection!
```

You can use the **validate** command to verify your configuration settings at any time. Your Motorola Netopia® Gateway automatically validates your configuration any time you save a modified configuration.

CONFIG Commands

This section describes the keywords and arguments for the various CONFIG commands.

Connection commands

conns are used to create connections, for example, a WAN or LAN **conn**. There may be more than one of each depending on your model. **names** correspond to the system object IDs (OIDs) but you can name them yourself.

set conn name *name* **link-oid** *value*

Sets the connection named *name* to point to an associated link specified by the **link-oid** value.

set conn name *name* **type** [**static** | **dhcpc**]

Specifies whether the **type** of the connection named *name* is static or dhcpc.

set conn name *name* **side** [**lan** | **wan**]

Specifies whether this conn is LAN- or WAN-side. A **conn** can be either **lan** or **wan**.

set conn name *name* **dhcp-server-enable** [**on** | **off**]

Turns the DHCP server for this connection **on** or **off**. The DHCP server can be enabled per connection. The default is **on**.

set conn name *name* **mcast-forwarding** [**off** | **on**]

Turns IP IGMP multicast forwarding for this connection **off** or **on**. The default is **off**.

set conn name *name* **static ipaddr** *ipaddr*

Specifies a **static** IP address when the connection **type** has been set to **static**. The default is 192.168.1.254

set conn name *name* **static netmask** *netmask*

Specifies a **static** netmask when the connection **type** has been set to **static**. The default is 255.255.255.0.

set conn name *name* **dhcp-server start-addr** *ipaddr*

If **dhcp-server-enable** is set to **on**, specifies the first address in the DHCP address range. The Motorola Netopia® Gateway can reserve a sequence of up to 253 IP addresses within a subnet, beginning with the specified address for dynamic assignment. The default is 192.168.1.200

set conn name *name* **dhcp-server end-addr** *ipaddr*

If **dhcp-server-enable** is set to **on**, specifies the last address in the DHCP address range. The default is 192.168.1.240

set conn name *name* **dhcp-server lease-time** *seconds*

If **dhcp-server-enable** is set to **on**, specifies the default length for DHCP leases issued by the Motorola Netopia® Gateway. Lease time is in seconds. Default is **3600**.

set conn name *name* nat-enable [on | off]

Specifies whether you want the Motorola Netopia® Gateway to use network address translation (NAT) when communicating with remote Gateways. NAT lets you conceal details of your network from remote Gateways. It also permits all LAN devices to share a single IP address. By default, address NAT is turned **on**.

set conn name *name* dhcp-client discover-time *seconds*

The DHCP client parameters appear when the connection **type** has been set to **dhcpc**. **discover-time** is in seconds; the default is **30**.

set conn name *name* dhcp-client dns-enable [on | off]

This allows you to enable or disable the default behavior of acting as a DNS proxy. The default is **on**.

set conn name *name* dhcp-client dns-override [off | on]

This allows you to enable or disable overriding default DNS behavior. The default is **off**.

set conn name *name* dhcp-client vendor-class *string*

The **vendor-class** default information varies by model and components. This is information that identifies the unit.

IP DNS commands

set ip dns domain-name *domain_name*

Specifies the default domain name for your network. When an application needs to resolve a host name, it appends the default domain name to the host name and asks the DNS server if it has an address for the “fully qualified host name.”

set ip dns primary-address *ip_address*

Specifies the IP address of the primary DNS name server.

set ip dns secondary-address *ip_address*

Specifies the IP address of the secondary DNS name server. Enter **0.0.0.0** if your network does not have a secondary DNS name server.

set ip dns proxy-enable [on | off]

This allows you to disable the default behavior of acting as a DNS proxy. The default is **on**.

IP IGMP commands

Multicasting is a method for transmitting large amounts of information to many, but not all, computers over an internet. One common use is to distribute real time voice, video, and data services to the set of computers which have joined a distributed conference. Other uses include updating the address books of mobile computer users in the field, or sending out company newsletters to a distribution list.

Since a router should not be used as a passive forwarding device, Motorola Netopia[®] Gateways use a protocol for forwarding multicasting: Internet Group Management Protocol (IGMP).

Motorola Netopia[®] Gateways support IGMP Version 1, Version 2, or Version 3.

IGMP “Snooping” is a feature of Ethernet layer 2 switches that “listens in” on the IGMP conversation between computers and multicast routers. Through this process, it builds a database of where the multicast routers reside by noting IGMP general queries used in the querier selection process and by listening to other router protocols.

From the host point of view, the snooping function listens at a port level for an IGMP report. The switch then processes the IGMP report and starts forwarding the relevant multicast stream onto the host's port. When the switch receives an IGMP leave message, it processes the leave message, and if appropriate stops the multicast stream to that particular port. Basically, customer IGMP messages although processed by the switch are also sent to the multicast routers.

In order for IGMP snooping to function with IGMP Version 3, it must always track the full source filter state of each host on each group, as was previously done with Version 2 only when Fast Leave support was enabled.

IGMP Version 3 supports:

IGMP Source Filtering: the ability for group memberships to incorporate source address filtering. This allows “Source-Specific Multicast” (SSM). By adding source filtering, a Gateway that proxies IGMP can more selectively join the specific multicast group for which there are interested LAN multicast receivers.

These features require no user configuration on the Gateway.

You can set the following options:

- ◆ **IGMP Snooping** – enables the Motorola Netopia[®] Gateway to “listen in” to IGMP traffic. The Gateway discovers multicast group membership for the purpose of restricting multicast transmissions to only those ports which have requested them. This helps to reduce overall network traffic from streaming media and other bandwidth-intensive IP multicast applications.
- ◆ **Robustness** – a way of indicating how sensitive to lost packets the network is. IGMP can recover from robustness minus 1 lost IGMP packet. The default value is 2.
- ◆ **Query Interval**– the amount of time in seconds between IGMP General Query messages sent by the querier gateway. The default query interval is 125 seconds.
- ◆ **Query Response Interval** – the maximum amount of time in tenths of a second that the IGMP Gateway waits to receive a response to a General Query message. The default query response interval is 10 seconds and must be less than the query interval.
- ◆ **Unsolicited Report Interval** – the amount of time in seconds between repetitions of a particular computer's initial report of membership in a group. The default unsolicited report interval is 10 seconds.
- ◆ **Querier Version** – select a version of the IGMP Querier: version **1**, version **2**, or version 3. If you know you will be communicating with other hosts that are limited to v1 or v2, for backward compatibility, select accordingly; otherwise, allow the default v3.



NOTE:

IGMP Querier version is relevant only if the Gateway is configured for IGMP forwarding. If any IGMP v1 routers are present on the subnet, the querier **must** use IGMP v1. The use of IGMP v1 must be administratively configured, since there is no reliable way of dynamically determining whether IGMP

v1 routers are present on a network. IGMP forwarding is enabled per IP Profile and WAN Connection Profile.

- ◆ **Last Member Query Interval** – the amount of time in tenths of a second that the IGMP gateway waits to receive a response to a Group-Specific Query message. The last member query interval is also the amount of time in seconds between successive Group-Specific Query messages. The default last member query interval is 1 second (10 deci-seconds).
- ◆ **Last Member Query Count** – the number of Group-Specific Query messages sent before the gateway assumes that there are no members of the host group being queried on this interface. The default last member query count is 2.
- ◆ **Fast Leave** – set to **off** by default, fast leave enables a non-standard expedited leave mechanism. The querier keeps track of which client is requesting which channel by IP address. When a leave message is received, the querier can check its internal table to see if there are any more clients on this group. If there are none, it immediately sends an IGMP leave message to the upstream querier.
- ◆ **Log Enable** – If set to on, all IGMP messages on both the LAN and the WAN will be logged.
- ◆ **Wireless Multicast to Unicast conversion** – Only available if **IGMP Snooping** is enabled. If set to **on**, the Gateway replaces the multicast MAC-address with the physical MAC-address of the wireless client. If there is more than one wireless client interested in the same multicast group, the Gateway will revert to multicasting the stream immediately. When one or more wireless clients leave a group, and the Gateway determines that only a single wireless client is interested in the stream, it will once again unicast the stream.

set ip igmp querier-version [1 | 2 | 3]

Sets the IGMP querier version: version **1**, version **2**, or version **3**. If you know you will be communicating with other hosts that are limited to v1, for backward compatibility, select **1**; otherwise, allow the default **3**.

set ip igmp robustness *value*

Sets IGMP robustness range: from 2 – 255. The default is 2.

set ip igmp query-interval *value*

Sets the query-interval range: from 10 seconds – 600 seconds, The default is 125 seconds.

set ip igmp query-response-interval *value*

Sets the query-response interval range: from 5 deci-seconds (tenths of a second) – 255 deci-seconds. The default is 100 deci-seconds.

set ip igmp unsolicited-report-interval *value*

Sets the unsolicited report interval: the amount of time in seconds between repetitions of a particular computer's initial report of membership in a group. The default is 10 seconds.

set ip igmp last-member-interval *value*

Sets the last member query interval: the amount of time in tenths of a second that the IGMP gateway waits to receive a response to a Group-Specific Query message. The last member query interval is also the amount of time in seconds between successive Group-Specific Query messages. The default is 1 second (10 deci-seconds).

set ip igmp last-member-count *value*

Sets the last member query count: the number of Group-Specific Query messages sent before the gateway assumes that there are no members of the host group being queried on this interface. The default is 2.

set ip igmp snoop-entry-time *seconds*

The **snoop-entry-time** is the amount of time an entry will remain in the snooping table (in seconds) after being added. An entry is added when a "JOIN" is seen from a multicast client. Any new joins (triggered by upstream queries) will reset the timeout back to *seconds*. If no additional joins are seen, the entry will expire after *seconds*. Default is **130**.

set ip igmp snooping-unreg-mode [**block** | **flood**]

The **snooping-unreg-mode** can be set to **block** or **flood**. This indicates what should happen to unregistered multicast traffic – traffic that hasn't been subscribed to by any clients. If set to **flood**, the traffic will be sent to all LAN ports. If set to **block**, the traffic will not be sent to any LAN ports; it will be dropped. Default is **block**.

NTP commands

set ip ntp enable [**on** | **off**]

Enables or disables acquiring the time of day from an NTP (Network Time Protocol) server.

set ip ntp server-address *server_address*

set ip ntp alt-server-address *alt_server_address*

Specify the NTP server(s) to use for time updates. The NTP **server-address** and **alt-server-address** can be entered as DNS names as well as IP addresses.

set ip ntp update-period *minutes*

update-period specifies how often, in minutes, the Gateway should update the clock. Default is **60**.

IP Gateway commands

set ip gateway enable [**on** | **off**]

Specifies the **conn** of the gateway. Normally, this would be the WAN connection.

set ip gateway conn-oid **2**

set ip gateway address "0.0.0.0"

Application Layer Gateway (ALG) commands

These commands allow you to enable or disable the router's support for a variety of Application Layer Gateways (ALGs). An application layer gateway (ALG) is a NAT component that helps certain application sessions to pass cleanly through NAT. Each ALG has a slightly different function based on the particular application's protocol-specific requirements.

An internal client first establishes a connection with the ALG. The ALG determines if the connection should be allowed or not and then establishes a connection with the destination computer. All communications go through two connections – client to ALG and ALG to destination. The ALG monitors all traffic against its rules before deciding whether or not to forward it. The ALG is the only address seen by the public Internet so the internal network is concealed. In some situations, it may be desirable to disable some of the ALGs.

set ip alg ftp [on | off]

Turns the FTP (File Transfer Protocol) ALG for file transfers **on** or **off**. Default is **on**.

set ip alg h323 [on | off]

Turns the H323 ALG for audio, video, and data communications across IP-based networks **on** or **off**. Default is **on**.

set ip alg pptp [on | off]

Turns the PPTP (Point-to-Point Transfer Protocol) ALG for authentication **on** or **off**. Default is **on**.

set ip alg sip [on | off]

Turns the SIP (Session Initiation Protocol) ALG for voice communication initiation **on** or **off**. Default is **on**.

set ip alg tftp [on | off]

Turns the TFTP (Trivial File Transfer Protocol) ALG for simple file transfers and firmware updates **on** or **off**. Default is **on**.

Link commands

links represent physical connections. Currently, port-based VLAN support is provided at this level.

set link name *name* type [ethernet...]

Specifies whether the **type** of the **link** named *name* is **ethernet** or some other.

(**ethernet** is the only **type** currently. Subsequent releases will support various PPP cases.)

set link name *name* igmp-snooping [off | on]

Turns **igmp-snooping** **off** or **on** on the **link** named *name*.

set link name *name* port-vlan ports [lan | ptm | vc-1 | vc-2]

Specifies a port-based VLAN on the selected ports on the **link** named *name*.

set link name *name* port-vlan priority [0 - 7]

Specifies the 802.1p priority bit. If you set this to a value greater than 0, all packets of this VLAN with unmarked priority bits (pbits) will be re-marked to this priority.

Management commands

All management related items are grouped in this section.

set management account administrator username *username*

Specifies the **username** for the administrative user – the default is **admin**.

set management account user username *username*

Specifies the **username** for the non-administrative user – the default is **user**.

set management cwpmp enable [off | on]

Turns **cwpmp** (TR-069 CPE WAN Management Protocol) **on** or **off**. TR-069 allows a remote Auto-Config Server (ACS) to provision and manage the Motorola Netopia® Gateway. TR-069 protects sensitive data on the Gateway by not advertising its presence, and by password protection.

set management cwpmp acs-url *acs_url:port_number*

set management cwpmp acs-username *acs_username*

set management cwpmpacs-password *acs_password*

If TR-069 WAN side management services are enabled, specifies the auto-config server URL and port number. A username and password must also be supplied, if TR-069 is enabled.

The auto-config server is specified by URL and port number. The format for the ACS URL is as follows:

```
http://some_url.com:port_number
```

or

```
http://123.45.678.910:port_number
```

On units that support SSL, the format for the ACS URL can also be:

```
https://some_url.com:port_number
```

or

```
https://123.45.678.910:port_number
```

set management shell idle-timeout [1...120]

Specifies a timeout period of inactivity for telnet access to the Gateway, after which a user must re-login to the Gateway. Default is **15** minutes for telnet.

set management shell telnet-port [1 - 65534]

Specifies the port number for telnet (CLI) communication with the Motorola Netopia® Gateway. Because port numbers in the range 0-1024 are used by other protocols, you should use numbers in the range 1025-65534 when assigning new port numbers to the Motorola Netopia® Gateway telnet configuration interface. A setting of **0** (zero) will turn the server off.

set management web http-port [1 - 65534]

Specifies the port number for HTTP (web) communication with the Motorola Netopia® Gateway. Because port numbers in the range 0-1024 are used by other protocols, you should use numbers in the range 1025-65534 when assigning new port numbers to the Motorola Netopia® Gateway web configuration interface. A setting of **0** (zero) will turn the server off.

set management web idle-timeout [1...120]

Specifies a timeout period of inactivity for HTTP access to the Gateway, after which a user must re-login to the Gateway. Default is **5** minutes for HTTP.



NOTE:

You cannot specify a port setting of **0** (zero) for both the web and telnet ports at the same time. This would prevent you from accessing the Gateway.

Physical interfaces commands

set physical dsl enable [off | on]

Turns the physical DSL interface **off** or **on**. Default is **on**.

set physical dsl loopback [off | on]

Turns the DSL loopback mode **off** or **on**. Default is **off**.

set physical dsl modulation auto [off | on]

Turns automatic DSL modulation **off** or **on**. Default is **on**.

set physical dsl profile-8a [off | on]

Default is **on**.

set physical dsl profile-8b [off | on]

Default is **on**.

set physical dsl profile-8c [off | on]

Default is **on**.

set physical dsl profile-8d [off | on]

Default is **on**.

set physical dsl profile-12a [off | on]

Default is **on**.

set physical dsl profile-12b [off | on]

Default is **on**.

set physical dsl profile-17a [off | on]

Default is **on**.

set physical dsl profile-30a [off | on]

Default is **off**.

set physical dsl us0 [off | on]

Default is **on**.

set physical dsl transport [atm | ptm | auto | off]

Sets the DSL transport mode: Asynchronous (**atm**), Packet (**ptm**), Automatic (**auto**), or none (**off**). Default is **auto**.

set physical dsl atm vcc 1 enable [off | on]

Turns **atm** on or off on vcc 1. Default is **on**.

set physical dsl atm vcc 1 aal-type [aal5 | aal0pkt | aal0cell]

Sets the ATM Adaptation Layer type (**aal-type**): AAL5, AAL0-packet, or AAL0-cell. Default is **aal5**.

set physical dsl atm vcc 1 datapath [phy0fast | phy0interleaved]

Sets the ATM datapath, Fast Path or Interleaved. Default is **phy0fast**.

set physical dsl atm vcc 1 encap-type [llcsnap-eth | llcsnap-rtip | llcencaps-ppp | vcmux-eth | vcmux-ipoa | vcmux-pppoa]

Specifies the data link encapsulation type. Default is **llcsnap-eth**.

set physical dsl atm vcc 1 vpi [0 - 255]

Sets the Virtual Path Identifier (**vpi**) for the circuit. Default is **0**.

set physical dsl atm vcc 1 vci [32 - 65535]

Sets the Virtual Channel Identifier (**vci**) for the circuit. Default is **35**.

set physical dsl atm vcc 2 enable [off | on]

Turns **atm** on or off on vcc 2. Default is **on**.

set physical dsl atm vcc 2 aal-type [aal5 | aal0pkt | aal0cell]

Sets the ATM Adaptation Layer type (**aal-type**): AAL5, AAL0-packet, or AAL0-cell. Default is **aal5**.

set physical dsl atm vcc 2 datapath [phy0fast | phy0interleaved]

Sets the ATM datapath, Fast Path or Interleaved. Default is **phy0fast**.

set physical dsl atm vcc 2 encap-type [llcsnap-eth | llcsnap-rtip | llcencaps-ppp | vcmux-eth | vcmux-ipoa | vcmux-pppoa]

Specifies the data link encapsulation type. Default is **llcsnap-eth**.

set physical dsl atm vcc 2 vpi [0 - 255]

Sets the Virtual Path Identifier (**vpi**) for the circuit. Default is **8**.

set physical dsl atm vcc 2 vci [32 - 65535]

Sets the Virtual Channel Identifier (**vci**) for the circuit. Default is **35**.

set physical dsl ptm datapath [phy0fast | phy0interleaved]

Sets the ATM datapath, Fast Path or Interleaved. Default is **phy0fast**.

set physical dsl ptm priority [low | high]

Sets the Packet Transfer Mode (**ptm**) priority. Default is **low**.

set physical enet 1 mac-addr-override *mac_addr*

You can override your Gateway's Ethernet MAC address with any necessary setting. Some ISPs require your account to be identified by the MAC address, among other things. Enter your 12-character Ethernet MAC override address as instructed by your service provider, for example: 12 34 AB CD 19 64

set physical enet 1 port media [auto | 100-fd | 100-hd | 10-fd | 10-hd]

Sets the Ethernet port's media flow control: Automatic, 100 Mbps Full-Duplex, 100 Mbps Half-Duplex, 10 Mbps Full-Duplex, or 10 Mbps Half-Duplex. Default is **auto**.

set physical enet 1 port mdix [auto | on | off]

Sets the Ethernet port's crossover detection. Default is **off**.

PPPoE relay commands

set pppoe-relay enable [on | off]

Allows the Gateway to forward PPPoE packets. Default is **on**.

set pppoe-relay max-sessions [0... 4]

Specifies the maximum number of PPPoE relay sessions. Default is **4**.

NAT Pinhole commands

NAT pinholes let you pass specific types of network traffic through the NAT interfaces on the Motorola Netopia® Gateway. NAT pinholes allow you to route selected types of network traffic, such as FTP requests or HTTP (Web) connections, to a specific host behind the Motorola Netopia® Gateway transparently.

To set up NAT pinholes, you identify the type(s) of traffic you want to redirect by port number, and you specify the internal host to which each specified type of traffic should be directed.

The following list identifies protocol type and port number for common TCP/IP protocols:

- ◆ FTP (TCP 21)
- ◆ telnet (TCP 23)
- ◆ SMTP (TCP 25),
- ◆ TFTP (UDP 69)

set pinhole name *name* protocol [tcp | udp]

Specifies the identifier for the entry in the Gateway's pinhole table. You can name pinhole table entries sequentially (1, 2, 3), by port number (21, 80, 23), by protocol, or by some other naming scheme. Specifies the type of protocol being redirected.

set pinhole name *name* ext-port-range [0 - 49151]

Specifies the first and last port number in the range being translated.

set pinhole name *name* int-addr *ipaddr*

Specifies the IP address of the internal host to which traffic of the specified type should be transferred.

set pinhole name *name* int-start-port [0 - 65535]

Specifies the port number your Motorola Netopia® Gateway should use when forwarding traffic of the specified type. Under most circumstances, you would use the same number for the external and internal port.

System commands

set system name *name*

Specifies the name of your Motorola Netopia® Gateway. Each Motorola Netopia® Gateway is assigned a name as part of its factory initialization. The default name for a Motorola Netopia® Gateway consists of the word “Netopia-7000/XXX” where “XXX” is the serial number of the device; for example, Netopia-7000/9437188. A system name can be 1 – 255 characters long. Once you have assigned a name to your Motorola Netopia® Gateway, you can enter that name in the Address text field of your browser to open a connection to your Motorola Netopia® Gateway.

**NOTE:**

Some broadband cable-oriented Service Providers use the **System Name** as an important identification and support parameter. If your Gateway is part of this type of network, do **NOT** alter the System Name unless specifically instructed by your Service Provider.

set system time-zone [UTC | HST10 | AKST9AKDT | YST8 | PST8PDT | MST7MDT | MST7 | CST6CDT | CST6 | EST5EDT | AST4ADT | NST3:30NDT]

time-zone of 0 is Coordinated Universal Time (UTC); options are -12 through 12 (+/- 1 hour increments from UTC time).

set system auto-daylight-savings [on | off]

Time zones honoring Daylight Saving Time may be automatically designated.

set system firewall-log enable [on | off]

Turns firewall logging on or off. The firewall log tracks attempted violations of the firewall rules. Default is **on**.

set system firewall-log file-size [4096... 65536]

Specifies a size for the firewall logs. The most recent entries are posted to the beginning of the log. When the log becomes full, the oldest entries are dropped. The default is 16384.

set system firewall-log file-count [2... 8]

Specifies the number of possible log files. The default is 4.

set system log buffer-size [4096... 65536]

Specifies a size for the system log. The most recent entries are posted to the beginning of the log. When the log becomes full, the oldest entries are dropped. The default is 16384.

set system log level [low | medium | high | alerts | failures]

Specifies the types of log messages you want the Motorola Netopia® Gateway to record. All messages with a level equal to or greater than the level you specify are recorded. For example, if you specify set system diagnostic-level **medium**, the diagnostic log will retain medium-level informational messages, alerts, and failure messages.

Use the following guidelines:

- ◆ **low** - Low-level informational messages or greater; includes trivial status messages.

-
- ◆ **medium** - Medium-level informational messages or greater; includes status messages that can help monitor network traffic.
 - ◆ **high** - High-level informational messages or greater; includes status messages that may be significant but do not constitute errors. The default.
 - ◆ **alerts** - Warnings or greater; includes recoverable error conditions and useful operator information.
 - ◆ **failures** - Failures; includes messages describing error conditions that may not be recoverable.

CHAPTER 5 Technical Specifications and Safety Information

Description

Communications interfaces: The Motorola Nteopia® Gateways have an RJ-11 jack for DSL line connections or an RJ-45 jack for cable/DSL modem connections and 1 or 4-port 10/100Base-T Ethernet switch for your LAN connections. Some models contain an 802.11b/g/n wireless LAN transmitter.

Power requirements

12V,1.5A

Environment

Operating temperature: 0° to +40° C

Storage temperature: 0° to +70° C

Relative storage humidity: 20 to 80% noncondensing

Software and protocols

Software media: Software preloaded on internal flash memory; field upgrades done via download to internal flash memory via TFTP or web upload.

Routing: TCP/IP Internet Protocol Suite, RIP

WAN support: PPPoE, DHCP, static IP address

Security: PAP, CHAP, UI password security, IPsec, Secure Sockets Layer (SSL) certificate (supported models)

Management/configuration methods: HTTP (Web server), Telnet, SNMP, TR-069 DSL Forum CPE WAN Management Protocol

Diagnostics: Ping, event logging, routing table displays, statistics counters, web-based management, traceroute, nslookup, and diagnostic commands.

Agency approvals

North America

Safety Approvals:

United States – UL 60950, Third Edition

- ◆ Canada – CSA: CAN/CSA-C22.2 No. 60950-00
- ◆ EMC:
- ◆ United States – FCC Part 15 Class B
- ◆ Canada – ICES-003

Telecom:

- ◆ United States – 47 CFR Part 68
- ◆ Canada – CS-03

International

Safety Approvals:

- ◆ Low Voltage (European directive) 73/23
- ◆ EN 60950-1 (Europe)

EMI Compatibility:

- ◆ 89/336/EEC (European directive)
- ◆ EN55022:1994 CISPR22 Class B
- ◆ EN300 386 V1.2.1 (non-wireless products)
- ◆ EN 301-489 (wireless products)

Regulatory notices

European Community. This Motorola product conforms to the European Community CE Mark standard for the design and manufacturing of information technology equipment. This standard covers a broad area of product design, including RF emissions and immunity from electrical disturbances.

The Motorola Netopia[®] Gateway complies with the following EU directives:

- ◆ Low Voltage, 73/23/EEC
- ◆ EMC Compatibility, 89/336/EEC, conforming to EN 55 022



This Motorola product is in conformity with the essential requirements and other relevant requirements of the Radio Equipment and Telecommunications Terminal Equipment Directive (R&TTE) 1999/5/EC, following the provision of the Electromagnetic Compatibility Directive (EMC) No. 89/336/EEC and Low Voltage Directive (LVD) No. 73/23/EEC.

The product is compliant with the following standards and other normative documents:

LEMC – Emissions and Immunity: EN 301 489-1 V1.2.1 (2002-08), EN 301 489-17 (2002-08), EN 55022 Class B (1998)

EMC – Radio Data Transmission: EN 300 328 V1.4.1 (2003-04)

EMC - Resistibility: ITU-T K.21 (1996)

LVD - Safety: EN 60950 (2000) + A1 + A2 + A3 + A4 + A11

Manufacturer's Declaration of Conformance



Warnings:

This is a Class B product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures. Adequate measures include increasing the physical distance between this product and other electrical devices.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

United States. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ◆ Reorient or relocate the receiving antenna.
- ◆ Increase the separation between the equipment and receiver.
- ◆ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ◆ Consult the dealer or an experienced radio TV technician for help.

Service requirements. In the event of equipment malfunction, if under warranty we will exchange a product deemed defective.

Under FCC rules, no customer is authorized to repair this equipment. This restriction applies regardless of whether the equipment is in or out of warranty. It is the responsibility of users requiring service to report the need for service to our Company or to one of our authorized agents.

Contact Us for US

Technical Support for Hardware Products

1-877-466-8646

<http://broadband.motorola.com/consumers/support/default.asp?supportSection=blank>



Important

This product was tested for FCC compliance under conditions that included the use of shielded cables and connectors between system components. Changes or modifications to this product not authorized by the manufacturer could void your authority to operate the equipment.

Canada. This Class B digital apparatus meets all requirements of the Canadian Interference -Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Declaration for Canadian users

NOTICE: The Canadian Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operation, and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to the certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution

Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

The Ringer Equivalence Number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

Important Safety Instructions

Australian Safety Information

The following safety information is provided in conformance with Australian safety requirements:

Caution

DO NOT USE BEFORE READING THE INSTRUCTIONS: Do not connect the Ethernet ports to a carrier or carriage service provider's telecommunications network or facility unless: a) you have the written consent of the network or facility manager, or b) the connection is in accordance with a connection permit or connection rules.

Connection of the Ethernet ports may cause a hazard or damage to the telecommunication network or facility, or persons, with consequential liability for substantial compensation.

Caution

- ◆ The direct plug-in power supply serves as the main power disconnect; locate the direct plug-in power supply near the product for easy access.
- ◆ For use only with CSA Certified Class 2 power supply, rated 12VDC.

Telecommunication installation cautions

- ◆ Never install telephone wiring during a lightning storm.
- ◆ Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- ◆ Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- ◆ Use caution when installing or modifying telephone lines.
- ◆ Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- ◆ Do not use the telephone to report a gas leak in the vicinity of the leak.

47 CFR Part 68 Information

FCC Requirements

1. The Federal Communications Commission (FCC) has established Rules which permit this device to be directly connected to the telephone network. Standardized jacks are used for these connections. This equipment should not be used on party lines or coin phones.
2. If this device is malfunctioning, it may also be causing harm to the telephone network; this device should be disconnected until the source of the problem can be determined and until repair has been made. If this is not done, the telephone company may temporarily disconnect service.
3. The telephone company may make changes in its technical operations and procedures; if such changes affect the compatibility or use of this device, the telephone company is required to give adequate notice of the changes. You will be advised of your right to file a complaint with the FCC.
4. If the telephone company requests information on what equipment is connected to their lines, inform them of:
 - a. The telephone number to which this unit is connected.
 - b. The ringer equivalence number. [0.XB]
 - c. The USOC jack required. [RJ11C]
 - d. The FCC Registration Number. [XXXUSA-XXXXX-XX-E]

Items (b) and (d) are indicated on the label. The Ringer Equivalence Number (REN) is used to determine how many devices can be connected to your telephone line. In most areas, the sum of the REN's of all devices on any one line should not exceed five (5.0). If too many devices are attached, they may not ring properly.

FCC Statements

a) This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to the telephone company.

b) List all applicable certification jack Universal Service Order Codes ("USOC") for the equipment: RJ11.

c) A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

d) The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. For products approved after July 23, 2002, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

e) If this equipment, the Motorola Netopia[®] Modem or Gateway, causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

f) The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

g) If trouble is experienced with this equipment, the Motorola Netopia[®] Gateway, for warranty information, please contact:

Technical Support for Hardware Products
1-877-466-8646

<http://broadband.motorola.com/consumers/support/default.asp?supportSection=blank>

If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

h) This equipment not intended to be repaired by the end user. In case of any problems, please refer to the troubleshooting section of the Product User Manual before calling Motorola Technical Support.

i) Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

j) If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this Motorola Netopia[®] Gateway does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or qualified installer.

RF Exposure Statement:

NOTE: Installation of the wireless models must maintain at least 20 cm between the wireless Gateway and any body part of the user to be in compliance with FCC RF exposure guidelines.

PRODUCT VENTILATION

The Motorola Netopia[®] Gateway is intended for use in a consumer's home. Ambient temperatures around this product should not exceed 104°F (40°C). It should not be used in locations exposed to outside heat radiation or trapping of its own heat. The product should have at least one inch of clearance on all sides except the bottom when properly installed and should not be placed inside tightly enclosed spaces unless proper ventilation is provided.

Electrical Safety Advisory

Telephone companies report that electrical surges, typically lightning transients, are very destructive to customer terminal equipment connected to AC power sources. This has been identified as a major nationwide problem. Therefore it is advised that this equipment be connected to AC power through the use of a surge arrester or similar protection device.

Warranty Information

Software License, Limited Warranty and Limitation of Remedies

Motorola, Inc., Broadband Communications Sector ("Motorola")
101 Tournament Drive, Horsham, PA 19044

IMPORTANT: PLEASE READ THIS SOFTWARE LICENSE ("LICENSE") CAREFULLY BEFORE YOU INSTALL, DOWNLOAD OR USE ANY APPLICATION SOFTWARE, USB DRIVER SOFTWARE, FIRMWARE AND RELATED DOCUMENTATION ("SOFTWARE") PROVIDED WITH MOTOROLA'S DATA PRODUCT (THE "PRODUCT"). BY USING THE PRODUCT AND/OR INSTALLING, DOWNLOADING OR USING ANY OF THE SOFTWARE, YOU INDICATE YOUR ACCEPTANCE OF EACH OF THE TERMS OF THIS LICENSE. UPON ACCEPTANCE, THIS LICENSE WILL BE A LEGALLY BINDING AGREEMENT BETWEEN YOU AND MOTOROLA. THE TERMS OF THIS LICENSE APPLY TO YOU AND TO ANY SUBSEQUENT USER OF THIS SOFTWARE.

IF YOU DO NOT AGREE TO ALL OF THE TERMS OF THIS LICENSE (I) DO NOT INSTALL OR USE THE SOFTWARE AND (II) RETURN THE PRODUCT AND THE SOFTWARE (COLLECTIVELY, "PRODUCT"), INCLUDING ALL COMPONENTS, DOCUMENTATION AND ANY OTHER MATERIALS PROVIDED WITH THE PRODUCT, TO YOUR SERVICE PROVIDER.

The Software includes associated media, any printed materials, and any "on-line" or electronic documentation. Software provided by third parties may be subject to separate end-user license agreements from the manufacturers of such Software. This License shall also apply to any updates, bug fixes, or newer versions of the software provided by Motorola for use with this product.

The Software is never sold. Motorola licenses the Software to the original customer and to any subsequent licensee for personal use only on the terms of this License. Motorola and its 3rd party licensors retain the ownership of the Software.

Software License

You may:

USE the Software only in connection with the operation of the Product.

TRANSFER the Software (including all component parts and printed materials) permanently to another person, but only if the person agrees to accept all of the terms of this License. If you transfer the Software, you must at the same time transfer the Product and all copies of the Software (if applicable) to the same person or destroy any copies not transferred.

TERMINATE this License by destroying the original and all copies of the Software (if applicable) in whatever form.

You may not:

(1) Loan, distribute, rent, lease, give, sublicense or otherwise transfer the Software, in whole or in part, to any other person, except as permitted under the TRANSFER paragraph above. (2) Copy or translate the User Guide included with the Software, other than for personal use. (3) Copy, alter, translate, decompile, disassemble or reverse engineer the Software, including but not limited to, modifying the Software to make it operate on non-compatible hardware. (4) Remove, alter or cause not to be displayed, any copyright notices or startup message contained in the Software programs or documentation. (5) Export the Software or the Product components in violation of any United States export laws.

The Product is not designed or intended for use in on-line control of aircraft, air traffic, aircraft navigation or aircraft communications; or in design, construction, operation or maintenance of any nuclear facility. MOTOROLA AND ITS 3RD PARTY LICENSORS DISCLAIM ANY EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR SUCH USES. YOU REPRESENT AND WARRANT THAT YOU SHALL NOT USE THE PRODUCT FOR SUCH PURPOSES. Title to this Software, including the ownership of all copyrights, mask work rights, patents, trademarks and all other intellectual property rights subsisting in the foregoing, and all adaptations to and modifications of the foregoing shall at all times remain with Motorola and its 3rd party licensors. Motorola retains all rights not

expressly licensed under this License. The Software, including any images, graphics, photographs, animation, video, audio, music and text incorporated therein is owned by Motorola or its 3rd party licensors and is protected by United States copyright laws and international treaty provisions. Except as otherwise expressly provided in this License, the copying, reproduction, distribution or preparation of derivative works of the Software, any portion of the Product or the documentation is strictly prohibited by such laws and treaty provisions. Nothing in this License constitutes a waiver of Motorola's rights under United States copyright law.

This License and your rights regarding any matter it addresses are governed by the laws of the Commonwealth of Pennsylvania, without reference to conflict of laws principles. THIS LICENSE SHALL TERMINATE AUTOMATICALLY if you fail to comply with the terms of this License.

Motorola is not responsible for any third party software provided as a bundled application, or otherwise, with the Software.

U.S. GOVERNMENT RESTRICTED RIGHTS

The Product and documentation is provided with RESTRICTED RIGHTS. The use, duplication or disclosure by the Government is subject to restrictions as set forth in subdivision (c)(1)(ii) of The Rights in Technical Data and Computer Software clause at 52.227-7013. The contractor/ manufacturer is Motorola, Inc., Broadband Communications Sector, 101 Tournament Drive, Horsham, PA 19044.

Warranty Information

Retail Purchasers. If you purchased this Product directly from Motorola or from an authorized Motorola retail reseller, Motorola warrants to you, the original end user customer, that (A) the Product, excluding Software, will be free from defects in materials and workmanship under normal use, and (B) with respect to Software, (i) the media on which the Software is provided will be free from defects in material and workmanship under normal use, and (ii) the Software will perform substantially as described in its documentation. This Limited Warranty to you, the original end user customer, continues (A) for Software and the media upon which it is provided, for a period of ninety (90) days from the date of purchase from Motorola or an authorized Motorola reseller, and (B) for the Product (excluding Software), for a period of one (1) year from the date of purchase from Motorola or from an authorized Motorola reseller. To take advantage of this Limited Warranty or to obtain technical support, you must call the Motorola support phone number (below). Motorola's sole and exclusive obligation under this Limited Warranty for retail sales shall be to repair or replace any Product or Software that does not meet this Limited Warranty. All warranty claims must be made within the applicable Warranty Period.

Cable Operator or Service Provider Arrangements. If you did not purchase this Product directly from Motorola or from a Motorola authorized retail reseller, Motorola does not warrant this Product to you, the end-user. A limited warranty for this Product (including Software) may have been provided to your cable operator or Internet Service Provider ("Service Provider") from whom you obtained the Product. Please contact your Service Provider if you experience problems with this Product.

General Information. The warranties described in this Section shall not apply: (i) to any Product subjected to accident, misuse, neglect, alteration, Acts of God, improper handling, improper transport, improper storage, improper use or application, improper installation, improper testing or unauthorized repair; or (ii) to cosmetic problems or defects which result from normal wear and tear under ordinary use, and do not affect the performance or use of the Product. Motorola's warranties apply only to a Product that is manufactured by Motorola and identified by Motorola owned trademark, trade name or product identification logos affixed to the Product. Motorola does not warrant to you, the end user, or to anyone else that the Software will perform error free or without bugs. MOTOROLA IS NOT RESPONSIBLE FOR, AND PROVIDES "AS IS" ANY SOFTWARE SUPPLIED BY 3RD PARTIES. EXCEPT AS EXPRESSLY STATED IN THIS SECTION ("WARRANTY INFORMATION"), THERE ARE NO WARRANTIES OF ANY KIND RELATING TO THE PRODUCT, EXPRESS, IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR THE WARRANTY AGAINST INFRINGEMENT PROVIDED IN THE UNIFORM COMMERCIAL CODE. Some states do not allow for the exclusion of implied warranties, so the above exclusion may not apply to you.

What additional provisions should I be aware of? Because it is impossible for Motorola to know the purposes for which you acquired this Product or the uses to which you will put this Product, you assume full responsibility for the selection of the Product for its installation and use. While every reasonable effort has been made to insure that you will receive a Product that you can use and enjoy, Motorola does not warrant that the functions of the Product will meet your requirements or that the operation of the Product will be uninterrupted or error-free. MOTOROLA IS NOT RESPONSIBLE FOR PROBLEMS OR DAMAGE CAUSED BY THE INTERACTION OF THE PRODUCT

WITH ANY OTHER SOFTWARE OR HARDWARE. ALL WARRANTIES ARE VOID IF THE PRODUCT IS OPENED, ALTERED, AND/OR DAMAGED.

THESE ARE YOUR SOLE AND EXCLUSIVE REMEDIES for any and all claims that you may have arising out of or in connection with this Product, whether made or suffered by you or another person and whether based in contract or tort.

IN NO EVENT SHALL MOTOROLA BE LIABLE TO YOU OR ANY OTHER PARTY FOR ANY DIRECT, INDIRECT, GENERAL, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR OTHER DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF INFORMATION OR ANY OTHER PECUNIARY LOSS), OR FROM ANY BREACH OF WARRANTY, EVEN IF MOTOROLA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO CASE SHALL MOTOROLA'S LIABILITY EXCEED THE AMOUNT YOU PAID FOR THE PRODUCT.

These matters are governed by the laws of the Commonwealth of Pennsylvania, without regard to conflict of laws principles and excluding the provisions of the United Nations Convention on Contracts for the International Sale of Goods.

Retail Purchasers Only. If you purchased this Product directly from Motorola or from a Motorola authorized retail reseller, please call the Motorola support number, 1-877-466-8646 for technical support or warranty service.

Cable Operator or Service Provider Arrangements. If you did not purchase this Product directly from Motorola or from a Motorola authorized retail reseller, please contact your Service Provider for technical support.

MOTOROLA, Intelligence Everywhere, and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. All rights reserved. No part of the contents of this document may be reproduced or transmitted in any form or by any means without the written permission of the publisher. © Motorola, Inc. 2009.

Copyright Acknowledgments

Because Motorola has included certain software source code in this product, Motorola includes the following text required by the respective copyright holders:

Portions of this software are based in part on the work of the following:

Copyright (c) 1998-2005 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment:

"This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit.
(<http://www.openssl.org/>)"

4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.
5. Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.
6. Redistributions of any form whatsoever must retain the following acknowledgment:

"This product includes software developed by the OpenSSL Project
for use in the OpenSSL Toolkit (<http://www.openssl.org/>)"

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com).

This product includes software written by Tim Hudson (tjh@cryptsoft.com).

Original SSLeay License

/Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com)

All rights reserved.

This package is an SSL implementation written by Eric Young (eay@cryptsoft.com).

The implementation was written so as to conform with Netscape's SSL.

This library is free for commercial and non-commercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed. If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement:

"This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)"

The word 'cryptographic' can be left out if the routines from the library being used are not cryptographic related :-).

4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement:

"This product includes software written by Tim Hudson (tjh@cryptsoft.com)"

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The licence and distribution terms for any publicly available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution licence [including the GNU Public Licence.]

Portions of this software are based in part on the work of the following:

Copyright (C) 1995, 1996, 1997, and 1998 WIDE Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

3. Neither the name of the project nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE PROJECT AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE PROJECT OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions of this software are based in part on the work of the following:

Copyright (C) 1990, RSA Data Security, Inc. All rights reserved.

<<RSA Data Security, Inc. MD5 Message-Digest Algorithm>>

License to copy and use this software is granted provided that it is identified as the "RSA Data Security, Inc. MD5 Message Digest Algorithm" in all material mentioning or referencing this software or this function.

License is also granted to make and use derivative works provided that such works are identified as "derived from the RSA Data Security, Inc. MD5 Message-Digest Algorithm" in all material mentioning or referencing the derived work.

<<RSA Data Security, Inc. MD4 Message-Digest Algorithm>>

License to copy and use this software is granted provided that it is identified as the "RSA Data Security, Inc. MD4 Message Digest Algorithm" in all material mentioning or referencing this software or this function.

License is also granted to make and use derivative works provided that such works are identified as "derived from the RSA Data Security, Inc. MD4 Message-Digest Algorithm" in all material mentioning or referencing the derived work.

RSA Data Security, Inc. makes no representations concerning either the merchantability of this software or the suitability of this software for any particular purpose. It is provided "as is" without express or implied warranty of any kind.

These notices must be retained in any copies of any part of this documentation and/or software.

Portions of this software are based in part on the work of the following:

Copyright (c) 1989 Carnegie Mellon University. All rights reserved.

Redistribution and use in source and binary forms are permitted provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that the software was developed by Carnegie Mellon University. The name of the University may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED ``AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Portions of this software are based in part on the work of the following:

Copyright 2000, 2001 Shane Kerr. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR(S) ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions of this software are based in part on the work of the following:

SHA-1 in C

By Steve Reid steve@ednweb.com

100% Public Domain

Portions of this software are based in part on the work of the following:

Broadcom Common Firmware Environment (CFE)

BSP Configuration file File: `bsp_config.h`

This module contains global parameters and conditional compilation settings for building CFE.

Author: Mitch Lichtenberg (mpl@broadcom.com)

Copyright 2000,2001

Broadcom Corporation. All rights reserved.

This software is furnished under license and may be used and copied only in accordance with the following terms and conditions. Subject to these conditions, you may download, copy, install, use, modify and distribute modified or unmodified copies of this software in source and/or binary form. No title or ownership is transferred hereby.

1) Any source code used, modified or distributed must reproduce and retain this copyright notice and list of conditions as they appear in the source file.

2) No right is granted to use any trade name, trademark, or logo of Broadcom Corporation. Neither the "Broadcom Corporation" name nor any trademark or logo of Broadcom Corporation may be used to endorse or promote products derived from this software without the prior written permission of Broadcom Corporation.

3) THIS SOFTWARE IS PROVIDED "AS-IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT ARE DISCLAIMED. IN NO EVENT SHALL BROADCOM BE LIABLE FOR ANY DAMAGES WHATSOEVER, AND IN PARTICULAR, BROADCOM SHALL NOT BE LIABLE FOR DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE), EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions of this software are based in part on the work of the following:

LZMA SDK 4.22 Copyright (C) 1999-2005 Igor Pavlov

LZMA SDK provides developers with documentation, source code, and sample code necessary to write software that uses LZMA compression.

LICENSE

LZMA SDK is licensed under two licenses:

- 1) GNU Lesser General Public License (GNU LGPL)
- 2) Common Public License (CPL)

It means that you can select one of these two licenses and follow rules of that license.

SPECIAL EXCEPTION

Igor Pavlov, as the author of this code, expressly permits you to statically or dynamically link your code (or bind by name) to the files from LZMA SDK without subjecting your linked code to the terms of the CPL or GNU LGPL.

Any modifications or additions to files from LZMA SDK, however, are subject to the GNU LGPL or CPL terms.

SPECIAL EXCEPTION allows you to use LZMA SDK in applications with closed code, while you keep LZMA SDK code unmodified.

SPECIAL EXCEPTION #2: Igor Pavlov, as the author of this code, expressly permits you to use this code under the same terms and conditions contained in the License Agreement you have for any previous version of LZMA SDK developed by Igor Pavlov.

SPECIAL EXCEPTION #2 allows owners of proprietary licenses to use latest version of LZMA SDK as update for previous versions.

SPECIAL EXCEPTION #3: Igor Pavlov, as the author of this code, expressly permits you to use code of examples (LzmaTest.c, LzmaStateTest.c, LzmaAlone.cpp) as public domain code.

GNU LGPL and CPL licenses are pretty similar and both these licenses are classified as

- 1) "Free software licenses" at <http://www.gnu.org/>
- 2) "OSI-approved" at <http://www.opensource.org/>

LZMA SDK also can be available under a proprietary license which can include:

- 1) Right to modify code without subjecting modified code to the terms of the CPL or GNU LGPL
- 2) Technical support for code

To request such proprietary license or any additional consultations, send email message from that page:

<http://www.7-zip.org/support.html>

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

You should have received a copy of the Common Public License along with this library.

Portions of this software are based in part on the work of the following:

The deflate format used by zlib was defined by Phil Katz. The deflate and zlib specifications were written by L. Peter Deutsch. Thanks to all the people who reported problems and suggested various improvements in zlib; they are too numerous to cite here.

Copyright notice: (C) 1995-2004 Jean-loup Gailly and Mark Adler

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
3. This notice may not be removed or altered from any source distribution.

Portions of this software are based in part on the work of the following:

A program and library for data compression by Julian Seward

<http://www.bzip.org>

Version 1.0.5 of 10 December 2007

Copyright © 1996-2007 Julian Seward

This program, bzip2, the associated library libbzip2, and all documentation, are copyright © 1996-2007 Julian Seward. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.

Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions of this software are based in part on the work of the following:

hostapd - user space IEEE 802.11 AP and IEEE 802.1X/WPA/WPA2 Authenticator

=====

Copyright (c) 2002-2004, Jouni Malinen <jkmaline@cc.hut.fi> and contributors. All Rights Reserved.

This program is dual-licensed under both the GPL version 2 and BSD license. Either license may be used at your option. Please note that some of the driver interface implementations (driver_*.c) may be licensed under a different license.

License

GPL v2:

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License version 2 as published by the Free Software Foundation.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA (this copy of the license is in COPYING file).

Alternatively, this software may be distributed under the terms of BSD license:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name(s) of the above-listed copyright holder(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions of this software are based in part on the work of the following:

BSD License

Regents of the University of California

University of California, Berkeley

1998

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the University of California, Berkeley nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions of this software are based in part on the work of the following:

Memtest

Filename: memtest.c

Description: General-purpose memory testing functions.

Notes: Some of the constants in this file are specific to Arcom's Target188EB hardware. This software can be easily ported to systems with different data bus widths by redefining 'datum';

Copyright (c) 1998 by Michael Barr. This software is placed into the public domain and may be used for any purpose. However, this notice must not be changed or removed and no warranty is either expressed or implied by its publication or distribution.

Portions of this software are based in part on the work of the following:

NIST Secure Hash Algorithm
heavily modified by Uwe Hollerbach <uh@alumni.caltech.edu>
from Peter C. Gutmann's implementation as found in
Applied Cryptography by Bruce Schneier

Portions of this software are based in part on the work of the following:

LGPL 2.1

GNU LESSER GENERAL PUBLIC LICENSE

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor,
Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document,
but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others. Finally, software patents pose a constant threat to the existence of any free program.

We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library. The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables. The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library. You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) The modified work must itself be a software library.

b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.

c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.

d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful. (For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy. This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange. If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License. However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables. When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law. If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications. You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy. For an executable, the required form of the "work that uses the "Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable. It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library. If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Portions of this software are based in part on the work of the following:

Copyright (c) 2002 Johnny Shelley jshelley@cahaus.com All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the author nor any contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions of this software are based in part on the work of the following:

ASN.1 object dumping code, copyright Peter Gutmann <pgut001@cs.auckland.ac.nz>, based on ASN.1 dump program by David Kemp <dpkemp@missi.ncsc.mil>, with contributions from various people including Matthew Hamrick <hamrick@rsa.com>, Bruno Couillard <bcouillard@chrysalis-its.com>, Hallvard Furuseth <h.b.furuseth@usit.uio.no>, Geoff Thorpe <geoff@raas.co.nz>, David Boyce <d.boyce@isode.com>, John Hughes <john.hughes@entegrity.com>, Life is hard, and then you die <ronald@trustpoint.com>, Hans-Olof Hermansson <hans-olof.hermansson@postnet.se>, Tor Rustad <Tor.Rustad@bbs.no>, Kjetil Barvik <kjetil.barvik@bbs.no>, James Sweeny <jsweeny@us.ibm.com>, Chris Ridd <chris.ridd@isode.com>, and several other people whose names I've misplaced (a number of those email addresses probably no longer work, since this code has been around for awhile).

Portions of this software are based in part on the work of the following:

The deflate format used by zlib was defined by Phil Katz. The deflate and zlib specifications were written by L. Peter Deutsch. Thanks to all the people who reported problems and suggested various improvements in zlib; they are too numerous to cite here. Copyright notice: (C) 1995-2004 Jean-loup Gailly and Mark Adler

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
3. This notice may not be removed or altered from any source distribution.

Jean-loup Gailly Mark Adler

jloup@gzip.org madler@alumni.caltech.edu

If you use the zlib library in a product, we would appreciate *not* receiving lengthy legal documents to sign. The sources are provided for free but without warranty of any kind. The library has been entirely written by Jean-loup Gailly and Mark Adler; it does not include third-party code. If you redistribute modified sources, we would appreciate that you include in the file ChangeLog history information documenting your changes. Please read the FAQ for more information on the distribution of modified source versions.

Portions of this software are based in part on the work of the following:

CMU Mach Kernel License

Copyright 1988, 1989 by Carnegie Mellon University

All Rights Reserved

Permission to use, copy, modify, and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appear in all copies and that both that copyright notice and this permission notice appear in supporting documentation, and that the name of CMU not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission.

CMU DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS, IN NO EVENT SHALL CMU BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Portions of this software are based in part on the work of the following:

Expat XML Parser License

For the expat xml parser component:

Copyright (c) 1998, 1999, 2000 Thai Open Source Software Center Ltd. and Clark Cooper

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software. THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Portions of this software are based in part on the work of the following:

Net SNMP License

<http://net-snmp.sourceforge.net/about/license.html>

Various copyrights apply to this package, listed in various separate parts below. Please make sure that you read all the parts. Up until 2001, the project was based at UC Davis, and the first part covers all code written during this time. From 2001 onwards, the project has been based at SourceForge, and Networks Associates Technology, Inc. hold the copyright on behalf of the wider Net-SNMP community, covering all derivative work done since then. An additional copyright section has been added as Part 3 below also under a BSD license for the work contributed by Cambridge Broadband Ltd. to the project since 2001.

An additional copyright section has been added as Part 4 below also under a BSD license for the work contributed by Sun Microsystems, Inc. to the project since 2003.

Code has been contributed to this project by many people over the years it has been in development, and a full list of contributors can be found in the README file under the THANKS section.

---- Part 1: CMU/UCD copyright notice: (BSD like) ----

Copyright 1989, 1991, 1992 by Carnegie Mellon University

Derivative Work - 1996, 1998-2000

Copyright 1996, 1998-2000 The Regents of the University of California

All Rights Reserved

Permission to use, copy, modify and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appears in all copies and that both that copyright notice and this permission notice appear in

supporting documentation, and that the name of CMU and The Regents of the University of California not be used in advertising or publicity pertaining to distribution of the software without specific written permission.

CMU AND THE REGENTS OF THE UNIVERSITY OF CALIFORNIA DISCLAIM ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL CMU OR

THE REGENTS OF THE UNIVERSITY OF CALIFORNIA BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM THE LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Part 2: Networks Associates Technology, Inc. copyright notice (BSD)

Copyright (c) 2001-2003, Networks Associates Technology, Inc.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

Neither the name of the Networks Associates Technology, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 3: Cambridge Broadband Ltd. copyright notice (BSD) ----

Portions of this code are copyright (c) 2001-2003, Cambridge Broadband Ltd. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, his list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

The name of Cambridge Broadband Ltd. may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 4: Sun Microsystems, Inc. copyright notice (BSD) ----

Copyright © 2003 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Use is subject to license terms below.

This distribution may include materials developed by third parties.

Sun, Sun Microsystems, the Sun logo and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

Neither the name of the Sun Microsystems, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 5: Sparta, Inc. copyright notice (BSD) ----

Copyright (c) 2003-2006, Sparta, Inc.

All rights reserved.

Redistribution and use in source and binary forms, with or without

modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

Neither the name of Sparta, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 6: Cisco/BUPTNIC copyright notice (BSD) ----

Copyright (c) 2004, Cisco, Inc. and Information Network Center of Beijing University of Posts and Telecommunications.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

Neither the name of Cisco, Inc., Beijing University of Posts and Telecommunications, nor the names of their contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 7: Fabasoft R&D Software GmbH & Co KG copyright notice (BSD) ----

Copyright (c) Fabasoft R&D Software GmbH & Co KG, 2003

oss@fabasoft.com

Author: Bernhard Penz

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

The name of Fabasoft R&D Software GmbH & Co KG or any of its subsidiaries, brand or product names may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions of this software are based in part on the work of the following:

Hw_cryptodev.c License

Copyright (c) 2002 Bob Beck <beck@openbsd.org>

Copyright (c) 2002 Theo de Raadt

Copyright (c) 2002 Markus Friedl

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the author nor the names of contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions of this software are based in part on the work of the following:

Sun RPC is a product of Sun Microsystems, Inc. and is provided for unrestricted use provided that this legend is included on all tape media and as a part of the software program in whole or part. Users may copy or modify Sun RPC without charge, but are not authorized to license or distribute it to anyone else except as part of a product or program developed by the user.

SUN RPC IS PROVIDED AS IS WITH NO WARRANTIES OF ANY KIND INCLUDING THE WARRANTIES OF DESIGN, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, OR ARISING FROM A COURSE OF DEALING, USAGE OR TRADE PRACTICE.

Sun RPC is provided with no support and without any obligation on the part of Sun Microsystems, Inc. to assist in its use, correction, modification or enhancement.

SUN MICROSYSTEMS, INC. SHALL HAVE NO LIABILITY WITH RESPECT TO THE INFRINGEMENT OF COPYRIGHTS, TRADE SECRETS OR ANY PATENTS BY SUN RPC OR ANY PART THEREOF.

In no event will Sun Microsystems, Inc. be liable for any lost revenue or profits or other special, indirect and consequential damages, even if Sun has been advised of the possibility of such damages.

Sun Microsystems, Inc.

2550 Garcia Avenue

Mountain View, California 94043

Portions of this software are based in part on the work of the following:

v3_pcia.c -- mode:C; c-file-style: "eay" -- /

Contributed to the OpenSSL Project 2004 by Richard Levitte (richard@levitte.org)

Copyright (c) 2004 Kungliga Tekniska Högskolan (Royal Institute of Technology, Stockholm, Sweden). All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the Institute nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE INSTITUTE AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE INSTITUTE OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions of this software are based in part on the work of the following:

Racoon License

Copyright © 1995, 1996, 1997, 1998, 1999, 2000, 2001, 2002 and 2003 WIDE Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the project nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE PROJECT AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE PROJECT OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions of this software are based in part on the work of the following:

Snprintf License

Copyright Patrick Powell 1995

This code is based on code written by Patrick Powell (papowell@astart.com). It may be used for any purpose as long as this notice remains intact on all source code distributions.

Portions of this software are based in part on the work of the following:

Hostapd License

hostapd - user space IEEE 802.11 AP and IEEE 802.1X/WPA/WPA2 Authenticator

=====

Copyright (c) 2002-2004, Jouni Malinen <jkmaline@cc.hut.fi> and contributors. All Rights Reserved.

This program is dual-licensed under both the GPL version 2 and BSD license. Either license may be used at your option. Please note that some of the driver interface implementations (driver_*.c) may be licensed under a different license.

License

GPL v2:

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License version 2 as published by the Free Software Foundation.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA (this copy of the license is in COPYING file).

Alternatively, this software may be distributed under the terms of BSD license:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name(s) of the above-listed copyright holder(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Caring for the Environment by Recycling

When you see this symbol on a Motorola product, do not dispose of the product with residential or commercial waste.



Recycling your Motorola Equipment

Please do not dispose of this product with your residential or commercial waste. Some countries or regions, such as the European Union, have set up systems to collect and recycle electrical and electronic waste items. Contact your local authorities for information about practices established for your region.

If collection systems are not available, call Motorola Customer Service for assistance.

Please visit <http://www.motorola.com/recycle> for instructions on recycling.

Beskyttelse af miljøet med genbrug

Når du ser dette symbol på et Motorola-produkt, må produktet ikke bortskaffes sammen med husholdningsaffald eller erhvervsaffald.

Genbrug af dit Motorola-udstyr

Dette produkt må ikke bortskaffes sammen med husholdningsaffald eller erhvervsaffald. Nogle lande eller områder, f.eks. EU, har oprettet systemer til indsamling og genbrug af elektriske og elektroniske affaldsprodukter. Kontakt de lokale myndigheder for oplysninger om gældende fremgangsmåder i dit område. Hvis der ikke findes tilgængelige indsamlingssystemer, kan du kontakte Motorola Kundeservice.

Umweltschutz durch Recycling

Wenn Sie dieses Zeichen auf einem Produkt von Motorola sehen, entsorgen Sie das Produkt bitte nicht als gewöhnlichen Hausoder Büromüll.

Recycling bei Geräten von Motorola

Bitte entsorgen Sie dieses Produkt nicht als gewöhnlichen Haus- oder Büromüll. In einigen Ländern und Gebieten, z. B. in der Europäischen Union, wurden Systeme für die Rücknahme und Wiederverwertung von Elektroschrott eingeführt. Erkundigen Sie sich bitte bei Ihrer Stadtoder Kreisverwaltung nach der geltenden Entsorgungspraxis. Falls bei Ihnen noch kein Abfuhroder Rücknahmesystem besteht, wenden Sie sich bitte an den Kundendienst von Motorola.

Cuidar el medio ambiente mediante el reciclaje

Cuando vea este símbolo en un producto Motorola, no lo deseche junto con residuos residenciales o comerciales.

Reciclaje de su equipo Motorola

No deseche este producto junto con sus residuos residenciales o comerciales. Algunos países o regiones, tales como la Unión Europea, han organizado sistemas para recoger y reciclar desechos eléctricos y electrónicos. Comuníquese con las autoridades locales para obtener información acerca de las prácticas vigentes en su región. Si no existen sistemas de recolección disponibles, solicite asistencia llamando el Servicio al Cliente de Motorola.

Recyclage pour le respect de l'environnement

Lorsque vous voyez ce symbole sur un produit Motorola, ne le jetez pas avec vos ordures ménagères ou vos rejets d'entreprise.

Recyclage de votre équipement Motorola

Veuillez ne pas jeter ce produit avec vos ordures ménagères ou vos rejets d'entreprise. Certains pays ou certaines régions comme l'Union Européenne ont mis en place des systèmes de collecte et de recyclage des produits électriques et électroniques mis au rebut. Veuillez contacter vos autorités locales pour vous informer des pratiques instaurées dans votre région. Si aucun système de collecte n'est disponible, veuillez appeler le Service clientèle de Motorola qui vous apportera son assistance.

Milieubewust recycleren

Als u dit symbool op een Motorola-product ziet, gooi het dan niet bij het huishoudelijk afval of het bedrijfsafval.

Dbalność o środowisko - recykling

Produktów Motorola oznaczonych tym symbolem nie należy wyrzucać do komunalnych pojemników na śmieci.

Cuidando do meio ambiente através da reciclagem

Quando você ver este símbolo em um produto Motorola, não descarte o produto junto com lixo residencial ou comercial.

Var rädd om miljön genom återvinning

När du ser den här symbolen på en av Motorolas produkter ska du inte kasta produkten tillsammans med det vanliga avfallet.

Uw Motorola-materiaal recycleren.

Gooi dit product niet bij het huishoudelijk afval het of bedrijfsafval. In sommige landen of regio's zoals de Europese Unie, zijn er bepaalde systemen om elektrische of elektronische afvalproducten in te zamelen en te recycleren. Neem contact op met de plaatselijke overheid voor informatie over de geldende regels in uw regio. Indien er geen systemen bestaan, neemt u contact op met de klantendienst van Motorola.

Recykling posiadanego sprzętu Motorola

Produktu nie należy wyrzucać do komunalnych pojemników na śmieci. W niektórych krajach i regionach, np. w Unii Europejskiej, istnieją systemy zbierania i recyklingu sprzętu elektrycznego i elektronicznego. Informacje o utylizacji tego rodzaju odpadów należy uzyskać od władz lokalnych. Jeśli w danym regionie nie istnieją systemy zbierania odpadów elektrycznych i elektronicznych, informacje o utylizacji należy uzyskać od biura obsługi klienta firmy Motorola (Motorola Customer Service).

Reciclagem do seu equipamento Motorola

Não descarte este produto junto com o lixo residencial ou comercial. Alguns países ou regiões, tais como a União Européia, criaram sistemas para coletar e reciclar produtos eletroeletrônicos. Para obter informações sobre as práticas estabelecidas para sua região, entre em contato com as autoridades locais. Se não houver sistemas de coleta disponíveis, entre em contato com o Serviço ao Cliente da Motorola para obter assistência.

Återvinning av din Motorola-utrustning

Kasta inte denna produkt tillsammans med det vanliga avfallet. Vissa länder eller regioner, som t.ex. EU, har satt upp ett system för insamling och återvinning av el- och elektronikavfall. Kontakta dina lokala myndigheter för information om vilka regler som gäller i din region. Om det inte finns något insamlingsystem ska du kontakta Motorolas kundtjänst för hjälp.

リサイクルによる環境保護

モトローラ製品にこの記号が表示されている場合、製品を家庭または商業廃棄物として処分しないでください。

재활용으로 환경 보호하기

Motorola 제품에 이 표시가 있는 경우, 가정 또는 상업 폐기물과 함께 버리지 마십시오.

重复利用，保护环境

如果 Motorola 产品上具有这个标识，请勿将产品丢弃到家庭或商业垃圾中。

注意環保問題

在你看到產品上有 Motorola 的標誌時，請勿以住家或商用的廢棄物方式處置。

モトローラ装置のリサイクル

本製品を家庭または商業廃棄物として処分しないでください。欧州連合などの国または地域によっては、電氣的・電子的廢棄物を収集およびリサイクルするシステムがあります。お住まいの地域で決められている方法についての情報は、地方自治体にお問い合わせください。収集システムがない場合、モトローラ・カスタマーサービスまでお問い合わせください。

Motorola 기기 재활용

이 제품을 가정용 또는 사업용 폐기물과 함께 버리지 마십시오. 유럽 유니온과 같은 일부 국가 또는 지역에서는 재활용 전기 전자 폐기물 항목을 수집하는 시스템이 구축되어 있습니다. 해당 지역에 구축되어 있는 절차에 관한 정보는 지역 관할당국에 연락하십시오. 수집 시스템이 존재하지 않는 경우, 도움을 받기 위해 Motorola 고객센터 서비스부로 연락하십시오.

Motorola 设备的重复利用

请勿将本产品丢弃到家庭或商业垃圾中。某些国家或地区，例如欧盟，已经建立起回收和重复利用电气与电子废弃物的体系。请与当地相关机构联系，获取有关所在地区相关规定的信息。如果当地尚未建立回收体系，请致电 Motorola 客户服务以寻求帮助。

Motorola 設備的回收

請勿以住家或商用的廢棄物方式處置。某些國家或地區，如歐盟，已對廢棄的電器和電子產品制訂回收以及再用體制。請與您所在地的管?機構諮詢相關規定。
?您所在的地區並未設置回收機制，請電 Motorola 客服部諮詢相關事宜。

Please visit <http://www.motorola.com/recycle> for instructions on recycling.

Index

Symbols

!! command [55](#)

A

Address resolution table [60](#)

Administrator password [54](#)

Arguments, CLI [64](#)

ARP

Command [56,62](#)

C

CLI [51](#)

!! command [55](#)

Arguments [64](#)

Command shortcuts [55](#)

Command truncation [64](#)

Configuration mode [64](#)

Keywords [64](#)

Navigating [64](#)

Prompt [55,64](#)

Restart command [55](#)

SHELL mode [55](#)

View command [65](#)

Command

ARP [56,62](#)

Ping [57](#)

Telnet [62](#)

Command line interface (see CLI)

CONFIG

Command List [53](#)

Configuration mode [64](#)

Configure [20](#)

Connection [21](#)

Connection commands [67](#)

D

DHCP [11](#)

DHCP lease table [58](#)

DHCP Server [23](#)

Diagnostic log [58,61](#)

Diagnostics [40](#)

DSL [35](#)

Dynamic Addressing [11](#)

E

Ethernet [36](#)

Ethernet statistics [58](#)

F

factory default [42](#)

Factory Reset Switch [49](#)

firewall [60](#)

Firewall Log [38](#)

H

Help [44](#)

Home Page [18](#)

I

ICMP Echo [57](#)

IGMP [69](#)

IGMP Snooping [69](#)

IP [36](#)

IP DNS commands [68](#)

IP Gateway commands [71](#)

IP IGMP commands [69](#)

IP interfaces [60](#)

IP routes [61](#)

IPMap table [61](#)

K

Keywords, CLI [64](#)

L

LAN [36](#)

LAN Host Discovery Table [61](#)

LEDs [46](#)

Link commands [72](#)

Links Bar [19](#)

Log [61](#)

Log, Firewall [38](#)

Log, System [37](#)

Logging in [54](#)

M

MAC Filtering [29](#)

Management commands [73](#)

Memory [61](#)

multiple subnets [24](#)

N

NAT [31](#)

NAT Pinhole commands [77](#)
NTP commands [71](#)

P

Password
 Administrator [54](#)
 User [54](#)
Physical interfaces commands [74](#)
Ping command [57](#)
Pinhole Entry [31](#)
PPP [63](#)
Prompt, CLI [55,64](#)

Q

quickstart [14](#)

R

Reset Router [42](#)
Reset Switch [49](#)
Restart [58](#)
Restart command [55](#)
Restart Router [42](#)
Router Password [33](#)

S

safety instructions [8](#)
SHELL
 Command Shortcuts [55](#)
 Commands [55](#)
 Prompt [55](#)
SHELL level [64](#)
SHELL mode [55](#)
show config [59](#)
Show ppp [63](#)
Software Upgrade [43](#)
Static IP Address [22](#)
Status [35](#)
status indicator lights [46](#)
Step mode [65](#)
subnets
 multiple [24](#)
System commands [78](#)
System Log [37](#)

T

Telnet [54](#)
Telnet command [62](#)
TFTP server [56](#)
Time Zone [34](#)

Trivial File Transfer Protocol [56](#)
Troubleshooting [45](#)
Truncation [64](#)

U

Update Router [43](#)
User name [54](#)
User password [54](#)
Utilities [39](#)

V

View command [65](#)
view config [62](#)

W

WAN [35](#)
Wi-Fi Protected Access [28](#)
Wired Equivalent Privacy [27](#)
Wireless [36](#)
Wireless Multi-media [29](#)