



QUICK SETUP GUIDE

Rocketfish Advanced Miracast Video Receiver

RF-WFD301

Package contents

- Rocketfish Miracast Video Receiver
- 6" HDMI adapter
- 30" Micro USB charger cable
- *Quick Setup Guide*

System requirements

- Digital TV with an HDMI jack and a USB port

Features



- Requires Android™ Jellybean 4.2.1 or newer
- Works with compatible devices such as your phone or tablet to deliver signals to your TV, projector or other audio/video devices.

Need additional help?

See your **User Guide!** This comprehensive guide includes everything from basic how-to steps to more advanced features.

Go to www.rocketfishproducts.com, then click **Support & Service**. Enter your model number in the **Manual, Firmware, Drivers & Product Information**, then click **Search**.

Before using your new product, please read these instructions to prevent any damage.


Installing your receiver

- 1 Turn off the TV.
- 2 Insert the Rocketfish Miracast Video Receiver into the HDMI port on your TV. If the video receiver will not fit into the HDMI port on your TV (too large or too wide), use the 6" HDMI adapter for a better fit.
- 3 Insert one end of the 30" cable into the micro USB port on the receiver. Insert the other end into the USB port on your TV.
- 4 Turn on your TV, then press the TV's Input or Source button to select the input HDMI input of the Rocketfish Wireless Video Receiver.
- 5 The LED on the Rocketfish Miracast Video Receiver starts to blink and boot up. The splash screen on your TV is displayed within 30 seconds. If the LED doesn't blink or the boot up splash screen is not seen, check to make sure that the TV input you have selected is correct and the Rocketfish Wireless Video Receiver has power and is fully inserted.

Setting up your receiver connection

For the first time use, the Rocketfish Miracast Video Receiver will boot up and go into the Auto mode and is ready to accept a Wi-Fi Direct connection.

- 1 Verify the TV screen shows Rocketfish Wireless Video Receiver screen as shown below.
- 2 On your Miracast mobile device, such as a mobile phone or tablet, turn on the Wi-Fi network.
- 3 Press the WPS button on the Rocketfish Miracast Video Receiver for first-time connection.
- 4 Go to **Settings > Display > Wireless Display** and select the SSID noted in Step 1.
- 5 When the connection is successful, your Miracast device's (such as your phone) screen is displayed on your TV, indicating that video streaming has started.





Legal notices

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warnings:

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Not for outdoor use!

Open Source Statement

For information on the open source software used on this device or to obtain a copy go to www.rocketfishproducts.com.



One-year limited warranty

Visit www.rocketfishproducts.com for details.

We're here for you:

For customer service call 1-800-620-2790

www.rocketfishproducts.com

Miracast is a trademark of the Wi-Fi Alliance.

Android is a trademark of Google, Inc.

ROCKETFISH is a registered trademark of BBY Solutions, Inc. Registered in some countries.

Distributed by Best Buy Purchasing, LLC, 7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2013 BBY Solutions, Inc. All Rights Reserved.

