



Set Up Verizon One	10
Verify Installation Kit Contents	10
Select a Location for your Verizon One	11
Attach the Base Unit to the Support Stand	11
Plug in the Power Cord	12
Configure Verizon One	12
Connect to your Wireless Home Network	13
Connect to your Wired Home Network	13
Register Handset	14
Activate Base Unit	14
Register Handset to Base Unit	14
Charge the Cordless Handset Battery	14
Handset Functionality	15
Handset Buttons	15
Received Calls	16
View Incoming Calls	16
Delete All Incoming Call Information	16
Placed Calls	16
View Outgoing Calls	16
Delete All Outgoing Call Information	17
Handset Phone Book	17
View Phone Book Contact	17
Add Contact to the Handset Phone Book	18
Edit Contact in Phone Book	19
Delete Contact from Phone Book	20
Delete All Contacts from Phone Book	20

Handset	Functionality	/	(cont'd)

Settings	21
Assign Name to Handset	21
Set Background	21
Change Ringtone	22
Set Ringtone Volume	22
View Version Information	23
Set Contrast	23
Set Handset Volume	23
Intercom	24
Invite Handset	24
Transfer Handset	24
Register Handset	25
Register Handset	25
Change Base	26
Delete Base	26
Delete Handset	27
Home Screen	28
Date and Time	28
Change Time Zone	28
View Calendar	28
Weather	29
Check Local Weather	29
View 5-Day Forecast	29
My Locations	29

Home Screen (cont'd)	
Dialer Make a Call Call a Person in Address Book or Call Logs Call a Person in Speed Dial List Add a Person to Speed Dial List View Call Log	30 30 37 37 32 32
Lookup Person or Business in SuperPages Use Intercom to Find Handset	30 30
On-Screen Actions Access Menu Answer a Call Ignore a Call Answer Call Waiting Adjust Speaker/Ringer Volume	34 34 34 35 35
Featured	36
Calls & Messages	37
View Call Logs Delete a Call Delete All Calls Add Caller to Address Book Call a Person in Call Log	37 37 38 38 40
Call a Person in Call I on	Δl

Table of Contents

Calls & Messages (cont'd)

Message Center Memo Pad Create Memo Delete Memo Verizon Messages View Verizon Messages Delete Verizon Messages Delete All Verizon Messages	41 41 42 42 42 43 43
Address Book View Address Book Add Person Add Business Add Group	44 44 45 47
Phone Book Yellow Pages Search for a Business Get Directions to a Business	47 47 47 48
White Pages Search for a Person	49
Speed Dial Add Speed Dial Entry Call Person on Speed Dial List Delete Person on Speed Dial List	50 50 50 51
Reverse Lookup Find a Person or Phone Number	51 51

News & Info	52
Weather Check Current Weather View 5-Day Forecast My Locations	52 52 52 53
News Check Top Headlines Read Entertainment News	54 54 54
Sports Read Sports News Check Scores Check Schedules	55 55 55 56
Information Lottery Check Lottery Results Change Lottery Location Horoscope Check Horoscope Change Horoscope Sign Stocks Check Stocks	57 57 57 57 58 58 58 58 59
Search/Add Stocks	59

60	Food & Entertainment
60	Restaurants
60	Search Restaurants Near Me
61	Search Restaurants in Other Areas
61	Search Restaurants By Cuisine
61	Get Map to Restaurant
61	Get Directions to Restaurant
62	Movies
62	Watch Movie Trailers
63	Lookup Movies in Other Areas
64	Tools & Settings
64	Tools & Calendar
64	Calculator
64	Calendar
64	View Event
64	Add Event
65	Edit Event
66	Delete Event
66	Sound Settings
66	Ringtones
66	Change Ringtone
67	Preview Ringtone
67	Volume
67	Adjust Volume
	Volume

		_	
Tools	&	Settings	(cont'd)

Display Sottings	68
Display Settings	
Brightness & Contrast	68
Adjust Brightness & Contrast	68
Wallpaper	68
Change Wallpaper	68
Screen Saver	69
Change Screen Saver	69
Touch Screen Tuneup	69
Calibrate Touch Screen	69
Network & Phone Settings	70
Date/Time	70
Change Time Zone	70
Network Setup	70
Set Up Wireless Network	70
Set Up Wireless Network via Static IP	71
Connect to Wireless Network	71
Connect to Wired Network	72
Voice Mail Setup	72
Set Up Voice Mail	72
Handsets	73
Register Handsets	73
System Info	74
View System Info	74
Update System Info	74
Account Settings	75
Reset to Factory Defaults	75

Regulatory Information	76
FCC Interference Information	76
FCC RF Radiation Exposure Statement	76
Troubleshooting	77
Restart your Verizon One	77
Call Customer Support	77

Set Up Verizon One

Setting up your Verizon One is an easy process. In just a few minutes you'll be ready to use your phone.

Verify Installation Kit Contents

- 1. Open installation kit.
- 2. Verify box contents:
 - 1. Base unit
 - 2. Base unit support stand
 - 3. Faceplate
 - 4. Cordless handset
 - 5. Stylus
 - 6. Power adapter and cord
 - 7. Phone cord
 - 8. Ethernet cable
 - 9. Important information sheet (not pictured)



Set Up Verizon One (cont'd)

Select a Location for your Verizon One

- 1. Your Verizon One has three requirements:
 - A sturdy flat surface or table to sit on.
 - A location close to an electrical outlet that is always active (not on a switch).
 - A location within range of your current home network devices.
- 2. If you have a wireless network, you must be within range of the wireless adaptors on the other devices.
- 3. If you have a wired network, you must be able to connect to the other devices using Ethernet cables.
- 4. Other location considerations include:
 - Keep your Verizon One at least 10 feet from a microwave.
 - Position your Verizon One away from heat sources, moisture and excessive dust.
 - Position your Verizon One to keep the number of walls and ceilings between the Verizon One and other devices on your network to a minimum. If the signal must go through walls, it loses less strength if it goes straight through the wall rather than at an angle.

- Place your Verizon One near a window if you want to use your laptop outside.
- Keep your Verizon One away from large metal objects, which can affect signal quality and strength.

You're done!

Attach the Base Unit to the Support Stand

- 1. Slip one end of the support stand into the hole at back of the base unit.
- 2. Slip the other end of the support stand into the other hole at the back of the base unit
- 3. Confirm that the support stand is firmly connected to the base unit.



Set Up Verizon One (cont'd)

Plug in the Power Cord

- Plug the DC 12V power cord to the power connector marked "12V DC" on the rear panel of the base unit.
- 2. Plug the other end of the power supply cord into an AC wall outlet.
- 3. Your Verizon One device will power up and turn on.

You're done!

Configure Verizon One

- After you plug in your Verizon One, the LCD screen will display the Startup screen.
- 2. After reading the Welcome screen, touch **Next**.
- 3. Insert one end of the phone cord (white) into the phone jack on the back panel of the Verizon One.
- 4. Connect the other end of the phone cord to your phone wall jack.
- 5. Touch Next.
- If you have an established home network, you can connect your Verizon One to the wired or wireless network.
 - If you have a wired home network, touch Use a network cable.
 - If you have a wireless home network, touch Use my wireless network.



Set Up Verizon One (cont'd)

Connect to your Wireless Home Network

- After Verizon One has scanned for available networks, touch your network from the list of available wireless networks.
- If your network isn't listed, touch Add network to manually enter your networking settings.
 - Use the electronic keyboard to enter your network's SSID in the Wireless Network Name (SSID) field.
 - Use the electronic keyboard to enter your network's encryption key or password phrase in the Encryption Key or Pass Phrase field.
- 3. Touch Next.
- 4. If you have a secure network (a lock displays before the name in the available network listing), you must enter your network's encryption or password phrase in the Encryption Key or Pass Phrase field.
- 5. Touch Next.
- 6. Verizon One will attempt to connect to your network.
- Touch Next when the message displays saying you have successfully connected to your network.

You're done!

Connect to your Wired Home Network

If you have an established wired home network, you can connect your Verizon One to it.

- Connect one end of the Ethernet cable into the Ethernet port on the back panel of the Verizon One.
- 2. Connect the other end of the Ethernet cable into your network router or Ethernet wall jack.
- 3. Touch Next.
- 4. When the screen displays saying you have successfully connected to the network, touch **Next**.



Set Up Verizon One (cont'd)

Register Handset

Activate Base Unit

Activate registration mode on the base unit so you can register the cordless handset.

- 1. Return to the base unit.
- 2. Touch Menu.
- 3. Tap Tools & Settings.
- 4. Touch Network & Phone Settings.
- 5. Touch **Handsets**.
- 6. Tap Register Handset.

You're done!

Register Handset to Base Unit

- 1. Press the **OK** button on the handset.
- 2. Use the navigation button to select **Register Handset** and press **OK**.
- 3. Select Subscription and press OK.
- 4. Select **Base #1** and press **OK**.
- 5. Enter 1111 as your PIN and press OK.
- 6. After 3 seconds, the handset will automatically register to the base unit.
- 7. To verify successful registration, press •• A dial tone will be emitted from the handset and it's ready to place a call.

You're done!

If there is no dial tone but the handset successfully registered with the base, verify

that the base unit is connected to an active telephone line and that this line is plugged into the phone port on the back of the base unit.

Charge the Cordless Handset Battery

- 1. Place the handset into the cradle (either way) so the contacts on the handset touch the contacts on the base unit.
- 2. Allow the battery to charge for approximately <u>12 hours before using it</u> for the first time.

Handset Functionality

Handset Buttons



▶ Handset Functionality (cont'd)

Received Calls

View Incoming Calls

- 1. Press **OK** to open the Menu.
- 2. **Received Calls** will be highlighted. Press **OK**.
- 3. Scroll to View and press OK.
- 4. Your list of incoming calls will appear.

You're done!

Delete All Incoming Call Information

- 1. Press **OK** to open the Menu.
- 2. **Received Calls** will be highlighted. Press **OK**.
- 3. Scroll to **Delete All** and press **OK**.
- 4. Press **OK** to confirm you want to delete all call information.

You're done! All incoming call information will be deleted from the handset.

Placed Calls

View Outgoing Calls

- 1. Press **OK** to open the Menu.
- 2. Press ▷ to scroll to **Placed Calls** and press **OK**.
- 3. Scroll to View and press OK.
- 4. Your list of incoming calls will appear.







▶ Handset Functionality (cont'd)

Placed Calls (cont'd)

Delete All Outgoing Call Information

- 1. Press **OK** to open the Menu.
- 2. Press ▷ to scroll to **Placed Calls** and press **OK**.
- 4. Press **OK** to confirm you want to delete all call information.

You're done! All outgoing call information will be deleted from the handset.

Handset Phone Book

View Phone Book Contact

- 1. Press **OK** to open the Menu.
- 2. Press ▷ to scroll to **Phone Book** and press **OK**.
- 4. Scroll to the contact you want to view.





▶ Handset Functionality (cont'd)

Handset Phone Book (cont'd)

Add Contact to the Handset Phone Book

Although your Verizon One base unit has a central Address Book that can be used the by entire family, you can also create a smaller Phone Book on your handset; especially if you've purchased multiple handsets.

- 1. Press **OK** to open Menu.
- Press ▷ to scroll to Phone Book and press OK.
- Use the handset keypad to enter the first and last name for this contact and press **OK**.
- Use the handset keypad to enter the phone number of this contact and press
 OK. Do not enter parentheses, dashes, or periods between numbers.
- 6. Press

 to scroll to the ringtone you want to play when this contact calls and press OK.
- 7. The contact information you entered will display. Press **OK** if the information is correct. If it isn't correct, press ⁴ to make any necessary changes.



▶ Handset Functionality (cont'd)

Handset Phone Book (cont'd)

Edit Contact in Phone Book

- 1. Press **OK** to open Menu.
- Press ▷ to scroll to Phone Book and press OK.

- 5. If no changes are required for the **Name**, press **OK** and skip to Step 7.
- 6. Use

 to move the cursor back to make any necessary edits to the Name.
- 7. Touch **OK** after you have completed the edits.
- If no changes are required for the Phone Number, press OK and skip to Step 10.
- Use \(\) to move the cursor back to make any necessary edits to the Phone Number.
- 10. Touch **OK** after you have completed the edits.
- 11. Scroll to the ringtone you want to play when this contact calls and press **OK**.
- 12. Review the contact information. If it is correct, press **OK**.



▶ Handset Functionality (cont'd)

Handset Phone Book (cont'd)

Delete Contact from Phone Book

- 1. Press **OK** to open Menu.
- Press ▷ to scroll to Phone Book and press OK.

- 5. Press **OK** to confirm you want to delete this contact.

You're done!

Delete All Contacts from Phone Book

- 1. Press **OK** to open Menu.
- Press ▷ to scroll to Phone Book and press OK.
- 4. Press **OK** to confirm you want to delete all contacts in your handset Phone Book.





▶ Handset Functionality (cont'd)

Settings

Assign Name to Handset

After you've registered your handset, you can assign a name to it. This is helpful if your purchase multiple handsets for your Verizon One.

- 1. Press OK to open Menu.
- 2. Press ▶ to scroll to **Settings** and press **OK**.
- 3. Scroll to **Set Name** and press **OK**.
- 4. Scroll to On and press OK.
- Use the handset keypad to enter a name for this handset. (Ex: Kitchen, Living Room)
- 6. Use 4 to edit your entries.
- 7. Press **OK** when you finish entering the handset name.

You're done! The handset name will appear on the main handset screen.

Set Background

- 1. Press **OK** to open Menu.
- 2. Press ▷ to scroll to **Settings** and press **OK**.
- Use △ and ▽ to scroll through the background options.







▶ Handset Functionality (cont'd)

Settings (cont'd)

Set Background (cont'd)

- 5. Press **OK** to select the graphic.
- 6. Press **OK** to confirm the background update.

You're done! The new background will appear on your handset screen.

Change Ringtone

- 1. Press **OK** to open Menu.
- 2. Press ▶ to scroll to **Settings** and press **OK**.
- 4. Scroll to **Ringtone Type** and press **OK**.
- 5. Use △ and ▽ to scroll to the ringtone you prefer and press **OK**.

You're done! Your selected ringtone will sound the next time you receive a call.

Set Ringtone Volume

- 1. Press **OK** to open Menu.
- 2. Press > to scroll to **Settings** and press **OK**.
- 3. Press ♥ to scroll to **Ringtones** and press **OK**.
- 4. Scroll to **Ringtone Volume** and press **OK**.
- Scroll to the preferred volume level Off,
 Low, Medium or High and press OK.





▶ Handset Functionality (cont'd)

Settings (cont'd)

View Version Information

- 1. Press **OK** to open Menu.
- 2. Press to scroll to **Settings** and press **OK**.
- 3. Press (down arrow) to scroll to Version and press **OK**.

You're done!

Set Contrast

- 1. Press **OK** to open Menu.
- 2. Press > to scroll to **Settings** and press **OK**.
- Use △ and ▽ to scroll to the level of contrast you prefer and press OK.

You're done!

Set Handset Volume

- 1. Press **OK** to open Menu.
- 2. Press ▶ to scroll to **Settings** and press **OK**.
- 3. Press ∇ to scroll to **Volume** and press **OK**.
- Scroll to the preferred volume level –
 Off, Low, Medium or High and press OK.







▶ Handset Functionality (cont'd)

Intercom

Use the Intercom feature to invite a handset or to transfer a call.

Invite Handset

- 1. Press **OK** to open Menu.
- 2. Press to scroll to Intercom and press OK.
- 4. Scroll to the preferred handset and press OK.

You're done!

Transfer Handset

Use this feature when you answer a call with the speakerphone of the base unit but want to transfer the call to the handset.

- 1. Press **OK** to open Menu.
- 2. Press > to scroll to Intercom and press OK.
- 3. Press ♥ to scroll to **Transfer Call** and press **OK**.
- 4. Scroll to the preferred handset and press **OK**.

You're done! The call will be transferred to the handset you chose.





▶ Handset Functionality (cont'd)

Register Handset

Register Handset

- If you haven't done so already, you must first activate registration mode on the base unit.
- 2. Touch Menu.
- 3. Tap Tools & Settings.
- 4. Touch Handset Registration.
- 5. Tap Register Handset.
- 6. Now the base unit is ready to accept the cordless handset registration.
- 7. Press the **OK** button on the handset.
- 8. Use the navigation button to select **Register Handset** and press **OK**.
- 9. Select Subscription and press OK.
- 10. Select Base #1 and press OK.
- 11. Enter 1111 as your PIN and press OK.
- After 3 seconds, the handset will automatically register to the base unit.
- 13. To verify successful registration, press [1]. A dial tone will be emitted from the handset and it's ready to place a call.

Note: If there is no dial tone but the handset successfully registered with the base, verify that the base unit is connected to an active telephone line and that this line is plugged into the phone port on the back of the base unit.



▶ Handset Functionality (cont'd)

Register Handset (cont'd)

Change Base

- 1. Press **OK** to open Menu.
- 2. Press ▶ to scroll to **Register Handset** and press **OK**.
- 3. Scroll to Change Base and press OK.
- 4. Scroll to the base unit you want and press **OK**.

You're done!

Delete Base

- 1. Press **OK** to open Menu.
- 2. Press ▶ to scroll to Register Handset and press OK.
- 3. Scroll to **Delete Base** and press **OK**.
- 4. Scroll to the base unit you want to delete and press **OK**.
- 5. Press **OK** to confirm you want to delete the selected base unit.





► Handset Functionality (cont'd)

Register Handset (cont'd)

Delete Handset

- 1. Press **OK** to open Menu.
- 2. Press ▷ to scroll to **Register Handset** and press **OK**.
- 3. Scroll to **Delete HS** and press **OK**.
- 4. Scroll to the handset you want to delete and press **OK**.



Home Screen


This covers what you can do from the Home screen of Verizon One.

Date and Time

Change Time Zone


- 1. Touch the **Date and Time** at the top-left of the screen
- 2. The Calendar will open.
- 3. Touch Change Time Zone.
- 4. Select the new **Time Zone** and touch **Save**.

You're done! The changes you've made to your Time Zone will be effective immediately.



View Calendar

- 1. Touch the **Date and Time** at the top-left of the screen
- 2. The Calendar will open.



► Home Screen (cont'd)

Weather

Check Local Weather

- 1. Touch the **Weather** at the top-right of the screen.
- 2. The Weather will open.

You're done!

View 5-Day Forecast

- 1. Touch the **Weather** at the top-right of the screen
- 2. The Weather will open.
- 3. Touch 5-Day Forecast.


You're done!

My Locations

- Touch the Weather at the top-right of the screen
- 2. The Weather will open.
- 3. Touch My Locations.
- 4. To enter a location in the U.S.:
 - Touch the National tab.
 - Enter the ZIP, City and State.
 - Touch Add.







► Home Screen (cont'd)

Weather (cont'd)

My Locations (cont'd)


- 5. To enter an international location:
 - Touch the **International** tab.
 - Enter the City and Country.
 - Touch Add.

You're done! The locations you added will also be displayed with you open the Weather screen.

Dialer

Make a Call

- 1. Touch (.
- 2. The Dialer will open.
- 3. Enter the **phone number** you want to call.
- 4. Touch **©** Dial.
- The call will be placed using the Speakerphone. If you want to switch to the handset, simply pick it up and press **Talk**.



► Home Screen (cont'd)

Dialer (cont'd)

Call a Person in Address Book or Call Logs

- 1. Touch (
- 2. The Dialer will open.
- 3. Touch Address Book or Call Logs.
- 4. Touch next to the person you want to call.
- The call will be placed using the Speakerphone. If you want to switch to the handset, simply pick it up and press Talk.

You're done!

Call a Person in Speed Dial List

- 1. Touch (
- 2. The Dialer will open.
- 3. Touch **Speed Dial**.
- 4. The Speed Dial list will appear.
- 5. Touch next to the person you want to call.
- The call will be placed using the Speakerphone. If you want to switch to the handset, simply pick it up and press Talk.





► Home Screen (cont'd)

Dialer (cont'd)


Add a Person to Speed Dial List


- 1. Touch (.
- 2. The Dialer will open.
- 3. Click Speed Dial.
- 4. Touch one of the entries labeled **(Empty)**.
- 5. Enter the **Name** and **Number** of the person.
- 6. Click Done.

You're done! This person will be added to your Speed Dial List.

View Call Log

- 1. Touch (
- 2. The Dialer will open.
- 3. Touch Call Logs.





► Home Screen (cont'd)

Dialer (cont'd)


Look Up Person or Business in SuperPages

- 1. Touch
- 2. The Dialer will open.
- 3. Click SuperPages.
- 4. Touch Yellow Pages or White Pages.
- 5. Enter the Name, City and State.
- 6. Click Find It.
- 7. Your results will appear.
- 8. Touch:
 - to call them.
 - 1+ Dial to call them (if the number is long distance).
 - Map to generate a map of their location.

You're done!

Use Intercom to Find Handset

- 1. Touch (
- 2. The Dialer will open.
- 3. Click Intercom.
- 4. The handset will beep for 10 seconds so you can find it.





► Home Screen (cont'd)

On-Screen Actions

Access Menu

- 1. Touch Menu.
- 2. The Menu will open.

You're done!


Answer a Call

- 1. A Caller ID pop-up will appear for each incoming call.
- 2. Tap Answer.
- 3. The call will be answered using the Speakerphone. If you want to switch to the handset, simply pick it up and press **Talk**.

You're done!

Ignore a Call

- 1. A Caller ID pop-up will appear for each incoming call.
- 2. Tap Ignore.
- 3. The caller will be sent to Voice Mail.







► Home Screen (cont'd)

On-Screen Actions (cont'd)

Answer Call Waiting

- 1. The Caller ID of the first caller will remain on the screen.
- 2. When a new Caller calls, another Caller ID will appear.
- 3. Touch **Flash** to answer Call Waiting.
- 4. Touch **End Call** to end your conversation with the second caller.

You're done! You are returned to speaking with the first caller.

Adjust Speaker/Ringer Volume

- 1. Locate the volume buttons on the Verizon One device.
- Press + to increase the volume.
 OR
 Press to decrease the volume.





Featured

This section will be updated with the latest Verizon One features. Each of these features with be Featured here, but also appear in their permanent location. Be sure to check this section occasionally to see what's new with Verizon One.

