Dynamic CCTV Ltd

BT Router (BT2700HGV)
Setup
Guide

Setup Guide

Open up internet explorer and enter 192.168.1.254 in the address bar
from the page that apears click "**Settings**" then "**Firewall**" then lastly "**Allow pinholes and DMZ mode**"

On the next screen scroll down to the 2 blue links at the bottom of the page and select "**Add new user-defined application**"

Setup Guide Part 2

Create a new user defined application by first giving it a name in the "**Application profile name**" box
in this instance call it "**DVR**"
the only other field we need to fill in is what port we want to forward, in the case of the EZH DVR the default
port is 80 so pop **80** in both the "**From**" and "**To**" fields in the cas of other DVRs check the documentation for
the required ports to forward
NB* some DVRs require more than one port in this case repeat the process to add additional ports
NB* some DVRs require a range of ports in this case add the first port in the "**From**" field then the end port in
the "**To**" field.

Lastly back on the "**Allow pinholes and DMZ mode**" page manualy enter the internal IP address of your DVR in
the "**Enter IP address**" field then click **Choose** then click the gray "**User-Defined**" filter button this will display
your newly created application simply click on the application in the left box the click the **Add** button, the
application will now appear in the right box simply scroll to the bottom of the page and click **Save** to finish