



My Net™ Wi-Fi Range Extender

User Manual



WD® Service and Support

Should you encounter a problem, please give us an opportunity to address it before returning this product. Most technical support questions can be answered through our knowledge base or e-mail support service at <http://support.wdc.com>. If the answer is not available or, if you prefer, please contact WD at the best telephone number shown below.

Your product includes 30 days of free telephone support during the warranty period. This 30-day period starts on the date of your first telephone contact with WD technical support. E-mail support is free for the entire warranty period and our extensive knowledge base is available 24/7. To help us keep you informed of new features and services, remember to register your product online at <http://register.wdc.com>.

Accessing Online Support

Visit our product support website at <http://support.wdc.com> and choose from these topics:

- **Downloads** - Download drivers, software, and updates for your WD product.
- **Registration** - Register your WD product to get the latest updates and special offers.
- **Warranty & RMA Services** - Get Warranty, Product Replacement (RMA), RMA Status, and Data Recovery Information.
- **Knowledge Base** - Search by keyword, phrase, or answer ID.
- **Installation** - Get online installation help for your WD product or software.
- **WD Community** – Share your thoughts and connect with other users.

Contacting WD Technical Support

When contacting WD for support, have your WD product serial number, system hardware, and system software versions available.

North America		Asia Pacific	
English	855-842-5370	Australia	1 800 42 9861
		China	800 820 6682/+65 62430496
Spanish	800.832.4778	Hong Kong	+800 6008 6008
		India	1 800 11 9393 (MNTL)/1 800 200 5789 (Reliance) 011 26384700 (Pilot Line)
Europe (toll free)*	00800 ASK4 WDEU (00800 27549338)	Indonesia	+803 852 9439
		Japan	00 531 650442
		Korea	02 703 6550
Europe	+31 880062100	Malaysia	+800 6008 6008/1 800 88 1908/+65 62430496
Middle East	+31 880062100	Philippines	1 800 1441 0159
Africa	+31 880062100	Singapore	+800 6008 6008/+800 608 6008/+65 62430496
		Taiwan	+800 6008 6008/+65 62430496

* Toll free number available in the following countries: Austria, Belgium, Denmark, France, Germany, Ireland, Italy, Netherlands, Norway, Spain, Sweden, Switzerland, United Kingdom.

Table of Contents

WD® Service and Support	3
1 Important User Information	1
Important Safety Instructions	1
Recording Your WD Product Information	2
Registering Your WD Product	2
2 Product Overview	3
Introduction	3
Features	3
Package Contents	3
Components	5
3 Getting Started	8
Setting up the Extender with a WPS Enabled Router	8
Setting up Your Extender Manually	9
Configuring the Extender for the First Time	11
4 Configuring Basic Settings	16
Opening My Dashboard After Setup	16
Configuring Wireless Settings	19
Adding a Wireless Device to Your Network	20
5 Configuring Advanced Settings	23
Changing the Administrator Password	23
Resetting and Rebooting the Extender	24
Updating the Extender's Firmware	25
6 Setting up the Extender in AP Mode	26
7 Troubleshooting	28
8 Regulatory and Warranty Information	29
Regulatory Compliance	29
Warranty Information (All Regions Except Australia/New Zealand)	33
Warranty Information (Australia/New Zealand only)	34
GNU General Public License ("GPL")	35
9 Appendix: Technical Specifications	79
10 Index	82

1

Important User Information

Important Safety Instructions

This device is designed and manufactured to assure personal safety. Improper use can result in electric shock or fire hazard. The safeguards incorporated into this unit will protect you if you observe the following instructions for installation, use, and servicing.

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Carefully read and follow the Quick Install Guide and User Manual.
- Do not operate this device outside the temperature range of 5°C–35°C (41°F–95°F).
- Do not drop or shake the device.
- Do not move the device when it is powered on.
- Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon them or against them.
- Do not overload wall outlets.

For additional safety information, refer to www.wdc.com.

Recording Your WD Product Information

In the following table, write the serial and model numbers of your new WD product. You can find this information on the label on the bottom of the device. You should also note the date of purchase. This information may be required when requesting technical support.

Serial Number:
Model Number:
Purchase Date:
System and Software Notes:

Registering Your WD Product

Your WD product includes 30 days of free technical support during the applicable warranty period for your product. The 30-day period commences on the date of your first telephone contact with WD technical support. Register your WD product online at <http://register.wdc.com>.

2

Product Overview

Thank you for purchasing the My Net™ Wi-Fi Range Extender. This user manual provides step-by-step instructions for installing and using your new range extender. For the latest WD product information and news, visit our website at www.wdc.com.

This chapter contains the following topics:

- Introduction
- Features
- [Package Contents](#)
- [Components](#)

Introduction

Features

The outstanding features of the My Net Wi-Fi Range extender are described below.

Note: For detailed technical specifications, see Appendix A.

- **Intelligence**—Automatically transfers Wi-Fi devices to the range extender when you're out of range.
- **Flexibility**— Choose the 2.4 or 5 GHz band with a flip of the switch on the side of the range extender. No PC required.
- **Simple to position**—Find the optimal location in your home with the Wi-Fi signal strength indicator.
- **Fast streaming**—Use with WD's My Net™ HD Dual-Band Routers for best possible HD entertainment streaming.
- **Wireless A,B,G,N, AC compatible**
- **Wired AP mode support**
- **UPnP support**

Package Contents

In addition to your My Net Wi-Fi Range extender, the package contains:


- Network (Ethernet) cable
- AC Power adapter
- Quick Install Guide



My Net Wi-Fi Range extender



AC power adapter



Ethernet cable

NEED

Quick Install Guide

Accessories

For U.S. residents, visit www.shopwd.com to view additional accessories available for your My Net Wi-Fi Range extender. For users outside the U.S., visit <http://support.wdc.com>.


AC Power Adapters

The AC power adapter varies, depending on your location. Some locations do not require a power plug clip. Units sold in those locations have a fixed power plug. Refer to the illustrations below.



Installing

Removing



Installing

Removing

Components

Front Panel

Wireless Strength Indicator

Power LED

WPS LED

Add labels and descriptions

Front LED indicators

LED	Description
Power	Steady blue when the extender is powered on and operational; flashes slowly during boot-up , firmware upgrades, and system self-tests.
Wi-Fi Protected Setup (WPS)	When connecting the extender and a wireless device (e.g., a printer) that you want to add to the network, the LED indicates the status of WPS: <ul style="list-style-type: none"> • When WPS is connecting a network device, the light blinks slowly. • If an error occurs during setup, the light blinks quickly. • After setup, light is solid when WPS is active.
Wireless strength	18 blue lights flash when you first connect to indicate the strength of the wireless connection (signal). Helps you determine optimal placement. <ul style="list-style-type: none"> •

Side Panel

Power button

WPS button

Frequency switch

Ethernet/Internet port

Port LEDs

Power port

Side components

Button	Description
Power button	Use the included AC power adapter to connect this port to the power source.
WPS (Wi-Fi Protected Setup) button	Enables you to configure Wi-Fi security on WPS-enabled devices.
Frequency switch	Switch to configure the extender to connect at either 2.4 GHz or 5.0 GHz frequency band.
Ethernet (LAN) or Internet port	Use an Ethernet (network) cable to connect wired network devices to these ports. or Use an Ethernet (network) cable to connect this port to a modem.
Power port	Use the included AC power adapter to connect this port to the power source.

Port LED indicators

Component	LED	Description
Ethernet port	Link LED (Green)	Steady on when a cable connects the port to another Ethernet port.
	Activity LED (Yellow)	Blinks to indicate network activity of that Ethernet port.
Internet port	Link LED (Green)	On when a cable connects the port to the modem.
	Activity LED (Yellow)	Blinks to indicate network activity on that port.

Back (not shown)

Component	Description
Reset button	Press and release —Reboots the extender. When the reset finishes, the Power LED blinks. Press and hold for 5 seconds or longer —Resets to factory default settings.

3

Getting Started

This chapter contains the following topics:

- [Setting up the Extender with a WPS Enabled Router](#)
- [Setting up Your Extender Manually](#)

Setting up the Extender with a WPS Enabled Router

If your router is WPS enabled, follow the steps below. If your router is not WPS enabled or you are experiencing interference problems, go to “Setting up Your Extender Manually” on page 9.




1. Set the frequency switch to the frequency of the router (2.4 GHz or 5.0 GHz).
 - Note:* If you don't know whether your router is dual-band, leave the switch set to 2.4 GHz.
2. Connect the extender to a power source and press the **Power** button.
3. If WPS is enabled on your router, press the Wi-Fi Protected Setup button (sometimes labeled **WPS**) on your router and within two minutes, press the **WPS** button on the extender.

Note: If your router does not support WPS, see “Setting up Your Extender Manually” on page 9.

The wireless connection light is blue when the extender's wireless connection is active.

4. Launch a web browser and enter **http://WDRangeextender** or **http://192.168.1.230** in the address field. The Home page of the Dashboard, the extender's user interface) displays.



5. Continue with “Configuring the Extender for the First Time” on page 11.

Setting up Your Extender Manually

There are cases where you may need to set up the extender manually, for example when:

- Wi-Fi Protected Setup (WPS) is disabled.
 - The router does not support WPS.
 - Some interference is preventing WPS from working.
1. You have two options:
 - Connect the Extender and your PC, Mac computer, or laptop using an Ethernet cable,


-OR-

 - Connect a wireless-enabled PC, Mac, or laptop to Network Name: **WDRangeExtender**.

Note: This is an open network without security.



2. Launch a web browser. If the extender's Welcome page does not appear automatically, enter **http://WDRangeExtender** or **http://192.168.1.230** as the address to display it.




Note: If the entries in the address field do not access the Welcome screen, enter the address of any website (e.g., Amazon.com) and the browser will redirect to the extender's Dashboard.

3. Continue with "Configuring the Extender for the First Time" on page 11.


Configuring the Extender for the First Time

Option #1-WPS is Not Enabled on the Router

1. On the Welcome page, select a language in the upper right corner (defaults to English) and make sure that **Mode** displays **range extender** (the default value).
2. Click **Next** to display the Welcome screen.




3. Click **Next** to display the Select an available network screen. After a few minutes the screen displays a list of networks.



4. Select a **Network Name** (or another item in its row) and click **Connect** to display the Secure Network Connection screen displays.



5. Enter the router's Network Key and click **Enter**.
The Setup Complete screen displays.




6. Click **I'm Done**

Note: From the Setup Complete screen, you can navigate to screens for registering your extender and adding a new device to your network. If you choose to perform these tasks before configuring the extender, see “Registering Your WD Product” on page 2 and “Adding a Wireless Device to Your Network” on page 20.


7. Continue with “Configuring the Extender for the First Time” on page 11.

Option #2–WPS is Enabled on the Router


1. On the Welcome page, select a language in the upper right corner (defaults to English) and make sure that **Mode** displays **range extender** (the default value). Click **Next** to display the Welcome screen.




2. Click **Next** to display the Select an available network screen. After a few minutes the screen displays a list of networks.



3. Select a **Network Name** (or another item in its row) and click **Connect** to display the Network Key is required screen displays.




4. Click **Use WPS** to display the Wi-Fi Protected Setup page.



- a. Press both the **WPS** button on the extender (or the virtual **WPS** button on the screen) and the **WPS** button on the router within two minutes.
-OR-
If your router has an 8-digit security PIN, enter it and click **Connect**.
- b. Click **WPS** to display the progress of the connection.
The Setup Complete page displays. The extender is now connected to the router

wirelessly.



Note: To add a new wireless device to your network, click the **Add a New Device to My Network** link. See “Adding a Wireless Device to Your Network” on page 20. To configure more settings, or to begin using the extender as is, click **I’m Done**. See -

4

Configuring Basic Settings


This chapter contains the following topics:

- [Opening My Dashboard After Setup](#)
- [Configuring Wireless Settings](#)
- [Adding a Wireless Device to Your Network](#)


Opening My Dashboard After Setup

To open the My Net Wi-Fi Range Extender dashboard after initial configuration:

1. Enter **http://WDRangeextender** in the address field of your browser. The login screen displays:



2. Enter the extender's username (default value is **admin**) and password (default value is lowercase **password**) and click **Submit**. The My Dashboard home screen displays:




The icons at the top of the screen open modules and wizards for performing important tasks. The red **Alert** icon at the upper right of the screen displays notices concerning the extender.

Icon	Name	Actions	See ...
	My Dashboard	Review and change current settings.	"Configuring Basic Settings" on page 16
	Connect to Internet	Connect the extender to the Internet and follow the wizard through the process of setting up the Internet connection.	"Connecting to the Internet" on page 17
	Set up Wireless	Configure wireless settings such as network name and security.	"Configuring Wireless Settings" on page 17
	Add a Device	Add a wireless device and configure its security settings.	"Configuring Advanced Settings" on page 23
	Advanced Settings	Configure advanced settings for system administration such as firmware upgrades.	"Configuring Advanced Settings" on page 23
	Alert	Click to display recent alerts about new firmware and network issues and shortcuts to important settings.	

Reviewing Current Settings

The My Dashboard's home screen is a simple snapshot of the extender's configuration with the most essential information in one screen. It includes summary information for wireless settings and status.



1. Review the following settings:

Setting	Description
Network Name	Unique identifier of the 2.4 GHz or 5.0 GHz network, depending on your selection on the frequency switch.
Network Key	Password for accessing the wireless network.
Mode	From the drop-down list, select Wireless Range extender or AP (Access Point)
Status	Status can be Unconfigured , Configured and Connected , or Unconnected .
Number of Devices Connected	Number of devices connected to the extender.

2. To reconfigure wireless settings, click one of the **Set up Wireless** links on the screen or the **Set up Wireless** icon in the icon bar. Continue with “Configuring Wireless Settings” on page 19.

Configuring Wireless Settings

1. Click the **Set up Wireless** icon.

Note: Alternatively, on the My Dashboard home screen, you can click the **Set up**

2. View or modify the required wireless settings of the extender:

Setting	Description
Network Name	Name given to the wireless network.
Network Frequency	Toggle to 2.4 GHz or 5.0 GHz.
Password	Password for accessing the wireless network.
Wireless Security mode	<p>Type of security applied to the wireless network. The default is WPA-Personal/WPA2-Personal.</p> <p>WPA (Wi-Fi Protected Access) and WPA2 are security protocols that use a dynamically changing key. WPA2 is the second generation protocol that uses stronger AES (Advanced Encryption Standard) encryption. The third option is None.</p> <p>WPA/WPA2 mixed security mode provides better compatibility with legacy devices. However, for better performance and connectivity, WPA2 security mode is highly recommended.</p>
Mode	<p>Wireless Range extender (the default value).</p> <p>Note: If you select AP, continue to “Troubleshooting” on page 28.</p>

Setting	Description
Connection Type	<p>Can be Static IP, Dynamic IP (DHCP), PPPoE (Username/Password), or PPTP (Username/Password).</p> <p>If you select Static IP, the following additional fields display:</p> <ul style="list-style-type: none"> ▪ IP address—IP address of the Extender. It should be on the same network as your router. ▪ Subnet—The subnet mask is used to control how many subnetworks can exist in your local network. The more subnetworks there are, the fewer the hosts you can have per subnet. ▪ Gateway—IP address of the router to which this extender is connected.
Status	Status can be Unconfigured , Configured and Connected , or Unconnected .
Number of Devices Connected	Number of devices connected to the extender.
QoS Enabled	Enable or disable the Fastrak QoS application, which prioritizes different client applications/traffic types over the Internet.

3. Click **Save**.


Adding a Wireless Device to Your Network

Once you configure wireless settings on the extender, you can easily connect wireless devices such as games, notebooks, laptops, tablets, PDAs, or smartphones to the Internet and to other devices on the network.

Note: Consult the device's user guide for guidance on finding and changing its wireless network settings.

To connect a WPS-enabled wireless device, you either press the **WPS** button on the front of the extender or enter a PIN on the device's Wi-Fi connection page. If the device is not capable of WPS, you can still connect to the extender using a network name and password.

1. On the Dashboard, click the **Add a Device** icon.



2. **If your device does not support WPS**, when prompted by the device:
 - a. Enter the following into your wireless device's Wi-Fi connection screen:
 - The Wi-Fi network name for the wireless network you want to use
 - The password for the wireless network you selected

Note: By default there is no password. If you establish a password during setup, that password displays in the password field.
 - b. Continue to step 6 to confirm that the device has been added.
3. **If the new device supports WPS**, click the **Click Here** link at the top right of the screen to display the Secure Network Connection screen.




4. Follow the appropriate procedure below:
 - a. **Setup 1:** Press the **WPS** button on the front of the extender or click the virtual button on this screen. On your wireless device, press the physical **WPS** button or click the virtual **WPS** button.


- b. **Setup 2:** If prompted by your wireless device, enter the extender's WPS PIN shown on the screen into your wireless device.

Note: The label on the bottom of the extender displays the default PIN. You can change the PIN on the Wi-Fi Protected Setup screen. Once you change the PIN, the default value is invalid unless you reset the extender to default values. If your device requests the extender's PIN, enter the PIN shown on the screen.

5. Click **WPS**.



6. To confirm that the device has been added, click **Confirm**.
7. The Confirmation screen displays the attached devices in the Client Table.



8. Click **OK** to return to the My Dashboard home screen.

5

Configuring Advanced Settings

The **Advanced Settings** icon provides screens for registering the extender, changing administrative password, updating the extender's firmware, restoring factory settings, and rebooting the extender.

This chapter contains the following topics:


- [Changing the Administrator Password](#)
- [Updating the Extender's Firmware](#)
- [Setting up the Extender in AP Mode](#)

Note: To close an Advanced Settings screen, click the **Close** button at the top of the screen. The My Dashboard home screen displays.

Changing the Administrator Password

The admin account manages the extender interface. The admin has read/write access and can create passwords. The default password is **password**; to keep your extender secure, it is a best practice to create a new password. To change the administrator password:

1. Click the **Advanced Settings** icon and then the **Administrator** tab (link) on the left to display the Admin/Administrator screen.



The screenshot shows the 'Advanced Settings' interface. At the top, there's a header with 'Welcome to My Net WiFi Range Extender', 'Firmware Version 1.00.02', and a notification 'You have more notifications'. Below the header is a 'Close' button. The main content area is titled 'Admin / Administrator'. On the left, there's a navigation menu with 'Admin' selected. The main content area is titled 'Admin Password' and contains the following text: 'The 'admin' account can access the management interface. The admin has read/write access and can change the password. The default admin password is 'password'. It is highly recommended that you create a new password to keep your range extender secure.' Below this text are three input fields: 'Original Password', 'New Password', and 'Verify New Password'. At the bottom right, there are 'Cancel' and 'Save' buttons.

2. Enter the existing administrator password in **Original Password** and the new administrator password in the **Password** and **Verify Password** fields. Click **Save**.


Resetting and Rebooting the Extender

Resetting to Factory Defaults

You may want to reset the extender to how it was when you bought it. You have two options for restoring factory defaults: through the user interface or through the **Reset** button on the bottom of the extender.

To use the user interface:

1. Click the **Advanced Settings icon** and then the **System** tab (link).



2. Click **Reset** to the right of **Reset to Factory Default Settings**.
3. When a confirmation message displays, click **OK**.
4. Wait until the extender reboots before using it.

To reset the extender manually:

1. Press and hold the **Reset** button on the bottom of the extender for at least 10 seconds. When the reset finishes, the Power LED blinks.

Important: Do not reboot the extender or close the application while the update is taking place.

Rebooting

WARNING! To avoid data loss, before rebooting, stop all network and read/write activities.

You can reboot the extender two ways. If you are physically close to it, just press the **On/Off** button on the extender. If you cannot easily press the button:


1. Click the **Advanced Settings icon** and then the **System** tab (link).
2. Click **Reboot**.

Updating the Extender's Firmware

Check for extender firmware updates and upload new firmware.

Note: For best results, upload the firmware using a wired connection.

1. Click the **Advanced Settings icon** and then the **Administrator icon**.
2. Click the **Firmware Update tab**.



To check for the latest firmware version:

Important: Do not disconnect or turn off the extender while the update is in process.

1. Click **Check Now**. The extender searches the WD website for a new firmware file. If a new file exists, the latest firmware version and an **Update Now** button appear.
2. Click **Update Now** to begin the firmware update. A message tells you how long the upload will take. Please wait while the firmware update is taking place.

To update from a file:

1. Locate the firmware file on the WD Support site at <http://support.wdc.com> and download it to your computer.
2. On the extender screen, browse to the firmware file you saved and click **Open**. The file name displays in the browser field on the extender screen.
3. Click **Upload**. A message says how long the upload will take. Please wait while the firmware update is taking place.

6

Setting up the Extender in AP Mode


The difference between extender mode and access point mode is that an extender has a wireless uplink to the router and an access point has a wired uplink to the router.

Note: Choosing to change the mode is a somewhat advanced task.


To set up an extender in AP mode, first connect it to a PC or Mac computer or a laptop using an Internet cable (see “Setting up Your Extender Manually” on page 9), and then change its mode to AP mode. To use the extender as an access point, connect the extender directly to your router using an internet cable.

You can set up the extender in AP mode from the Welcome screen on the Wireless Settings page.

1. Launch a web browser, and type **WDRangeextender** in the address field.
2. Do one of the following:
 - If the Welcome page displays, set **Mode** to **AP** and click **Next**:



The My Dashboard Home page displays the mode as Wireless range extender:




-OR-

- If the extender has been set up in **range extender** mode (default), on the My Dashboard screen change Mode to Wireless Range Extender. Edit **Network Name**



3. Click **Save**. The Setup Complete screen displays.



4. Click **I'm Done**. The Dashboard Home screen displays.
5. Disconnect the extender from the computer and connect it directly to the router using a network cable. The Access Point is ready for use.

8

Troubleshooting

Problem	Solution
The power LED does not illuminate.	<ol style="list-style-type: none"> 1. Ensure that the power cord is correctly connected to the extender. 2. Ensure that the electrical outlet is working properly. To do this, plug a different electronic device into the outlet and try to power it on. 3. Ensure that you are using the AC adapter provided with the extender.
A port number LED does not illuminate.	<ol style="list-style-type: none"> 1. Ensure that the connected device is powered on. 2. Ensure that the Ethernet cable(s) are securely connected to the ports on both the device and the extender. 3. To ensure that the cable between the extender and the electronic device is working properly, replace it with another cable.
Computers are unable to access the Internet.	<ol style="list-style-type: none"> 1. Ensure that the extender is powered on. The power LED should be solid and not flashing. 2. Check the cable connections between the modem, extender and computer. The Ethernet cable connected to your modem should be connected to the Internet port on the extender. An Ethernet cable from your computer should be connected to a LAN port on the side of the extender. 3. Power off and power on your modem, extender, and computer. 4. If all else fails, install My Net View from the product CD or contact Technical Support at http://support.wdc.com or your ISP.
All front panel LEDs flash continuously.	<ol style="list-style-type: none"> 1. Relocate your extender to a place that has good ventilation. 2. Turn off your extender, and set it aside for 15 to 20 minutes until it cools down. Turn your extender back on to resume operation. 3. If the problem persists, contact Technical Support at http://support.wdc.com.
The extender has a weak signal	<ol style="list-style-type: none"> 1. Tune as described in "" on page 8.

9

Regulatory and Warranty Information

This chapter contains the following topics:

- [Regulatory Compliance](#)
- [Warranty Information \(All Regions Except Australia/New Zealand\)](#)
- [Warranty Information \(Australia/New Zealand only\)](#)
- [GNU General Public License \(“GPL”\)](#)

Regulatory Compliance

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Regulatory Information/Disclaimers

Installation and use of this Wireless LAN device must be in strict accordance with the instructions included in the user documentation provided with the product. Any changes or modifications (including the antennas) made to this device that are not expressly approved by the manufacturer may void the user’s authority to operate the equipment. The manufacturer is not responsible for any radio or television interference caused by unauthorized modification of this device, or the substitution of the connecting cables and equipment other than manufacturer specified. It is the responsibility of the user to correct any interference caused by such unauthorized modification, substitution or attachment. Manufacturer and its authorized resellers or distributors will assume no liability for any damage or violation of government regulations arising from failing to comply with these guidelines.

For operation within 5.15 ~ 5.25 GHz frequency range, it is restricted to indoor environment. This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.

CAUTION: To comply with FCC RF exposure compliance requirements, the antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: The country code selection is for non-US models only and is not available for all US models. Per FCC regulations, all WiFi products marketed in the US must be fixed to US operation channels only.

Industry Canada (IC)

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Ce dispositif est conforme à la norme CNR-210 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

CAUTION! The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

AVERTISSEMENT! Les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

Radiation Exposure Statement: This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

Déclaration d'exposition aux radiations: Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

ICES-003/NMB-003 Statement

Cet appareil numérique de la classe B est conforme à la norme ICES-003 du Canada.

This device complies with Canadian ICES-003 Class B.

This product is intended to be supplied by a listed limited power source, double insulated, or direct plug-in power unit marked "Class 2."

Safety Compliance

Approved for US and Canada. CAN/CSA-C22.2 No. 60950-1, UL 60950-1: Safety of Information Technology Equipment.

Approuvé pour les Etats-Unis et le Canada. CAN/CSA-C22.2 No. 60950-1, UL 60950-1: Sûreté d'équipement de technologie de l'information.

This device is only for use with the compatible UL Listed AC adapter.

Cet appareil n'est destiné qu'à des adaptateurs compatibles marqués "UL Listed".

以下警語適用台灣地區

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

For Mexico Only

La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

For Russia FAC DoC Only

For Brazil Only

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não causar interferência a sistema operando em caráter primário.

CE Compliance for Europe

Operation of this device is subjected to the following National regulations and may be prohibited to use if certain restriction should be applied.

Marking by the CE symbol indicates compliance of this system to the applicable Council Directives of the European Union, including the EMC Directives (2004/108/EC), (1999/5/EC), the Low Voltage Directive (2006/95/EC), and EuP Directive (2005/32/EC). A "Declaration of Conformity" in accordance with the applicable directives has been made and is on file at Western Digital Europe.

Die Kennzeichnung mit dem CE-Symbol zeigt an, dass dieses System die anwendbaren Richtlinien der Europäischen Union erfüllt, einschließlich der EMV-Richtlinien (2004/108/EG), (1999/5/EG), der Niederspannungsrichtlinie (2006/95/EG) und der Richtlinie (2005/32/EG) des Europäischen Parlaments. Eine „Konformitätserklärung“ gemäß den anwendbaren Richtlinien wurde abgegeben und kann bei Western Digital Europe eingesehen werden.

Le symbole CE sur l'appareil indique la conformité de cet appareil avec les directives applicables du Conseil de l'Union Européenne, dont les directives EMC (2004/108/EC), (1999/5/EC), la directive sur les limites de tension (2006/95/EC) et la directive EuP (2005/32/EC), si applicable. Une « déclaration de conformité » conforme aux directives applicables a été effectuée et est consultable chez Western Digital Europe.

Il marchio CE indica la conformità del sistema alle direttive applicabili del Consiglio dell'Unione europea, tra cui le Direttive EMC (2004/108/CE), (1999/5/CE), la Direttiva Bassa Tensione (2006/95/CE), e la Direttiva EuP (2005/32/CE). Una "Dichiarazione di conformità" redatta in base alle direttive vigenti è disponibile presso Western Digital Europe.

La marca con el símbolo CE indica el cumplimiento de este sistema de las Directivas del Consejo de la Unión Europea correspondientes, incluidas las directivas EMC (2004/108/EC) y (1999/5/EC), la Directiva de bajo voltaje (2006/95/CE) y la Directiva EuP (2005/32/EC). Se

ha realizado una "Declaración de conformidad" de acuerdo con las directivas aplicables y se encuentra archivada en Western Digital Europe.

CE-märkningen innebär att detta system uppfyller Europeiska Unionens tillämpliga rådsdirektiv, inklusive EMC-direktivet (2004/108/EC), (1999/5/EC), lågspänningsdirektivet (2006/95/EC) och EuP-direktivet (2005/32/EC). En "Konformitetsdeklaration" i enlighet med gällande direktiv har gjorts och finns arkiverad hos Western Digital Europe.

Merking med CE-symbolet indikerer at dette systemet samsvarer med gjeldende direktiver (council directives) for EU, inkludert EMC-direktiv (2004/108/EF), (1999/5/EF), Lavspenningsdirektiv (2006/95/EF) og EuP-direktiv (2005/32/EF). En "Samsvarserklæring" i henhold til gjeldende direktiver har blitt opprettet og er i Western Digital Europas arkiver.

CE-merkintä osoittaa tämän järjestelmän yhdenmukaisuuden sovellettavissa olevien Euroopan yhteisön neuvoston direktiivien kanssa, mukaan lukien EMC-direktiivi (2004/108/EC), (1999/5/EC), alijännitedirektiivi (2006/95/EC) sekä EuP-direktiivi (2005/32/EC). "Noudattamisjulistus" on jätetty asiaankuuluvien direktiivien mukaisesti, ja se on tallessa Western Digital Europessa.

Mærkning med CE-symbolet angiver at systemet overholder Europaparlamentets og Rådets direktiver, herunder EMC-direktiverne (elektromagnetisk kompatibilitet) (2004/108/EC), (1999/5/EC) og lavspændingsdirektivet (2006/95/EC) og EuP-direktivet 2005/32/EC. En "Declaration of Conformity" (overensstemmelsesattestering) i henhold til gældende direktiver er afgivet og opbevares hos Western Digital Europe.

Маркировка символом CE свидетельствует о соответствии настоящей системы положениям применимых директив Совета Европейского Союза, в том числе директив об электромагнитной совместимости (2004/108/EC, 1999/5/EC), директивы о низковольтном оборудовании (2006/95/EC) и директивы об устройствах, использующих электроэнергию (2005/32/EC). Заявление о соответствии положениям применимых директив, сделанное компанией Western Digital, находится в архиве её европейского подразделения.

Η σήμανση με το σύμβολο CE υποδεικνύει ότι το σύστημα αυτό συμμορφώνεται με τις ισχύουσες οδηγίες του Συμβουλίου της Ευρωπαϊκής Ένωσης, συμπεριλαμβανομένων των οδηγιών περί ηλεκτρομαγνητικής συμβατότητας (2004/108/ΕΚ), (1999/5/ΕΚ), της οδηγίας περί χαμηλής τάσης (2006/95/ΕΚ) και της οδηγίας του Ευρωπαϊκού Κοινοβουλίου (2005/32/ΕΚ). Έχει πραγματοποιηθεί μία «Δήλωση συμμόρφωσης», σύμφωνα με τις ισχύουσες οδηγίες και τηρείται στα αρχεία της Western Digital Ευρώπης.

يشير التمييز بوضع الرمز CE إلى توافق هذا النظام مع توجيهات المجلس القابلة للتطبيق والخاصة بالاتحاد الأوروبي، بما في ذلك توجيهات التوافقية الكهرومغناطيسية (EMC) (2004/108/EC) وتوجيهات الجهد الكهربائي المنخفض (2006/95/EC) وتم وضع "إعلان المطابقة" وفقًا للتوجيهات القابلة للتطبيق وهو موجود في ملف على Western Digital Europe.

Environmental Compliance (China)

产品中有毒有害物质或元素的名称及含量

部件名称	有毒有害物质或元素					
	铅	汞	镉	六价铬	多溴联苯	多溴二苯醚
机壳/机箱	X	0	0	0	0	0
电路板组合 / 板卡	X	0	0	0	0	0
电源变压器 / 电源供应器	X	0	0	0	0	0
硬盘	X	0	0	0	0	0

0: 代表此种部件的所有均质材料中所含的该种有毒有害物质均低于中华人民共和国信息产业部所颁布的《电子信息产品中有毒有害物质的限量要求》(SJ/T 11363-2006) 规定的限量。
X: 代表此种部件所用的均质材料中, 至少有一类材料其所含的有毒有害物质高于中华人民共和国信息产业部所颁布的《电子信息产品中有毒有害物质的限量要求》(SJ/T 11363-2006) 规定的限量

除非产品上另有标记, 所有内附产品及其部件的‘环保使用期限’均由此显示的符号表示。此环保使用期限只适用于产品手册中所规定的使用条件。
(在此表中, 企业可能需要根据实际情况对标记“X”的项目进行进一步的技术性解释。)



Warranty Information (All Regions Except Australia/New Zealand)

Project Name	Product Name	PanAm	EMEA	UK	Japan	APAC	ANZ
Starfish	TBD	1-year	2-year	2-year	1-year	1-year	1-year

Limited Warranty

WD warrants that the Product, in the course of its normal use, will for the term defined below, be free from defects in material and workmanship and will conform to WD's specification therefor. The term of your limited warranty depends on the country in which your Product was purchased. The term of your limited warranty is for 1 year in the North, South and Central America region, 2 years in the Europe, the Middle East and Africa region, and 1 year in the Asia Pacific region, unless otherwise required by law. The term of your limited warranty period shall commence on the purchase date appearing on your purchase receipt. WD may at its discretion make extended warranties available for purchase. WD shall have no liability for any Product returned if WD determines that the Product was stolen from WD or that the asserted defect a) is not present, b) cannot reasonably be rectified because of damage occurring before WD receives the Product, or c) is attributable to misuse, improper installation, alteration (including removing or obliterating labels and opening or removing external enclosures, unless the product is on the list of limited user-serviceable products and the specific alteration is within the scope of the applicable instructions, as found at <http://support.wdc.com>), accident or mishandling while in the possession of someone other than WD. Subject to the limitations specified above, your sole and exclusive warranty shall be, during the period of warranty specified above and at WD's option, the repair or replacement of the Product with an equivalent or better Product. The foregoing warranty of WD shall extend to repaired or replaced Products for the balance of the applicable period of the original warranty or ninety (90) days from the date of shipment of a repaired or replaced Product, whichever is longer.

The foregoing limited warranty is WD's sole warranty and is applicable only to products sold as new. The remedies provided herein are in lieu of a) any and all other remedies and warranties, whether expressed, implied or statutory, including but not limited to, any implied warranty of merchantability or fitness for a particular purpose, and b) any and all obligations and liabilities of WD for damages including, but not limited to accidental, consequential, or special damages, or any financial loss, lost profits or expenses, or lost data arising out of or in connection with the purchase, use, or performance of the Product, even if WD has been advised of the possibility of such damages. In the United States, some states do not allow exclusion or limitations of incidental or consequential damages, so the limitations above may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Obtaining Service

WD values your business and always attempts to provide you the very best of service. If this Product requires maintenance, either contact the dealer from whom you originally purchased the Product or visit our product support Web site at <http://support.wdc.com> for information on how to obtain service or a Return Material Authorization (RMA). If it is determined that the Product may be defective, you will be given an RMA number and instructions for Product return. An unauthorized return (i.e., one for which an RMA number has not been issued) will be returned to you at your expense. Authorized returns must be shipped in an approved shipping container, prepaid and insured, to the address provided on your return paperwork. Your original box and packaging materials should be kept for storing or shipping your WD product. To conclusively establish the period of warranty, check the warranty expiration (serial number required) via <http://support.wdc.com>. WD shall have no liability for lost data regardless of the cause, recovery of lost data, or data contained in any Product placed in its possession.

Warranty Information (Australia/New Zealand only)

For consumers purchasing products in Australia and New Zealand, please refer to this warranty information.

Nothing in this warranty modifies or excludes your legal rights under the Australian Competition and Consumer Act or the New Zealand Consumer Guarantees Act. This warranty identifies WD's preferred approach to resolving warranty claims which is likely to be quick and simple for all parties.

No other warranties either express or implied by law, including but not limited to those contained in the Sale of Goods Act, are made with respect to the Product. If you purchased your Product in New Zealand for the purposes of a business, you acknowledge and agree that the New Zealand Consumer Guarantees Act does not apply.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure. What constitutes a major failure is set out in the Australian Consumer Law.

Warranty

WD warrants that the Product, in the course of its normal use, will for the term defined below, be free from defects in material and workmanship and will conform to WD's specifications. The term of your warranty is 1 year in Australia and New Zealand, unless otherwise required by law. The term of your warranty period shall commence on the purchase date appearing on your purchase receipt from an authorized distributor or authorized reseller. Proof of purchase shall be required to be eligible for this warranty and to establish the commencement date of this warranty. Warranty service will not be provided unless the Product is returned to an authorized distributor, authorized reseller or regional WD return center where the Product was first shipped by WD. WD may at its discretion make extended warranties available for purchase. WD shall have no liability for any Product returned if WD determines that the Product was (i) not purchased from an authorized distributor or authorized reseller, (ii) not used in accordance with WD specifications and instructions, (iii) not used for its intended function, or (iv) stolen from WD, or that the asserted defect a) is not present, b) cannot reasonably be rectified because of damage occurring before WD receives the Product, or c) is attributable to misuse, improper installation, alteration (including removing or obliterating labels and opening or removing external enclosures, including the mounting frame, unless the product is on the list of limited user-serviceable products and the specific alteration is within the scope of the applicable instructions, as found at <http://support.wdc.com>), accident or mishandling while in the possession of someone other than WD.

PRODUCTS ARE COMPLEX AND FRAGILE ITEMS THAT MAY OCCASSIONALLY FAIL DUE TO (A) EXTERNAL CAUSES, INCLUDING WITHOUT LIMITATION, MISHANDLING, EXPOSURE TO HEAT, COLD, AND HUMIDITY, AND POWER FAILURES, OR (B) INTERNAL FAULTS. SUCH FAILURES CAN RESULT IN THE LOSS, CORRUPTION, DELETION OR ALTERATION OF DATA. NOTE THAT YOU SHALL BE RESPONSIBLE FOR THE LOSS, CORRUPTION, DELETION OR ALTERATION OF DATA HOWSOEVER CAUSED, AND FOR BACKING UP AND PROTECTING DATA AGAINST LOSS, CORRUPTION, DELETION OR ALTERATION. YOU AGREE TO CONTINUALLY BACK UP ALL DATA ON THE PRODUCT, AND TO COMPLETE A BACKUP PRIOR TO SEEKING ANY GENERAL SERVICE AND TECHNICAL SUPPORT FROM WD.

In Australia, if the Product is not of a kind ordinarily acquired for personal, domestic or household use or consumption, provided it is fair and reasonable to do so, WD limits its liability to replacement of the Product or supply of equivalent or better Product.

This warranty shall extend to repaired or replaced Products for the balance of the applicable period of the original warranty or ninety (90) days from the date of shipment of a repaired or replaced Product, whichever is longer. This warranty is WD's sole manufacturer's warranty and is applicable only to Products sold as new.

Obtaining Service

WD values your business and always attempts to provide you the very best of service. Should you encounter any problem, please give us an opportunity to address it before returning this Product. Most technical support questions can be answered through our knowledge base or e-mail support service at <http://support.wdc.com>. If the answer is not available or, if you prefer, please contact WD at the applicable telephone number shown in the front of this document.

If you wish to make a claim, you should initially contact the dealer from whom you originally purchased the Product. If you are unable to contact the dealer from whom you originally purchased the Product, please visit our product support Web site at <http://support.wdc.com> for information on how to obtain service or a Return Material Authorization (RMA). If it is determined that the Product may be defective, you will be given an RMA number and instructions for Product return. An unauthorized return (i.e., one for which an RMA number has not been issued) will be returned to you at your expense. Authorized returns must be shipped in an approved shipping container, prepaid and insured, to the address provided with your RMA number. If following receipt of a qualifying claim under this warranty, WD or the dealer from whom you originally purchased the Product determines that your claim is valid, WD or such dealer shall, at its discretion, either repair or replace the Product with an equivalent or better Product or refund the cost of the Product to you. You are responsible for any expenses associated with a claim under this warranty. The benefits provided to you under this warranty are in addition to other rights and remedies available to you under the Australian Competition and Consumer Act or the New Zealand Consumer Guarantees Act.

Your original box and packaging materials should be kept for storing or shipping your WD product. To conclusively establish the period of warranty, check the warranty expiration (serial number required) via <http://support.wdc.com>.

Western Digital Technologies, Inc.
3355 Michelson Drive, Suite 100
Phone: 949-672-7000
E-mail: support@wdc.com

GNU General Public License (“GPL”)

Firmware incorporated into this product may include third party copyrighted software licensed under the GPL or Lesser General Public License (“LGPL”) (collectively, “GPL Software”) and not Western Digital’s End User License Agreement. In accordance with the GPL, if applicable: 1) the source code for the GPL Software may be downloaded at no charge from <http://support.wdc.com/download/gpl> or obtained on CD for a nominal charge from <http://support.wdc.com/download/gpl> or by calling Customer Support within three years of the date of purchase; 2) you may re-use, re-distribute, and modify the GPL Software; 3) with respect solely to the GPL Software, no warranty is provided, to the extent permitted by applicable law; and 4) a copy of the GPL is included herewith, may be obtained at <http://www.gnu.org>, and may also be found at <http://support.wdc.com/download/gpl>.

Modification of or tampering with the Software, including but not limited to any Open Source Software, is solely at your own risk. Western Digital is not responsible for any such modification or tampering. Western Digital will not support any product in which you have or have attempted to modify the Software supplied by Western Digital.

Appendix: Technical Specifications

Specification	Value
Wireless standard	IEEE 802.11n client
Ethernet	1 x Gigabit Ethernet
I/O ports	(1) Ethernet (RJ-45) port
Bands	2.4 GHz and 5.0 GHz selectable dual mode
MIMO mode	3x3 (2.4 GHz), 3x3(5 GHz)
Security	WPA/WPA2-PSK WEP
QoS	
Firewall	N/A
Supported operating systems	Windows XP with Service Pack 3
	Windows Vista with Service Pack 2
	Windows 7 with Service Pack 1
	Mac OS X Leopard
	Mac OS X Snow Leopard
	Mac OS X Lion
Supported web browsers	Internet Explorer 7 and later
	Safari 2 and later
	Firefox 2 and later
	Chrome 7 and later
Physical dimensions	Length: 6.0" (153.48 mm)
	Width: 5.2" (132 mm)
	Height: 2.0" (51 mm)
Power supply	Input voltage: 100V to 240V AC
	Input frequency: 50 to 60 Hz
	Output voltage: 12V DC, 3A
	Power supply: 36W
Temperature	
	Non-operating temperature: -? to ?°C (-? to ? °F)

Index

A

AC power adapters 6
 access point setup 74
 accessing files remotely 4
 accessing internal drive and external USB storage 68
 accessories 5
 adding a wireless device 28
 Additional Features screens 48
 additional software 4
 Admin screens 56
 administrator password 67
 Advanced LAN screens 43
 Advanced Settings screens 35
 advanced tasks 61
 Advanced WAN (Internet) screens 36
 Advanced Wireless screens 41
 attached storage, accessing files on 68

B

back panel of extender 7
 basic wireless settings 24
 bottom of extender 8
 box contents 5
 button
 Close 35
 On/Off 13
 Reset 8
 WPS 7, 28

C

CD, getting started with 9
 changing admin password 67
 closing an Advanced Settings screen 35
 connecting to the Internet 23
 current settings 20

D

dashboard icons 21
 device not WPS enabled, connecting 28, 29
 DHCP server setup 75
 dual band speed 3

E

Easy Setup for Windows computers 9
 environmental compliance (China) 88
 external storage, setting up 26

F

factory defaults, restoring 73
 FasTrack Plus 3
 firmware updates 72
 front of extender/
 LEDs 7

G

GPL software 90
 guest access 4, 61

I

icons, dashboard 21
 installing the extender
 using a browser 13
 using Easy Setup (Windows PC) 9
 internal drive storage, accessing files on 68
 Internet
 connection 23
 security 4
 Internet Security & Parental Controls screen 49

K

Kensington security slot 8

L

LEDs
 back of extender 7
 front panel 7

M

MAC Filter screen 49
 My Dashboard
 accessing during setup 14
 current settings 22
 My Net software for Mac computers 17
 My Net View 4, 79

O

obtaining service 88
 obtaining service (Australia and New Zealand) 89
 operating precautions 1

P

package contents 5
 parental controls 4, 62
 port forwarding 77
 power adapters 6
 product
 accessories 5
 overview 3

- recording information 2
 - registration 2
 - safety information 1
 - warranty 88
- R**
- rebooting 73
 - recording product information 2
 - registering the extender 2
 - regulatory compliance 84
 - remote access 4
 - Remote Access screens 48
 - Reset button 8
 - restoring to factory defaults 73
 - RoHS 88
 - extender
 - as an access point 74
 - back panel 7
 - components, views, LEDs 6
 - front LEDs 7
 - front panel 6
 - installation 10
 - port LEDs 7
 - USB ports 3
 - wired speed 3
 - wireless speed 3
- S**
- safety instructions 1
 - screens
 - Admin 56
 - Administrator 57
 - Advanced lan 43
 - ALG 53
 - Connection Check 58
 - Device and Client Tables 44
 - Device Mode 59
 - DHCP Server Settings 44
 - DMZ 49
 - Dynamic DNS 40
 - Enhanced WMM (My Net N900) 55
 - FasTrack Plus QoS 54
 - Firewall 48
 - Firmware Update 58
 - Guest Access 43
 - Host and Lan Settings 44
 - Internet status 36
 - IPv6 40
 - IPv6 Status 40
 - Language 59
 - Log 59
 - MAC Filter 49
 - Network UPnP 55
 - Parental Controls 49
 - Port Forwarding 53
 - Registration 59
 - Routing 53
 - System 58
 - Time Settings 57
 - Wi-Fi Protected Setup (WPS) 42
 - Wireless Setup 41
 - service 88
 - service (Australia /New Zealand) 89
 - settings
 - advanced 35
 - basic 20
 - storage 26
 - setup
 - PC) 10
 - setup
 - options 10
 - Windows Vista/Win7 9
 - Windows XP 9
 - sharing a printer on the network 80
 - software, GPL 90
 - speed, wired 3
 - storage
 - attached USB drive 68
 - capacity 4
 - internal drive 68
 - settings 26
- T**
- tasks
 - advanced 61
 - basic 20
 - troubleshooting 83
- U**
- updating firmware 72
 - UPnP configuration 77
- W**
- warranty 88
 - warranty, Australia/New Zealand 89
 - WD Print Share 4, 80
 - WD Print Share, installing
 - on a Mac 81
 - WD Print Share, installing
 - on a Windows computer 80
 - WD Print Share, using 81
 - WD Quick View
 - accessing stored filee 68
 - description 4

WD Smartware	5	6	Setting up the Extender in AP Mode	26
Wi-Fi Protected Security(WPS)	4	7	Troubleshooting	28
wireless		8	Regulatory and Warranty Information	29
adding devices	28		Regulatory Compliance	29
settings	24		Warranty Information (All Regions Except Australia/New Zealand)	33
speed, simultaneous dual band	3		Warranty Information (Australia/New Zealand only)	34
WPS LED	7		GNU General Public License (“GPL”)	35
WPS-enabled device, connecting	28	9	Appendix: Technical Specifications	79
WD [®] Service and Support	3	10	Index	82
1	Important User Information			
	Important Safety Instructions			
	Recording Your WD Product Information			
2				
	Registering Your WD Product			
2	Product Overview			
	Introduction			
	Features			
	Package Contents			
	Components			
3	Getting Started			
	Setting up the Extender with a WPS Enabled Router			
	Setting up Your Extender Manually			
	Configuring the Extender for the First Time			
4	Configuring Basic Settings			
	Opening My Dashboard After Setup			
	Configuring Wireless Settings			
	Adding a Wireless Device to Your Network			
5	Configuring Advanced Settings			
23				
	Changing the Administrator Password			
	Resetting and Rebooting the Extender			
	Updating the Extender’s Firmware			