

PK5000Z

802.11g Wireless ADSL2+ 4-port Gateway

Quick Start Guide


Version 3.40
12/2009
Edition 1

The logo for ZyXEL, featuring the word "ZyXEL" in a bold, blue, italicized sans-serif font. The "Z" and "y" are lowercase, while "XEL" are uppercase. The letters are slanted to the right.

Overview

The PK5000Z is a wireless ADSL router with a four-port built-in switch.

This Quick Start Guide shows you how to use the PK5000Z to connect to the Internet and how to configure the device settings to connect wirelessly.



See your User's Guide for background information on all features.

Quick Login Information

LAN IP address	http://192.168.0.1
default administrator password	1234

1 Hardware Connections

- 1 DSL:** Use the gray telephone wire to connect your PK5000Z's **DSL** port to a telephone jack (or to the modem port on a splitter if you are using one).
- 2 ETHERNET:** Use the yellow Ethernet cable to connect a computer to an **ETHERNET** port for initial configuration and/or Internet access.
- 3 POWER:** Use the included power adaptor to connect an appropriate power source to the **POWER** socket. Make sure the power source is on.
- 4** Push in the **POWER** button.
- 5** Look at the lights on the front panel.
 - The **POWER** light blinks while your PK5000Z starts up and stays on once it is ready.
 - Each **ETHERNET** light stays on if the corresponding **ETHERNET** port is properly connected and blinks when there is traffic.
 - The **DSL** light is on when the PK5000Z has a DSL connection.
 - The **INTERNET** light is on when you are able to access the Internet and blinks when the PK5000Z is sending or receiving data. Wait a couple of minutes while your device checks the connection.

If any of these lights are not on, check your connections and inspect your cables for damage. If the lights are still off, contact your local vendor.

2 Internet Connection Setup: Automatic

Use this section to have your PK5000Z automatically detect and set up your Internet connection.

- 1** Open your web browser to a website. Wait while your PK5000Z tries to detect your DSL connection to your ISP. This may take a few minutes.
- 2** After it detects the connection, the DSL light shows green on your device and the Internet light comes on when the Internet is ready for you to use. If you have a PPPoE connection, you will have to enter your user name and password.
- 3** Go to section **3** if you wish to configure your wireless settings.
- 4** If you do not see the connection test screen, or the connection test is not successful, follow the instructions in the screen below, or check your connections and restart the PK5000Z. If you still cannot access the Internet, follow the steps in section **3**.

3 Configuring your Wireless Settings

To create a wireless network, the PK5000Z and your wireless computer must all use the same SSID (network name), channel and security settings.

If you do not set wireless security then anyone within range could use your PK5000Z to access your network and the Internet.

Choose WPA-PSK wireless security if your wireless device supports it as it is stronger than WEP. Otherwise choose WEP.

- 1 Select **Active** and click **Next** to continue. It is strongly recommended that **Enable OTIST** is NOT selected. See **section 7** for more information.
- 2 Configure your wireless settings in the screen. Click **Next**.
- 3) If you select either **WEP** or **WPA-PSK** security (recommended), then follow the directions to enter the appropriate key. Click **Next** to continue and **Apply** to save your wireless LAN settings.
- 4 Check your configuration and write down your wireless LAN settings for later use. Click **Finish** to complete and save the wizard setup.
- 5 Your Internet is ready for you to use. Open your browser and navigate to your favorite website.

4 Internet Connection Setup Using Advanced Settings

Use this section to set up your Internet connection manually if you do not see the **ISP Parameters for Internet Access** screen when you run the wizard (see **section 4**, step 4).

- 1 Login again. (Follow steps 1 to 5 in section 3.)
- 2 Select **Go to Advanced setup**. Then, click **Apply**.
- 3 The **Status** screen appears. Click **Network > WAN** in the navigation panel on the left of the screen.
- 4 Enter the information exactly as provided by your ISP. Click **Apply**.
- 5 If you still cannot access the Internet, see **Troubleshooting** and/or contact your Internet Service Provider (ISP) for assistance.

Troubleshooting

1 If you cannot access the web configurator,

- Your computer may be set to use a static IP address in a different subnet from the ZyXEL device. See the appendix in the User's Guide for information on setting up your IP address.
- If you are using Internet Explorer in Windows XP or Windows Server 2003, make sure you allow pop-up windows, JavaScripts and Java permissions or set the Internet security level lower than **High** in Internet Explorer (in Internet Explorer, click **Tools > Internet Options > Security > Custom Level...**). See the appendix in the User's Guide for more information.

2 If you cannot access the Internet when your computer is connected to the **ETHERNET** port, follow these steps.

A) Check the lights on the front panel. If they are different from what is described in section 1, make sure the PK5000Z is correctly connected. (See section 1.) If the lights are still different, turn off the device, wait a few seconds, and turn it on again.

B) Check you have correctly entered the information your ISP gave you. For example, if your account has a user name and password, make sure you type it correctly. In addition, if you are not sure which encapsulation your ISP uses, contact your ISP. If your ISP did not give you Internet connection information, follow the steps in section 2.

C) If you are using a new Internet account, contact your ISP to make sure it is active.

D) If you still have problems, see **Troubleshooting** in the User's Guide.


If you cannot access the Internet after you take the steps above, either try the following or contact your ISP:

E) Turn your PK5000Z off and on. Open your Internet browser if it is not already open.


Let the PK5000Z complete the DSL connection test (this may take several minutes). See section 2 for details.

If the test is successful, check whether you can access the Internet.

F) If the test is unsuccessful or if you cannot access the Internet, log in to the PK5000Z's web configurator (see section 3).

- Click **Network > WAN > Internet Connection**. Ensure that the settings in this screen are the same as those your ISP gave you. If your ISP gave you a static IP address to use, select **Static IP Address** in the **IP Address** section and enter it in the **IP Address** field. If not, select **Obtain an IP Address Automatically**. Click **Apply**.
- Click the wizard icon (). Run the **Internet/Wireless Setup** wizard again. Check whether you can access the Internet.

If you still cannot access the Internet, take the following steps:

- If you are using **Bridge** mode (check **Mode** in the **Network > WAN > Internet Connection** screen) click **NAT > General** and ensure **Active Network Address Translation (NAT)** is not selected. Click **LAN > DHCP Setup** and ensure that **DHCP** is set to **None**. Your ISP gives your computer an IP address directly. If you want to access the PK5000Z again, you need to use a static IP address in the same subnet as your PK5000Z (the PK5000Z's default IP address is <http://192.168.0.1>).
- Click the wizard icon (). Run the **Internet/Wireless Setup** wizard again. Check whether you can access the Internet.

If you still cannot access the Internet, contact your Internet Service Provider.

3 If you cannot access the Internet using the wireless network, follow these steps.

- A) On a computer in the wireless network, open your browser, and go to <http://192.168.0.1>. If you see the login screen in section 3, follow suggestions A - F above. If you do not, go to the next step.
- B) On a computer connected to the PK5000Z, make sure your PK5000Z and the computers on your wireless network are using the same wireless and wireless security settings. See the chapter on Wireless LAN in the User's Guide for more information.

Viewing Your Product's Certifications

- 1 Go to www.zyxel.com.
- 2 Select your product from the drop-down list box on the ZyXEL home page to go to that product's page.
- 3 Select the certification you wish to view from this page.

Customer Information Statement

The information informing the user of his/her and the telephone company's rights and obligations is outlined on the following pages. This information will be included in the final version of the manual.

Customer Information

- 1 This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On bottom of this equipment is a label that contains, among other information, a product identifier of QWEST Z9. If requested, this number must be provided to the telephone company.
- 2 If this equipment DL causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also you will be advised of your right to file a complaint with the FCC if you believe it is necessary.
- 3 The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modification to maintain uninterrupted service.
- 4 If you experience trouble with this equipment, you disconnect it from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning.
- 5 Please follow instructions for repairing if any (e.g. battery replacement section); otherwise do not alternate or repair any parts of device except specified.
- 6 Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.
- 7 If the telephone company requests information on what equipment is connected to their lines, inform them of:
 - a) The ringer equivalence number is 02
 - b) The USOC jack required RJ14, and
 - c) The FCC Registration Number US: 1RODL02BP660RD1V2

Item (a) and (c) are indicated on the label. The ringer equivalence number (REN) is used to determine how many devices can be connected to your telephone line. In most areas, the sum of the RENs of all devices on anyonelineshouldnotexceedfive(5.0).Iftoomanydevicesareattached,theymaynotringproperly.

8 If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment does not disable alarm equipment, consult your telephone company or a qualified installer.

Service Requirements

In the event of equipment malfunction, all repairs should be performed by our Company or an authorized agent. It is the responsibility of users requiring service to report the need for service to our Company or to one of our authorized agents.

Service can be facilitated through our office at:

ZyXEL Communications Corporation
6, Innovation Rd II, Science-Based Industrial Park, Hsin-Chu, Taiwan, R.O.C.
+886- 3-578-3942

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

(c) The provisions of paragraphs (a) and (b) do not apply to digital devices exempted from the technical standards under the provisions of Section 15.103.

(d) For systems incorporating several digital devices, the statement shown in paragraph (a) or (b) needs to be contained only in the instruction manual for the main control unit.

(e) In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that form.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.