Quick Start Guide

Cloud-Enabled Outdoor 60 + 5 + 2.4GHz PTP/PTMP MetroLing^M 60 LW

1. Unpack the MetroLing



Package Contents

MetroLing[™] 60 LW (ML-60-LW)

Tools/Items Required


- Flat-head screwdriver
- Ethernet cables

2. Mount the MetroLing on a Pole





- 1) Slide the pole-mount bracket onto the rails on the back of the AP until it snaps into its secured position.
- Use the included M3 screw to secure the bracket to the AP.



- Feed the two steel-band clamps through the pole-mount bracket mounting points.
- 4 Fasten the steel-band clamps around the pole to secure the AP to the pole.

IgniteNet

3. Grounding



- Ensure the structure on which the unit is to be mounted is properly grounded and in compliance with ETSI ETS 300 253.
- Verify that there is a good electrical connection to a grounding point (no paint or isolating surface treatment). Use the included (M4) screw to attach a grounding wire (not included) to the grounding point on the unit, and then to ground.



Caution: The earth connection must not be removed unless all supply connections have been disconnected.

4. Connect Cables





- Connect outdoor-rated Category 5e or better cable to the **RJ45** port. (The other end of this cable connects to the PoE power injector.)
- Install a 1G SFP transceiver in the **SFP** port, and then connect fiber optic cabling to the transceiver.

The following transceivers are supported:

- 1000BASE-SX
- 1000BASE-LX

5. Connect Power

a. Using the PoE Power Injector



1 Connect outdoor-rated Category 5e or better cable from the MetroLing to the **POE** port on the power injector.

- 2 Connect Category 5e or better cable from the **LAN** port on the power injector to a LAN switch.
- 3 Connect the power cord to the power injector and to a nearby AC power source (100-240 VAC, 50/60 Hz).



Caution: The power injector is designed for indoor use only. Never mount the power injector outside with the MetroLing unit.

b. DC Power





Warning: Before wiring the DC block or connecting power to the device, ensure that power to the feed lines is turned off at the supply circuit breaker or disconnected from the power bus.

- 1) Connect the 24 VDC power feed wire to the DC block "+" pin.
- Connect the ground/return wire to the DC block "-" pin.

6. Verify AP Operation



- (1) The **power** LED should be on amber.
- The RJ45 port link/activity LED should be on/blinking green.
- When connected, the **SFP** port link/activity LEDs should also be on/blinking green.
- During normal operation, the wireless LEDs should be on/ blinking green.

7. Connect to the Web User Interface

To access the web interface, connect a PC directly to the MetroLinq's **RJ45** port. In a web browser, enter the default management IP address of 192.168.1.20 to access the web login page.




Log in to the web interface using the default settings:

- Login Name root
- Password admin123



Note: To reset the MetroLinq to factory default settings, press and hold down the AP's **Reset** button for 10 seconds.

8. Complete the Setup Wizard



Select the country of operation for the AP. Setting the correct country ensures that the radios operate within local regulations specified for Wi-Fi networks.

Manage the MetroLing with the IgniteNet Cloud Controller

Go to **cloud.ignitenet.com** to register your AP.

Log in and select **Devices** from the menu. Click **Add Device** and enter the MetroLinq serial number and MAC address to register the MetroLinq with your cloud network. The serial number and MAC address can be found on the product packaging or label.

Manage the MetroLing in Stand-Alone Mode

If you select to manage the MetroLinq in stand-alone mode, use the web interface to manually make your configuration changes. For more information on MetroLinq configuration in stand-alone mode, refer to the *User Manual*, which can be downloaded from **ignitenet.com/support**.

Safety and Regulatory Information

FCC Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- ◆ Consult the dealer or an experienced radio/TV technician for help

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For product available in the USA/Canada market, only channel 1–11 can be operated. Selection of other channels is not possible.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 23 cm between the radiator and your body.

Industry Canada

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

For product available in the USA/Canada market, only channel 1–11 can be operated. Selection of other channels is not possible.

Pour les produits disponibles aux États-Unis / Canada du marché, seul le canal 1 à 11 peuvent être exploités. Sélection d'autres canaux n'est pas possible.

IMPORTANT NOTE:

IC Radiation Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 25 cm between the radiator and your body.

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 25 cm de distance entre la source de rayonnement et votre corps.

CE Statement

This equipment complies with EU radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

All operational modes:

2.4 GHz: 802.11b, 802.11g, 802.11n (HT20), 802.11n (HT40) 5 GHz: 802.11a, 802.11n (HT20), 802.11n (HT40), 802.11ac (VHT20), 802.11ac (VHT40), 802.11ac (VHT80) 60 GHz: 802.ad

The frequency and maximum transmitted power limit in EU are listed as below:

2412-2472 MHz: 20 dBm 5500-5700 MHz: 30 dBm 57-66 GHz

AT	BE	BG	СН	CY	CZ
DE	DK	EE	EL	ES	FI
FR	HR	HU	ΙE	IS	IT
LI	LT	LU	LV	MT	NL
NO	PL	PT	RO	SE	SI
SK	TR	UK			

The abbreviations of the countries, as prescribed in above table, where any restrictions on putting into service or any requirements for authorization of use exist.



Europe - EU Declaration of Conformity

Hereby, **IgniteNet Inc.** declares that the radio equipment type: MetroLinq[™] 60 LW is in compliance with Directive 2014/53/EU and Directive 2014/35/EU.

The full text of the EU declaration of conformity is available at the following Internet address: www.ignitenet.com -> support.

NCC Statement (Taiwan)

低功率電波輻射性電機管理辦法

第十二條 經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時‧應立即停用‧並改善至無干擾時方得繼續使用‧前項合法通信‧指依電信法規定作業之無線電通信‧低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

電磁波曝露量 MPE 標準值 1mW/cm²·本產品使用時建議應距離人體 20 cm。

Warnings and Cautionary Messages



Warning: This product does not contain any serviceable user parts.

Warning: Installation and removal of the unit must be carried out by qualified personnel only.

Warning: When connecting this device to a power outlet, connect the field ground lead on the tri-pole power plug to a valid earth ground line to prevent electrical hazards.



Caution: Wear an anti-static wrist strap or take other suitable measures to prevent electrostatic discharge when handling this equipment.

Caution: Do not plug a phone jack connector in the RJ-45 port. This may damage this device.

Caution: Use only twisted-pair cables with RJ-45 connectors that conform to FCC standards.

Regulatory Compliances

Radio EN 300 328 V2.1.1(2016-11)

EN 301 893 V2.1.1(2017-03) EN 302 567 V2.1.1 (2017.07) 47 CFR FCC Part 15.247 47 CFR FCC Part 15.407 47 CFR FCC Part 15.255 ICES-003,Issue 6,Class B

RSS-247

RSS-102 Issue 5 RSS-Gen Issue 4 RSS-210 Issue 9

Emissions EN 301 489-1 V2.2.1 (2017-02)

EN 301 489-17 V3.1.1 (2017-02)

47 CFR FCC Rules and Regulations Part 15

Subpart B, Class B Digital Device

Canada Standard ICES-003, Issue 6, Class B

Hardware Specifications

Chassis

Size (L x W x H:) 202.7 x 239.8 x 48 mm (7.98 x 9.44 x 1.89

inch)

Weight 650 g (1.43 lb)

Temperature Operating: -30 °C to 55 °C (-22 °F to 131 °F)

Storage: -40 °C to 70 °C (-40 °F to 158 °F)

Humidity Operating: 10% to 90% (non-condensing)

Network Interfaces

Ports RJ45 Port: 1000BASE-T, passive PoE

SFP Port: 1000BASE-X

60 GHz Radio IEEE 802.11ad
2.4 GHz Radio IEEE 802.11b/g/n
5 GHz Radio IEEE 802.11a/n/ac

Radio Frequencies 2412–2472 (FCC, IC, CE, AU, MIC, NCC, SRRC)

5150–5250 (FCC, NCC) 5470–5725 (CE, MIC, AU) 5725–5850 (FCC, IC, NCC, SRRC)

58.32-64.80 GHz

Power Supply

PoE 24 VDC passive PoE Power Consumption 24 W maximum Manufacturer

Accton Technology Corporation

1, Creation 3rd Rd., Hsinchu Science Park,
Hsinchu 30077,
Taiwan, R.O.C

US Contact

IgniteNet
20 Mason,
Irvine, CA 92618,

https://www.ignitenet.com/

USA