

Before you proceed with the installation, please notice the following descriptions.

Note 1: The following installation was operated under Windows XP.

(Procedures are similar for Windows 98SE/Me/2000.)

Note 2: If you have installed the WLAN USB driver & utility before, please uninstall the old version first.

Note 3: Do not insert the wireless LAN adaptor into your computer until the procedure in “Install the Driver & Utility” has been performed.

1. Installation


1. If you insert the Wireless LAN USB Adaptor into your computer USB port after ``installing the software program from the CD, then the following window pops up.

2. Click **Cancel**.




3. Choose a set up language.

4. Click **Next** to process the installation. .



5. Click install to WLAN USB adaptor installation.




6. On Windows Logo Software Installation screen, click **Continue Anyway** to continue.

Note: Not all the drivers will have this message box.



7. Click **Finish** to complete the installation.



8. After setup, restart your computer




2. Uninstallation


- A. Uninstall the WLAN USB Adaptor Driver from “Wireless Network Driver and Utility” or “Control Panel”. Click “Uninstall” (or “Change/Remove”) to remove Wireless LAN USB Adaptor driver.



- B. Click “OK” if you want to remove Wireless LAN USB Adaptor Driver.
- C. Click “Finish” to complete the uninstallation.




Making a Basic Network Connection



In the following instruction for making a network connection, we use the utility we provided to configure your wireless network settings.

Note: For Windows XP users that want to configure your wireless network using this Utility, please perform the following procedures to disable your native Windows XP wireless support (Wireless Zero Configuration Service)

1. Double click the  icon on your desktop to start the utility or  in the task bar.




Ad-Hoc Mode

An Ad-Hoc mode wireless network connects two computers directly without the use of a router or AP. It is also known as a peer-to-peer network. For example, we can

install this wireless adapter to two computers respectively. The communication


between the two computers is an Ad-Hoc mode network.




Ad-Hoc Mode

To use this adapter in Ad-Hoc Mode

1. Double click the  icon on your desktop to start the utility or  in the task bar.
2. Click the “Available Network” button to scan available wireless network adapters. Double click on the network adapter that you are going to connect to.




3. Click the OK button to confirm that you are connecting to an open wireless network.




4. Click OK to add this network into the profile list.

Note: This example is an open wireless network. If you are going to connect to a Wireless adapter with security protection, you will have to configure the encryption settings in this profile to be corresponding to the other wireless adapter. Please click on the "Network Authentication" drop list to select an authentication method, and then select a "Data encryption" type. Fill in each required blanks and click "OK".



Infrastructure mode


An Infrastructure Mode network contains at least one wireless client and one wireless AP or router. This client connects to Internet or intranet by communicating with this wireless AP.




Infrastructure Mode

To use this adapter in Infrastructure Mode:


1. Double click the  icon on your desktop to start the utility or  in the task bar.
2. Click the “Available Network” button to scan available access points. Double click on the AP that you are going to connect to.



3. Double click to create profile that you are connecting to an open wireless network.



4. Click OK to add this network into the profile list.




Note:

This example is an open wireless network. If you are going to connect to an AP with security protection, you will have to configure the encryption settings in this profile to be corresponding to your AP. Please click on the “Network Authentication” drop list to select an authentication method, and then select a “Data encryption” type. Fill in each required blanks and click “OK”.


Tip: Windows XP and Windows 2000 users is also allowed to connect to your wireless network with the “RT-Set” setup wizard. Please refer to “Appendix” for more information.

Introduction to the Wireless LAN Utility



Note: This management instruction uses Windows XP as the presumed operation system. Some functions are not supported in Windows 98se or Windows ME.

Starting the Wireless LAN Utility




You may click on the tabs above to configure this adapter. The checkboxes below provide the following functions:

| | |
|-----------------|--|
| Show Tray Icon | Check this checkbox to show the utility icon on your system tray, which is in the notification area at the lower-right corner of the windows desktop. You may also uncheck it to remove the utility icon from system tray. |
| Radio Off | Check this checkbox to prevent this adapter form transmitting or receiving signals. Uncheck it to communicate. |
| Disable Adapter | Check this checkbox to disable this wireless adapter. Uncheck it to enable this adapter again. |

General


After starting the utility, the general page pops up. This General tab provides the information of your current wireless network connection. You may click the Renew IP button to refresh those listed information.



| | |
|------------------|---|
| Status: | Check if the device associated to target network. |
| Speed: | The current connection speed |
| Type: | Infrastructure mode or Ad-Hoc mode. |
| Encryption: | The performing encryption mode for connecting to current network profile. |
| SSID: | The SSID (network name) of the connected wireless network. |
| Signal Strength: | Indicates the signal strength detected by this adapter. |
| Link Quality | Indicates the link quality of this wireless connection. |
| Network Address: | Shows the current IP addresses settings for this adapter. |

Profile


The Profile tab lists the preferred connections. You can click the buttons beside to do configure each connection.



- Add** Click this button to add a connection profile for this adapter.
- Remove** To remove a connection profile, click this profile on the profile list and click this button to delete it.
- Edit** To modify the configurations for a profile, click this profile on the profile list and click this button to edit.
- Duplicate** To make a copy of a profile, click the profile that going to be copied, and click this button to copy it.
- Set Default** To select a profile as your default wireless connection, click this profile on the list and click this button. You may also double click on each profile to select it as your default wireless connection.

Available Network

This available tab lists the reachable wireless network of this adapter.



| SSID | Channel | Encryption | Network Authentication |
|----------|---------|------------|------------------------|
| ARG-TEST | 1 | None | Unknown |
| TP-LINK | 6 | None | Unknown |

Refresh Add to Profile

Note
Double click on item to join/create profile.

Refresh

Click this button to rescan available networks around the adapter.

Add to Profile

To add an available Network to your profile list, select an available network and click this button to add.

Advanced

This Advanced tab provides advanced configurations to this adapter. Every modification in this tab will be performed after clicking the Apply button.

To restore the default settings of the advanced tab, click the Set defaults button to perform restoring.

| | |
|--|---|
| None | Disable Power saving function. |
| Min | Minimum power consumption |
| Max | Maximum power consumption |
| OFF | Disable turbo mode |
| ON | Enable turbo mode |
| AUTO | Enable or disable turbo automatically according to the detected environment |
| The maximum size of a packet that is going to be segmented and transmitted. Select the size from 256 to 2432(default) bytes. | |
| Select the RTS Threshold form 0 to 2432(default) | |
| 802.11g/b | Connect to a 802.11b/g network (2.4GHz/54Mbps) |
| 802.11b | Connect to a 802.11b network (2.4GHz/11Mbps) |

| |
|---|
| 802.11b Preamble Mode |
| Select the preamble mode to be long, short or auto detection mode. |
| Channel Plan |
| Select your region from the drop list. Please note that it is necessary for you to select a correct region. Selecting an incorrect region may again the applicable law. |
| PSP XLink Mode |
| If you are using the PS2 or X-box for wireless connection |


Status

This tab shows the current connection status of this adapter.

| General | Profile | Available Network | Advanced | Status | Statistics | Wi-Fi Protect Setup |
|---------------------|---------|-------------------|----------|---------------------|------------|---------------------|
| Manufacturer | | | | = Realtek | | |
| NDIS Driver Version | | | | = 5.1097.718.2007 | | |
| Short Radio Header | | | | = Yes | | |
| Encryption | | | | = Disabled | | |
| Authenticate | | | | = Open | | |
| Channel Set | | | | = FCC | | |
| MAC Address | | | | = 00:E0:4C:00:0C:32 | | |
| Data Rate (AUTO) | | | | = 11 Mbps | | |
| Channel (Frequency) | | | | = 6 (2437 MHz) | | |
| Status | | | | = Associated | | |
| SSID | | | | = TP-LINK | | |
| Network Type | | | | = Infrastructure | | |
| Power Save Mode | | | | = None | | |
| Associated AP MAC | | | | = 00:19:E0:A5:A2:DC | | |
| Up Time (hh:mm:ss) | | | | = 0:00:16 | | |

Statistics

See this tab to show the transmission activity record. Clicking the “Reset” button recounts the values from zero.




The screenshot shows the 'REALTEK USB Wireless LAN Utility' window with the 'Statistics' tab selected. The window title bar includes 'Refresh(R)', 'Set Wizard(S)', 'Mode(M)', 'View(V)', and 'About(A)'. The left sidebar shows 'MyComputer' and 'Realtek RTL8187B V'. The main area contains a table with the following data:

| Counter Name | Value |
|-----------------|-------|
| Tx OK | 43 |
| Tx Error | 0 |
| Rx OK | 21 |
| Rx Packet Count | 21 |
| Rx Retry | 4 |
| Rx ICV Error | 0 |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

Below the table is a 'Reset' button. At the bottom of the window, there are checkboxes for 'Show Tray Icon' (checked), 'Radio Off', and 'Disable Adapter' (unchecked), along with a 'Close' button.


AP mode management guide



General


After configuring the adapter in AP mode, this “General” page shows up, which shows the general information of this AP.

- SSID:** The SSID (network name) of the wireless network constructed by this AP.
- BSSID:** The MAC address of this AP
- Config:** Click this button to change configurations to this AP
- Association Table:** Shows the information of those devices that associated with this AP including their MAC addresses and the time that they connected with this device.




Advanced

- Beacon Interval:** Define the interval between beacons from 20~1000
DTIM Period: Set the DTIM period between 1~255
Preamble Mode: Click the drop list to select the preamble to be long, short or auto
- Set Defaults:** Click this button to restore the settings above to default
Apply: Click this button to execute changes.



Statistics


See this tab to show the transmission activity record. Clicking the “Reset” button recounts the values from zero.



Internet Connection Sharing (ICS)

This page allows users to select the adapter for connect to public network.

Please click on the device that are used for connecting to public network and click the “Select” button, and then click the “Apply” button to execute.



1. Fixed on the wall , directly by 4 screws



Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

You must use the Ferrite core and coil the USB cable around it twice.

